


# JVC

## SERVICE MANUAL

Hi-Fi STEREO VIDEO CASSETTE RECORDER

### HR-S9000EG



D2 **MAC**

**VPT-TOP** TELETEXT PROGRAMMING

#### SPECIFICATIONS

##### GENERAL

|                        |                                                                                               |
|------------------------|-----------------------------------------------------------------------------------------------|
| Power requirement      | : 220 V~, 50/60 Hz                                                                            |
| Power consumption      | : 67 W                                                                                        |
| Temperature            | : 5°C to 40°C (Operating)<br>-20°C to 60°C (Storage)                                          |
| Humidity               | : 35% to 80% (Operating)<br>5% to 80% (Storage)                                               |
| Operating position     | : Horizontal only                                                                             |
| Dimensions (WxHxD)     | : 471 x 124 x 424 mm                                                                          |
| Weight                 | : 9.3 kg                                                                                      |
| Tape format            | : S-VHS/VHS PAL standard                                                                      |
| Tape width             | : 12.65 mm                                                                                    |
| Tape speed (SP)        | : 23.39 mm/sec                                                                                |
| (LP)                   | : 11.70 mm/sec                                                                                |
| Maximum recording time | : (VHS) : 480 min. with E-240 video cassette<br>(S-VHS) : 360 min. with SE-180 video cassette |

##### VIDEO

|                       |                                                                                                    |
|-----------------------|----------------------------------------------------------------------------------------------------|
| Signal system         | : PAL colour and separated Y/C signals, 525 lines/60 fields (with D2-MAC decoder)                  |
| Recording system      | : Rotary two-head helical scan system with slant double-azimuth combination video heads            |
| Input                 | : 0.5 to 2.0 Vp-p, 75 ohms, unbalanced                                                             |
| Output                | : 1.0 Vp-p, 75 ohms, unbalanced                                                                    |
| Signal-to-noise ratio | : 43 dB (Rohde & Schwarz noise meter) with picture sharpness control at centre position            |
| Horizontal resolution | : More than 400 lines (S-VHS)/250 lines (VHS SP) with picture sharpness control at centre position |

##### AUDIO

|        |                                                                                                                                                                                                                                           |
|--------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Input  | : Mic: -67 dBs, high impedance, unbalanced<br>: AUDIO EING. connector (RCA x 2):<br>-8 dBs, 50 k-ohms, unbalanced<br>: A/V1 EING./AUSG. and A/V2 EING. socket (21-pin Peri connector): -3.8 dBs (CENELEC standard), 10 k-ohms, unbalanced |
| Output | : AUDIO AUSG. connector (RCA x 2):<br>-8 dBs, high impedance load<br>: A/V1 EING./AUSG. socket (21-pin Peri connector): -3.8 dBs (CENELEC standard), high impedance load, less than 1 k-ohm, unbalanced (100 k-ohms, load)                |

##### NORMAL AUDIO

|                             |                                                                                                                                     |
|-----------------------------|-------------------------------------------------------------------------------------------------------------------------------------|
| Recording system            | : Longitudinal track                                                                                                                |
| No. of channels             | : 1 (Monaural)                                                                                                                      |
| Frequency response          | : 100 Hz to 10,000 Hz                                                                                                               |
| Hi-Fi AUDIO                 |                                                                                                                                     |
| Recording system            | : Deep-layer recording system conforming to stereo Hi-Fi VHS standard                                                               |
| No. of channels             | : 2 (stereo)                                                                                                                        |
| Frequency response          | : 20 Hz to 20,000 Hz                                                                                                                |
| Dynamic range               | : More than 90 dB                                                                                                                   |
| Wow and flutter             | : Less than 0.005% WRMS                                                                                                             |
| TUNER                       |                                                                                                                                     |
| Tuning system               | : Frequency synthesized tuner                                                                                                       |
| TV channel storage capacity | : 48 positions (+ AUX position "AU")                                                                                                |
| Channel coverage            | : VHF 47 - 111 MHz<br>111 - 300 MHz<br>Hyperband (APL)<br>300 - 470 MHz<br>Hyperband (D2-MAC)<br>300 - 465 MHz<br>UHF 470 - 862 MHz |

##### Aerial output

: UHF channel 36 (adjustable 32 - 40)

##### TIMER

|                     |                          |
|---------------------|--------------------------|
| Clock reference     | : Quartz-crystal         |
| Programme capacity  | : 1-yr/8-programme timer |
| Memory back-up time | : Minimum 3 min.         |

##### ACCESSORIES

|                      |                                                                                                                                                        |
|----------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------|
| Provided accessories | : Aerial cable,<br>Infrared remote control unit,<br>"RB" battery x 2<br>Audio cable (RCA-RCA)<br>S-Video cable (4-pin/4-pin)<br>Cassette tape (SE-180) |
|----------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------|

Specifications shown are for SP mode unless otherwise specified.  
E. & O.E. Design and specifications subject to change without notice.

NOTE: For a technical description, please refer to Technical Guide VTG82051 HR-S9000EG.

## TABLE OF CONTENTS

| Section                                         | Title                                                      | Page | Section | Title                                                                                            | Page  |
|-------------------------------------------------|------------------------------------------------------------|------|---------|--------------------------------------------------------------------------------------------------|-------|
| <b>Important Safety Precautions</b>             |                                                            |      | 3.8     | AUDIO BLOCK DIAGRAM .....                                                                        | 3-17  |
| <b>INSTRUCTIONS</b>                             |                                                            |      | 3.9     | DECORDER/VPT BLOCK DIAGRAM .....                                                                 | 3-19  |
| <b>1. DISASSEMBLY AND MECHANISM ADJUSTMENTS</b> |                                                            |      | 3.10    | VPT BLOCK DIAGRAM .....                                                                          | 3-23  |
| 1.1                                             | DISASSEMBLY .....                                          | 1-1  | 3.11    | POWER SYSTEM BLOCK DIAGRAM .....                                                                 | 3-25  |
| 1.1.1                                           | External covers .....                                      | 1-1  | 3.12    | SWITCHING POWER SUPPLY AND REGULATOR<br>SCHEMATIC DIAGRAMS .....                                 | 3-27  |
| 1.1.2                                           | Circuit boards .....                                       | 1-2  | 3.13    | SWITCHING POWER SUPPLY AND REGULATOR<br>CIRCUIT BOARDS .....                                     | 3-29  |
| 1.1.3                                           | Disconnecting the flat wire .....                          | 1-3  | 3.14    | MECHANISM CONTROL SCHEMATIC DIAGRAM .....                                                        | 3-31  |
| 1.2                                             | MECHANISM ADJUSTMENT .....                                 | 1-4  | 3.15    | DECK TERMINAL, CASSETTE HOUSING, RELAY,<br>END SENSOR AND REC SAFETY SCHEMATIC<br>DIAGRAMS ..... | 3-33  |
| 1.2.1                                           | Precautions .....                                          | 1-4  | 3.16    | DECK TERMINAL, CASSETTE HOUSING, RELAY,<br>END SENSOR AND REC SAFETY CIRCUIT BOARDS .....        | 3-34  |
| 1.2.2                                           | Check without cassette housing .....                       | 1-4  | 3.17    | MECHANISM CONTROL AND AUDIO CONTROL HEAD<br>CIRCUIT BOARDS .....                                 | 3-37  |
| 1.2.3                                           | Manually removing cassette tape .....                      | 1-4  | 3.18    | SERVO AND SERVO SUB SCHEMATIC DIAGRAM ....                                                       | 3-38  |
| 1.2.4                                           | Test equipment .....                                       | 1-4  | 3.19    | SERVO AND SERVO SUB CIRCUIT BOARDS .....                                                         | 3-41  |
| 1.3                                             | MAIN MECHANISM PARTS .....                                 | 1-5  | 3.20    | VIDEO SCHEMATIC DIAGRAM .....                                                                    | 3-43  |
| 1.4                                             | INSPECTION AND MAINTENANCE .....                           | 1-7  | 3.21    | VIDEO CIRCUIT BOARD .....                                                                        | 3-46  |
| 1.4.1                                           | Suggested servicing schedule for main<br>components .....  | 1-7  | 3.22    | JACK SCHEMATIC DIAGRAMS AND CIRCUIT<br>BOARD .....                                               | 3-51  |
| 1.5                                             | MAIN ASSEMBLY REPLACEMENT .....                            | 1-8  | 3.23    | FLYING ERASE DIAGRAM AND CIRCUIT BOARD ...                                                       | 3-52  |
| 1.6                                             | ASSEMBLY PROCEDURE OF MECHANISM .....                      | 1-10 | 3.24    | PRE/REC AMP SCHEMATIC DIAGRAM .....                                                              | 3-53  |
| 1.7                                             | CONFIRMATION AND ADJUSTMENT .....                          | 1-12 | 3.25    | PRE/REC AMP CIRCUIT BOARD .....                                                                  | 3-55  |
| 1.8                                             | TAPE TRANSPORT CHECKS AND ADJUSTMENT<br>PREPARATIONS ..... | 1-13 | 3.26    | AUDIO SCHEMATIC DIAGRAM .....                                                                    | 3-57  |
| 1.9                                             | INTERCHANGEABILITY CHECKS AND<br>ADJUSTMENTS .....         | 1-14 | 3.27    | AUDIO CIRCUIT BOARD .....                                                                        | 3-59  |
| <b>2. ELECTRICAL ADJUSTMENTS</b>                |                                                            |      | 3.28    | AV IN/OUT SCHEMATIC DIAGRAM .....                                                                | 3-61  |
| 2.1                                             | PREPARATION .....                                          | 2-1  | 3.29    | AV IN/OUT CIRCUIT BOARD .....                                                                    | 3-63  |
| 2.1.1                                           | Required test equipment .....                              | 2-1  | 3.30    | IF SCHEMATIC DIAGRAM .....                                                                       | 3-65  |
| 2.1.2                                           | Check and adjustment steps .....                           | 2-2  | 3.31    | IF CIRCUIT BOARD .....                                                                           | 3-67  |
| 2.2                                             | SWITCHING REGULATOR CIRCUIT .....                          | 2-3  | 3.32    | TUNER CONTROL SCHEMATIC DIAGRAM .....                                                            | 3-69  |
| 2.3                                             | TIMER CIRCUIT .....                                        | 2-3  | 3.33    | TUNER CONTROL CIRCUIT BOARD .....                                                                | 3-71  |
| 2.4                                             | SERVO CIRCUIT .....                                        | 2-4  | 3.34    | DEMOMULATOR SCHEMATIC DIAGRAM .....                                                              | 3-73  |
| 2.5                                             | VIDEO CIRCUIT .....                                        | 2-5  | 3.35    | DEMOMULATOR CIRCUIT BOARD .....                                                                  | 3-75  |
| 2.6                                             | AUDIO CIRCUIT .....                                        | 2-12 | 3.36    | TIMER SCHEMATIC DIAGRAM .....                                                                    | 3-77  |
| 2.7                                             | TUNER/IF CIRCUIT .....                                     | 2-13 | 3.37    | TIMER CIRCUIT BOARD .....                                                                        | 3-79  |
| 2.8                                             | DEMOMULATOR CIRCUIT .....                                  | 2-15 | 3.38    | DISPLAY SCHEMATIC DIAGRAM .....                                                                  | 3-81  |
| 2.9                                             | PRE/REC CIRCUIT .....                                      | 2-16 | 3.39    | DISPLAY CIRCUIT BOARD .....                                                                      | 3-83  |
| 2.10                                            | DECORDER/VPT CIRCUIT .....                                 | 2-17 | 3.40    | DECORDER-1 SCHEMATIC DIAGRAM .....                                                               | 3-85  |
| <b>3. CHARTS AND DIAGRAMS</b>                   |                                                            |      | 3.41    | DECORDER-2 SCHEMATIC DIAGRAM .....                                                               | 3-87  |
| 3.1                                             | CIRCUIT BOARD LOCATION .....                               | 3-1  | 3.42    | DECORDER/VPT CIRCUIT BOARD .....                                                                 | 3-91  |
| 3.2                                             | GENERAL INFORMATION .....                                  | 3-2  | 3.43    | VPT/CTL SCHEMATIC DIAGRAM .....                                                                  | 3-95  |
| 3.2.1                                           | Connections .....                                          | 3-2  | 3.44    | AUTO TRACKING SCHEMATIC DIAGRAM .....                                                            | 3-97  |
| 3.2.2                                           | Disconnecting the flatwire .....                           | 3-2  | 3.45    | AUTO TRACKING CIRCUIT BOARD .....                                                                | 3-99  |
| 3.2.3                                           | Indications .....                                          | 3-2  | 3.46    | TERMINAL SCHEMATIC DIAGRAM .....                                                                 | 3-101 |
| 3.2.4                                           | Schematic diagram values .....                             | 3-2  | 3.47    | TERMINAL CIRCUIT BOARD .....                                                                     | 3-103 |
| 3.2.5                                           | Signal flow in the schematic .....                         | 3-2  | 3.48    | OPERATION AND STEP SCHEMATIC DIAGRAM ....                                                        | 3-105 |
| 3.2.6                                           | Semiconductors .....                                       | 3-3  | 3.49    | OPERATION AND STEP CIRCUIT BOARDS .....                                                          | 3-107 |
| 3.2.7                                           | Replacement of chip parts .....                            | 3-3  | 3.50    | SWITCH SCHEMATIC DIAGRAM .....                                                                   | 3-109 |
| 3.3                                             | BOARD INTERCONNECTIONS .....                               | 3-5  | 3.51    | SWITCH CIRCUIT BOARD .....                                                                       | 3-111 |
| 3.4                                             | SERVO BLOCK DIAGRAM .....                                  | 3-7  | 3.52    | RF CONVERTER SCHEMATIC DIAGRAM .....                                                             | 3-113 |
| 3.5                                             | MECHAON BLOCK DIAGRAM .....                                | 3-9  | 3.53    | REMOTE CONTROLLER SCHEMATIC DIAGRAM ...                                                          | 3-115 |
| 3.6                                             | VIDEO BLOCK DIAGRAM .....                                  | 3-11 |         |                                                                                                  |       |
| 3.7                                             | PRE/REC BLOCK DIAGRAM .....                                | 3-15 |         |                                                                                                  |       |

| Section                                     | Title                                     | Page |
|---------------------------------------------|-------------------------------------------|------|
| <b>4. EXPLODED VIEWS AND PARTS LIST</b>     |                                           |      |
| 4.1                                         | PACKING ASSEMBLY <M1> .....               | 4-1  |
| 4.2                                         | CABINET ASSEMBLY <M2> .....               | 4-3  |
| 4.3                                         | CHASSIS ASSEMBLY <M3> .....               | 4-5  |
| 4.4                                         | MECHANISM ASSEMBLY (1) <M4> .....         | 4-7  |
|                                             | MECHANISM ASSEMBLY (2) <M4> .....         | 4-8  |
| <b>5. ELECTRICAL PARTS LIST</b>             |                                           |      |
| SW POWER SUPPLY BOARD ASSY <01><02> .....   |                                           | 5-1  |
| MECHAON BOARD ASSEMBLY <04> .....           |                                           | 5-4  |
| VIDEO BOARD ASSEMBLY <05> .....             |                                           | 5-5  |
| TERMINAL BOARD ASSEMBLY <06> .....          |                                           | 5-12 |
| IF BOARD ASSEMBLY <07> .....                |                                           | 5-13 |
| TUNER CTL BOARD ASSEMBLY <08> .....         |                                           | 5-14 |
| AUDIO BOARD ASSEMBLY <09> .....             |                                           | 5-15 |
| AUDIO/VIDEO IN OUT BOARD ASSY <10> .....    |                                           | 5-18 |
| AUDIO CONTROL HEAD BOARD <12> .....         |                                           | 5-20 |
| DEMODULATOR BOARD ASSEMBLY <14> .....       |                                           | 5-20 |
| TIMER BOARD ASSEMBLY <20> .....             |                                           | 5-21 |
| OPERATION BOARD ASSEMBLY <22> .....         |                                           | 5-23 |
| SW/JACK BOARD ASSEMBLY <26><36> .....       |                                           | 5-24 |
| DISPLAY/STEP BOARD ASSY <27><37> .....      |                                           | 5-24 |
| SERVO SUB BOARD ASSEMBLY <39> .....         |                                           | 5-26 |
| PRE/REC BOARD ASSEMBLY <43> .....           |                                           | 5-26 |
| FLYING ERASE BOARD ASSEMBLY <46> .....      |                                           | 5-28 |
| SERVO BOARD ASSEMBLY <48> .....             |                                           | 5-29 |
| DECK TERMINAL BOARD ASSEMBLY <51><53> ..... |                                           | 5-30 |
| RELAY BOARD ASSEMBLY <52> .....             |                                           | 5-31 |
| END SENSOR BOARD ASSEMBLY <54> .....        |                                           | 5-31 |
| CASSETTE HOUSING BOARD <56> .....           |                                           | 5-31 |
| UPPER DRUM BOARD <62><63> .....             |                                           | 5-31 |
| AUTO TRACKING BOARD ASSEMBLY <83> .....     |                                           | 5-31 |
| DECODE/VPT BOARD ASSEMBLY <87> .....        |                                           | 5-32 |
| <b>6. TECHNICAL INFORMATION</b>             |                                           |      |
| 6.1                                         | MECHANISM CONTROL CPU PIN FUNCTIONS ..... | 6-1  |
| 6.1.1                                       | IC1 pin function .....                    | 6-1  |
| 6.2                                         | TIMER/DISPLAY CONTROL CIRCUIT .....       | 6-2  |
| 6.2.1                                       | Timer CPU pin functions (IC1) .....       | 6-2  |
| 6.3                                         | TUNER CONTROL CIRCUIT .....               | 6-3  |
| 6.3.1                                       | Tuner CPU pin functions .....             | 6-3  |

# Important Safety Precautions

Prior to shipment from the factory, JVC products are strictly inspected to conform with the recognized product safety and electrical codes of the countries in which they are to be sold. However, in order to maintain such compliance, it is equally important to implement the following precautions when a set is being serviced.

## ●Precautions during Servicing

1. Locations requiring special caution are denoted by labels and inscriptions on the cabinet, chassis and certain parts of the product. When performing service, be sure to read and comply with these and other cautionary notices appearing in the operation and service manuals.

2. Parts identified by the  symbol and shaded (▨) parts are critical for safety.

Replace only with specified part numbers.

Note: Parts in this category also include those specified to comply with X-ray emission standards for products using cathode ray tubes and those specified for compliance with various regulations regarding spurious radiation emission.

3. Fuse replacement caution notice.

Caution for continued protection against fire hazard.

Replace only with same type and rated fuse(s) as specified.


4. Use specified internal wiring. Note especially:

- 1) Wires covered with PVC tubing
- 2) Double insulated wires
- 3) High voltage leads

5. Use specified insulating materials for hazardous live parts. Note especially:

- 1) Insulation Tape
- 3) Spacers
- 5) Barrier
- 2) PVC tubing
- 4) Insulation sheets for transistors


6. When replacing AC primary side components (transformers, power cords, noise blocking capacitors, etc.) wrap ends of wires securely about the terminals before soldering.



7. Observe that wires do not contact heat producing parts (heat-sinks, oxide metal film resistors, fusible resistors, etc.)

8. Check that replaced wires do not contact sharp edged or pointed parts.

9. When a power cord has been replaced, check that 10–15 kg of force in any direction will not loosen it.



10. Also check areas surrounding repaired locations.

11. Products using cathode ray tubes (CRTs)

In regard to such products, the cathode ray tubes themselves, the high voltage circuits, and related circuits are specified for compliance with recognized codes pertaining to X-ray emission. Consequently, when servicing these products, replace the cathode ray tubes and other parts with only the specified parts. Under no circumstances attempt to modify these circuits. Unauthorized modification can increase the high voltage value and cause X-ray emission from the cathode ray tube.

12. Crimp type wire connector

In such cases as when replacing the power transformer in sets where the connections between the power cord and power transformer primary lead wires are performed using crimp type connectors, if replacing the connectors is unavoidable, in order to prevent safety hazards, perform carefully and precisely according to the following steps.

1) Connector part number : E03830-001

2) Required tool : Connector crimping tool of the proper type which will not damage insulated parts.

3) Replacement procedure

(1) Remove the old connector by cutting the wires at a point close to the connector.


Important : Do not reuse a connector (discard it).




(2) Strip about 15 mm of the insulation from the ends of the wires. If the wires are stranded, twist the strands to avoid frayed conductors.




(3) Align the lengths of the wires to be connected. Insert the wires fully into the connector.



(4) As shown in Fig. 6, use the crimping tool to crimp the metal sleeve at the center position. Be sure to crimp fully to the complete closure of the tool.



(5) Check the four points noted in Fig. 7.





## PRECAUTIONS

Handling and storage

- Avoid using the recorder under the following conditions:
  - extremely hot, cold or humid places,
  - dusty places,
  - places subject to powerful strong magnetic fields,
  - places subject to vibrations, and
  - poorly ventilated places.

- Be careful of moisture condensation.
  - If the recorder is used in a room having a cold room or under extremely humid conditions.
  - In conditions where moisture condensation may occur, leave the power cord plugged in an AC outlet and the recorder on for a few minutes after use to prevent moisture from condensing on the tape.


- Handle the recorder carefully.
  - Do not place anything heavy on the recorder.
  - Do not place anything hot or cold on it and cause trouble on the top cover of the recorder.
  - Use in horizontal (flat) position only.

- In case of transportation,
  - Avoid jolts, shocks to the recorder during packing and unpacking.
  - Before packing, be sure to remove the cassette from the recorder.

### Video cassettes

- This recorder employs S-VHS and VHS cassettes only.
  - S-VHS: 2 hours and SECAM for 30 minutes/1 hour of recording.
  - VHS: E-240 for 4 hours/8 hours, E-180 for 3 hours/6 hours, E-120 for 2 hours/4 hours, E-90 for 1 hour/2 hours and E-60 for 30 minutes/1 hour of recording.

- Video cassettes are equipped with a safety tab to prevent accidental erasure. When the tab is removed, recording cannot be made. If the tab is removed, use adhesive tape to block the hole.



— Safety tab

- Avoid exposing the cassette to direct sunlight. Keep them away from heaters, radiators, electric fans, or other heat sources.
- Avoid placing cassettes near a magnet, transformer or magnet and dusty places.
- Place the cassettes in cassette cases and position vertically.

- Moisture condensation
  - If you pour a cold liquid into a glass, water vapour in the air will condense on the surface of the glass. This is called moisture condensation.
  - Moisture condensation on the head drum, one of the most crucial parts of the video recorder, will cause damage to the tape.
- Rotation in the air will condense on the recorder when you use it in a room having a cold room or under extremely humid conditions.
- In conditions where moisture condensation may occur, leave the power cord plugged in an AC outlet and the recorder on for a few minutes after use to prevent moisture from condensing on the tape.
- When condensation has occurred, it will not evaporate quickly once the power is switched on. Wait a few hours for the recorder to become dry.

### Remote control unit

- Avoid violent shocks, especially take care not to drop the unit.
- The unit can not allow liquid to spill into the unit.
- Do not place heavy objects on the unit.
- Avoid leaving the unit in places subject to direct sunlight or extremely high temperatures.

## WARNING


### Regarding S-VHS recordings

- Since the S-VHS Euro System is a unified standard, S-VHS recordings are the same regardless of whether the original signal is PAL or SECAM. However, this recorder can record only in the VHS mode for recording a SECAM signal.
- 1. S-VHS recording is not possible when the input signal is SECAM.
- 2. When the S-VHS indicator goes off.
- 3. The resulting tapes have the same limitations as described in "Regarding VHS recording".

### Regarding VHS recordings

There are two different types of SECAM colour systems: SECAM-L used in FRANCE (also called SECAM-L) and SECAM-B, used in the USSR, e.g. also called SECAM-East.

1. This recorder can also receive SECAM-B colour television signals for recording and playback.
2. Some monochrome pictures if played back on a video recorder of SECAM-L standard, or do not produce normal colour picture if played back on a PAL video recorder. This is because the colour signal incorporated (even if the TV set is SECAM-compatible).
3. SECAM-L pre-recorded cassettes or recordings made with a SECAM-L video recorder produce monochrome pictures when played back on a video recorder of SECAM-B standard.
4. Pictures when played back on a video recorder of SECAM-L standard, will be blurred for the SECAM-L transcoder signal.









## FOR A BETTER UNDERSTANDING OF S-VHS AND VHS

### S-VHS vs. VHS

• VHS is the world's most popular video format. If you owned a VCR before this recorder, most likely it was a VHS machine.

• This new video sub-format based on VHS, it offers superior picture quality with a horizontal resolution of more than 400 lines by shifting the FM carrier frequency of the luminance signal from the conventional 3.8 - 4.8 MHz range to a higher one of 5.4 - 7 MHz.


• This recorder is equipped for recording and playback in both the S-VHS and VHS formats. Therefore, you can still play back your VHS software programmes and previously recorded (taped) recordings on VHS for your new recordings to enjoy breath-taking picture quality. Or to exchange recordings with someone whose VCR is not S-VHS ready, simply record in the VHS mode. Whether with a regular VHS cassette or an S-VHS cassette.

### S-VHS Recording


Insert an S-VHS cassette; this indicator will light.



Press the S-VHS button; this indicator will light.




### Compatibility between S-VHS and VHS



### CATV Cable Connection

• First connect the cable TV line to the ANTENNA/ENGANG terminal of the recorder.



### RF Connection

- Then connect the HF AUDIO/VIDEO terminal of the television to the AUDIO/VIDEO terminal of the television using the provided aerial cable. When you are not using the recorder, the received TV signals are fed to the television via this terminal.
- If your television is equipped with the aerial terminal only, you view tape playback via this terminal. In this case, the aerial cable must be connected to a Video Channel. (See page 62.)

### SCART Connection

• Connect the AV1 ENG/AUGS connector of the recorder to the 21-pin SCART connector of the television. The output signal from the AV1 ENG/AUGS terminal is fed to the television via the provided S-VHS cable. In this case, be sure to connect the AUDIO/VIDEO connectors of the recorder to the AUDIO IN connectors of the television. The setting of the AV1 VIDEO-AUGS switch of the recorder (FMAS, Y/C, or AUTOM.) See chart on next page.

### 4-Pin S Connection

• If your television is equipped with a 4-pin S-VIDEO IN connector, simply connect the S-AUGS connector of the recorder to the S-VIDEO IN terminal of the television using the provided S-VIDEO cable. In this case, be sure to connect the AUDIO/VIDEO connectors of the recorder to the AUDIO IN connectors of the television. The setting of the AV1 VIDEO-AUGS switch of the recorder has no effect.

Note:  
When switching the television's input mode, refer to the instruction manual of your television.

## Audio connection


For more dynamic sound reproduction, a stereo system can be connected. By doing so, even with monaural televisions, you can play stereo and bilingual programmes. When listening to sound from the connected stereo system, turn down completely the sound volume of the television.

Connect the AUDIO ENG. L and R connectors of the recorder to the recording output terminals of the amplifier, and connect the AUDIO OUT L and R connectors of the recorder to the AUX IN or TAPE MONITOR terminals of the amplifier.

If you want to time-control the recording of FM simulcast programmes, connect the tuner's power cord to the recorder's AC outlet. Set the RETAUSCANCING switch to EFM, and connect the FM tuner's power cord to the recorder's power cord. The recorder's programmed time. Time-controlled recording of FM simulcast programmes is not possible with the type of tuners which reset the channel each time the power is switched on.

## CAUTION

• This recorder has a dynamic range of more than 90 dB with regards to its hi-fi audio capability. It is recommended that you use a hi-fi amplifier when listening to sound going to listen to the hi-fi audio signal through a stereo amplifier. A sudden surge in speaker input may cause speaker damage. When using a hi-fi amplifier, please prevent radiation interference. If both are of the same shielded type, do not place the speaker adjacent to the TV set, otherwise the video playback picture will not be normal because of mutual interference.



## Output signals from the HR-S9000EG's SCART connector depending on the type of source signals

The HR-S9000EG detects through its SCART connector whether the connected television is compatible with RGB or not, and delivers the output signal to the television in two different configurations.

### 1. With RGB-compatible televisions

| AVI VIDEO-AUSG.<br>Type of switch setting | FEAS                                                                                | Y/C                                  | AUTOM.                               |
|-------------------------------------------|-------------------------------------------------------------------------------------|--------------------------------------|--------------------------------------|
| Type signals                              | Composite                                                                           | Y/C                                  | Y/C                                  |
| Type playback                             | Composite, and RGB                                                                  | Y/C                                  | Composite, and RGB                   |
| On-screen menu                            | Composite, and RGB                                                                  | Y/C                                  | Composite, and RGB                   |
| EE                                        | Composite                                                                           | Y/C                                  | Y/C                                  |
| MAC                                       | Composite                                                                           | Y/C                                  | Y/C                                  |
| PAL                                       | Composite, and RGB                                                                  | Y/C                                  | Composite, and RGB                   |
| Text (MAC/PAL)                            | Composite picture with monochrome subtitle, and RGB with mixed picture and subtitle | Y/C picture with monochrome subtitle | Y/C picture with monochrome subtitle |
| MAC subtitles                             | Composite picture with monochrome subtitle                                          | Y/C picture with monochrome subtitle | Y/C picture with monochrome subtitle |
| PAL subtitles                             | Composite picture with monochrome subtitle                                          | Y/C picture with monochrome subtitle | Y/C picture with monochrome subtitle |

Note: If this television is an auto-RGB type, the upselected signal form appears on the TV screen. Otherwise, either output can be selected by setting the television's mode manually.

### 2. With non-RGB-compatible televisions

| AVI VIDEO-AUSG.<br>Type of switch setting | FEAS                                                                                | Y/C                                  | AUTOM.                               |
|-------------------------------------------|-------------------------------------------------------------------------------------|--------------------------------------|--------------------------------------|
| Type signals                              | Composite                                                                           | Y/C                                  | Y/C                                  |
| Type playback                             | Composite, and RGB                                                                  | Y/C                                  | Y/C                                  |
| On-screen menu                            | Composite, and RGB                                                                  | Y/C                                  | Y/C                                  |
| EE                                        | Composite                                                                           | Y/C                                  | Y/C                                  |
| MAC                                       | Composite                                                                           | Y/C                                  | Y/C                                  |
| PAL                                       | Composite, and RGB                                                                  | Y/C                                  | Y/C                                  |
| Text (MAC/PAL)                            | Composite picture with monochrome subtitle, and RGB with mixed picture and subtitle | Y/C picture with monochrome subtitle | Y/C picture with monochrome subtitle |
| MAC subtitles                             | Composite picture with monochrome subtitle                                          | Y/C picture with monochrome subtitle | Y/C picture with monochrome subtitle |
| PAL subtitles                             | Composite picture with monochrome subtitle                                          | Y/C picture with monochrome subtitle | Y/C picture with monochrome subtitle |

Note: Underslanted signal form appears on the TV screen.

## Direct Dish Reception


Current satellite tuners designed for PAL satellite broadcast reception can be connected to either SCART connector for reception of both PAL and D2-MAC broadcasts. (Use of PAL/2 ENG. connector is recommended.) At PAL and D2-MAC reception, the tuner's output is selected by the PAL/2 ENG. switch. For proper reception of either PAL or D2-MAC broadcasts.

### With a PAL satellite tuner

| Tuner's de-emphasis switch              | PAL    | D2-MAC |
|-----------------------------------------|--------|--------|
| HR-S9000EG's MACCH. SUBSTITUTION switch | ON     | OFF    |
|                                         | B/line | E/line |

### With a PAL/D2-MAC satellite tuner

| Tuner's de-emphasis switch              | PAL    | D2-MAC |
|-----------------------------------------|--------|--------|
| HR-S9000EG's MACCH. SUBSTITUTION switch | ON     | OFF    |
|                                         | B/line | E/line |



## VIDEO CHANNEL SETTING

When using an AV receiver with SCART or 4-pin S-video (see page 58), video channel setting is not necessary.


- Press the **RECALL** button **Ⓢ** to turn the power on. Turn on the TV receiver.
- Set the TEST switch **Ⓢ** to **ENL**.
- Adjust your TV receiver. The video channel setting screen will appear. The video signal you bring in from the two white signal lines on the screen as illustrated.
- Press the **TEST** switch to **ADJ**.



## CLOCK SETTING

### Setting the built-in clock


- Although the VCR clock can be set via the on-screen menu, manual setting of the VCR clock is also possible. Plug the recorder into an AC outlet. The display shows a series of dashes. Press the **NUMERIC** buttons to set the clock. Clock setting can also be performed by using the on-screen display. Refer to the VCR feature instructions accompanying this instruction manual for on-screen clock setting.
- Set the **TEST** switch **Ⓢ** to **ENL**.
  - Press the **RECALL** button **Ⓢ** to turn the power on. Turn on the TV receiver.
  - Set the TEST switch **Ⓢ** to **ADJ**.
  - Press the **NUMERIC** buttons to set the clock. Clock setting can also be performed by using the on-screen display. Refer to the VCR feature instructions accompanying this instruction manual for on-screen clock setting.



**Power failure indicator**  
The blinking "CLOCK" (initial condition of the display) is also a power failure indicator, showing that there has been a power outage. Press the **RECALL** button **Ⓢ** to turn the power on. This restores the normal condition of the clock display.

## Setting the LCD clock of the recorder's clock

The LCD clock is independent of the recorder's clock.



- Key in the digits corresponding to the current minute, then the day position of the DATE indication will blink.
- Key in the digits for the day, month and year in succession.  
In year setting, set only the last two digits of the year.
- Press the **UNREINTELLING** button at the exact instant the time signal.  
The day of the week indication will be set accurately to the second.  
The day of the week indication will be displayed automatically.  
Press the **UNREINTELLING** button and then press either **CURSOR** or **ENTER** button so that the position which requires correction blinks.


### SUMMER TIME ADJUST

For quickly making the annual clock adjustment to the "summer time" (daylight saving time) setting, and back to regular time later, use the **SOMMERZEIT** **ENST**.  
1. Simply press and quickly release the **SOMMERZEIT** **ENST** button to set the clock forward by one hour.  
2. To return the clock back to regular time, simply hold the **SOMMERZEIT** **ENST** button pressed for more than 2 seconds to set the clock back by an hour.  
Note:  
For summer time adjustment, make sure that the transfer-ready mark is on on the LCD.


Insert 2 "180"-size batteries (provided) into the remote control. The LCD shows the following with "2000" blinking.



- Press the **UNREINTELLING** button.  
This hour indication will blink.
- Press the numeric keys corresponding to the current hour, then the minute indication will blink.  
For a one-digit number, key in "0" first.



- Press the numeric keys corresponding to the current hour, then the minute indication will blink.  
For a one-digit number, key in "0" first.
- Press the numeric keys corresponding to the current hour, then the minute indication will blink.  
For a one-digit number, key in "0" first.



**Note:**  
If you press a wrong numeric key, you can return to the previous numeric key by pressing the **RECALL** button **Ⓢ**.  
Once all necessary data have been entered, you can reach any position for correction using the **ZURÜCK** and **VOR** keys.  
Clock setting is not possible during playback, or if the **SCART** **TURN** button **Ⓢ** is engaged with the **TIMER** in clear or **IL**. First check to see that the **TIMER** indicator is off.





The on-screen menu system facilitates initial VCR status setting and use of the built-in teletext decoder. For teletext operation, see page 88.

Initial VCR status setting includes clock setting, on-screen language selection and functions associated with D2-MAC. Since on-screen messages help you operate all other on-screen menu functions, we recommend that you set the language first.

#### On-Screen Message Language Setting



- Turn the recorder and television on, and set both units as required.
- 1 Press the MENU/TEXT button.
- 2 Press the number key "2" to select the four languages, depending on the present status will appear on the screen.
- 3 Press numeric key "4".
- 4 The INITIAL menu will appear.
- 5 The ON SCREEN LANG. menu will appear.
- 6 Move the cursor to a desired language with either CURSOR button.
- 7 Press the OK/SPEICHERN button.
- 8 The screen will change to the corresponding display in the selected language.
- Now follow the on-screen messages for all other on-screen operations.

#### ENGLISH

#### Clock Setting

If you have not yet set the built-in clock, set it on the screen. If the VCR timer is set to a channel broadcasting teletext programmes accompanied by time information, the clock data can be set automatically by reading time information.

- 1 Open the INITIAL menu, and select "1. CLOCK ADJUST."




- 2 Press the ALFZ NR./ANWAHL button.
- 3 The cursor will move to the time data while the time information is being searched.
- It may take some time to complete time setting. This is not due to any defect of the unit.
- The date and year are set automatically.
- All data can also be set manually. For this purpose, use the numeric keys, CURSOR keys, and at the end of adjustment, press the OK/SPEICHERN button.

#### D2-MAC Language Selection

If you have stored some D2-MAC channels, poised to D2-MAC language settings. The HF-SUBDEC is able to use full capabilities of D2-MAC. The language can be selected in the menu up to five. The menu can be specified in order of priority from a total of 31 languages, independently for soundtracks and subtitles.

- 1. Open the LANGUAGE menu from the INITIAL menu.
- 2. To set the soundtrack language priority, press the green button.
- The MAC-LANGUAGES menu will appear.
- 3. Select languages following the on-screen instructions.
- 4. To set the subtitle language priority, press the red key.
- Select languages following the on-screen instructions.



#### Available languages:


| 11 major languages |            |
|--------------------|------------|
| Dutch              | Dutch      |
| English            | English    |
| French             | French     |
| German             | German     |
| Italian            | Italian    |
| Japanese           | Japanese   |
| Portuguese         | Portuguese |
| Romanian           | Romanian   |
| Spanish            | Spanish    |
| Swedish            | Swedish    |
| Other              | (Other)    |

| 20 other languages |            |
|--------------------|------------|
| Irish              | Gaelic     |
| Luxembourg         | Luxembourg |
| Norwegian          | Norwegian  |
| Polish             | Polish     |
| Romanian           | Romanian   |
| Russian            | Russian    |
| Hebrew             | Hebrew     |
| Chinese            | Chinese    |
| Japanese           | Japanese   |
| Cherokee           | Cherokee   |
| Basque             | Basque     |

#### Guide to on-screen messages and operations

Numbers in the BUTTON column: numeric keys

- The languages are divided in two groups. When you select the intended language in one group, select "OTHER LANG.", then another group of languages will be displayed.
- The languages in the second group can also be used for language selection.
- The three menu (ON SCREEN LANG., MAC-LANGUAGES and MAC-SUBTITLE) are accessible among one another by pressing the colour key corresponding to the column colour at the bottom of the screen.



## D2-MAC Function Setting

- To receive D2-MAC broadcasts properly and deliver them to menu.
1. Open the D2-MAC FUNCTIONS menu from the INITIAL menu.
  2. Follow on-screen instructions for operation.

### Guide to operation

- **1. SATELLITE TUNER**  
This setting has no effect if you receive D2-MAC broadcasts via a terrestrial antenna. If you receive D2-MAC broadcasts via a D2-MAC decoder, set to YES in order for the HR-S8000EG's D2-MAC decoder to turn on even in the AUX mode. (To receive D2-MAC broadcasts via the 21-pin SCART connector, set to YES in order for the D2-MAC decoder to turn on even in the AUX mode.)  
D2-MAC decoder is automatically switched off. Setting this item to YES turns it on again. If your satellite tuner incorporates a D2-MAC decoder and V/C separate output function, set to YES in order for the D2-MAC decoder to turn on. If not a V/C separate signal, set this item to "YES" to use the HR-S8000EG's D2-MAC decoder.
- **2. MACROB OUT**  
Indicates an RGB control signal which assigns the connected television in the RGB mode automatically. This setting is provided to prevent the RGB control signal from being output to the television. If it is set to YES, the RGB control signal will not be output to the television. If you wish to view macrob channel while receiving D2-MAC program. Usually set this item to NO to avoid this inconvenience.
- **3. 16:9 FORMAT**  
Indicates whether the television is compatible with wide-aspect ratio. Set to YES if the television is compatible with wide-aspect ratio. If the television is not compatible with wide-aspect ratio, set to NO. If the television is compatible with 4:3 aspect ratio, the images will appear vertically elongated on the screen. If you wish to view macrob channel while receiving D2-MAC program. Usually set this item to YES to avoid this inconvenience.
- **4. AUDIO RECORDING**  
Indicates whether the television is compatible with audio recording. Set to YES if the television is compatible with audio recording. If the television is not compatible with audio recording, set to NO. If you wish to record audio while receiving D2-MAC program. Usually set this item to YES to avoid this inconvenience.
- **5. AUDIO RECORDING**  
Indicates whether the television is compatible with audio recording. Set to YES if the television is compatible with audio recording. If the television is not compatible with audio recording, set to NO. If you wish to record audio while receiving D2-MAC program. Usually set this item to YES to avoid this inconvenience.




## INFORMATION ON THE HR-S8000EG'S AUDIO SYSTEM

### Hi-Fi and Normal Audio

To provide true hi-fi audio accompaniment to video images, the HR-S8000EG's audio system is designed to reproduce VHS tapes, this recorder records hi-fi audio signals (2-channel) into the tape's magnetic coating (with video signals on top of them), and normal audio signals (monaural) onto the tape's normal audio track. This system provides the best selection of audio soundtracks of television programs.

### CAUTION

The hi-fi soundtrack recorded with Hi-Fi VHS dials cannot be reproduced with non-Hi-Fi VHS dials.



Hi-Fi audio recording and reproduction are available only from the hi-fi audio track while the longitudinal audio track provides normal audio.  
The hi-fi and normal soundtracks are recorded separately, and audio dubbing is applicable only to the normal audio.

### Recorded signals by track according to the selected input mode

| Input mode | Track                                                 | Normal audio track (mono)                                                                                                               | Hi-Fi audio track (2-channel)                                              |
|------------|-------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------|
| TUNER      | TV picture (from built-in tuner)                      | TV sound (from built-in tuner)                                                                                                          | TV sound (from built-in tuner)                                             |
| SIMULCAST  | TV picture (from built-in tuner)                      | TV sound (from built-in tuner)                                                                                                          | Audio signal from AUDIO ENG. (from built-in microphone input, if possible) |
| AUX        | Video signal from AV1 EING/AURG, A/V2 EING, or S EING | Audio signal from AV1 EING/AURG, A/V2 EING, or AUDIO ENG. with ENG/MS-MAIL switch set to "S" (mixing with microphone input is possible) | Audio signal from AUDIO ENG. (from built-in microphone input, if possible) |

### Notes:

- To engage the AUX mode, press the "0" key of the 10-digit keypad.
- Microphone input will be mixed with the audio signals on the normal audio track. To receive the audio signals from the microphone, set the MICROPHONE COM selector to the MICROPHONE jack (unless needed).

### Audio Configuration of PAL Broadcasts

PAL offers three types of broadcasts in terms of audio configuration:

1. Monaural
2. Stereo
3. Bilingual (main and sub)

### Recording options according to the type of broadcasts and the setting of the PAL 2-KANAL TON switch

| PAL 2-KANAL TON switch position | Audio Track       |                 | Normal audio track (mono)         |                                   | Hi-Fi audio track (2-channel) |   |
|---------------------------------|-------------------|-----------------|-----------------------------------|-----------------------------------|-------------------------------|---|
|                                 | Type of broadcast | Either position | Monaural                          | Mono                              | L                             | R |
| Repeater (monaural audio)       | Either position   | Monaural        | Monaural                          | Monaural                          |                               |   |
| Stereo broadcast                | Either position   | L + R mixed     | L + R mixed                       | Stereo                            |                               |   |
| Bilingual broadcast             | HAUPT             | HAUPT           | Main soundtrack (local language)  | Main soundtrack (local language)  |                               |   |
|                                 | NEBEN             | NEBEN           | Sub soundtrack (foreign language) | Sub soundtrack (foreign language) |                               |   |

When a stereo programme is received, the STEREO indicator will be lit. If the PAL 2-KANAL TON switch is set to "HAUPT", the stereo soundtrack will be recorded on the normal audio track. If the PAL 2-KANAL TON switch is set to "NEBEN", the stereo soundtrack will be recorded on the sub audio track.

## Possible audio configurations

## Audio Configuration of D2/MAC Broadcasts

D2/MAC offers a variety of audio programming, up to 8 sound channels. One TV programme can include, in addition to its main soundtrack (either stereo or monaural), several additional soundtracks. These additional soundtracks can be programmed independently of the picture programming. Possible configurations are:

1. Monaural
2. Monaural main soundtrack + language versions or independent audio programmes
3. Stereo main soundtrack + language versions or independent audio programmes
4. Stereo main soundtrack + language versions or independent audio programmes

When the D2/MAC programme includes a stereo soundtrack, the STEREO indicator lights. It includes an independent audio programme, the RADITION indicator lights.

For programmes such as 3 and 4, the number of language versions is indicated by the number of lights on the main soundtrack can be specified using the on-screen menu.

## Recording options according to the sound recording mode

| REC SOUND SELECT | 1 language |          |     |     | 2 languages |     |     |      | 3 languages |     |      |      |
|------------------|------------|----------|-----|-----|-------------|-----|-----|------|-------------|-----|------|------|
|                  | Auto track | Language | L   | R   | Norm        | L   | R   | Norm | L           | R   | Norm |      |
| 1                |            |          | Z   | Z   | Z           | Z   | Z   | Z    | Z           | Z   | Z    | Z    |
| 2                |            |          | ZL  | ZR  | ZLZR        | ZL  | ZR  | ZLZR | ZL          | ZR  | ZLZR | ZLZR |
| 3                |            |          | Z/A | Z/A | Z/A         | Z/A | Z/A | Z/A  | Z/A         | Z/A | Z/A  | Z/A  |
| 4                |            |          | Z+B | Z+B | Z+B         | Z+B | Z+B | Z+B  | Z+B         | Z+B | Z+B  | Z+B  |

Note: Designation of additional languages as A, B, and C does not necessarily mean that only three additional languages are broadcast, but indicates languages that are specified in order of priority on the on-screen menu. (See page 87.)

## On-screen sound recording selection and mix level control

1. Open the D2/MAC FUNCTIONS menu from the INITIAL menu. (See page 88.)
2. Select the SOUND SELECT key.
3. Select the language(s) to be recorded. The screen shows "1 LANG." or "2 LANG." or "3 LANG." depending on how you wish to record soundtracks, referring to the chart "Recording option according to the sound recording mode".
4. Select the language(s) to be recorded. The screen shows "1 LANG." or "2 LANG." or "3 LANG." depending on how you wish to record soundtracks, referring to the chart "Recording option according to the sound recording mode".
5. Move the cursor to the right to reduce the main soundtrack level to make additional language louder.

• This adjustment is possible only when the broadcast programme includes all data which permits relative level control.

## Hi-Fi audio recording level adjustment

While recording onto the normal audio track is controlled by the built-in Automatic Level Control circuit, Hi-Fi audio recording has two control options: manual and automatic.

## AUDIO-REGENERATOR switch

The AUDIO-REGENERATOR switch adjusts the built-in audio level for both channels to that the recording level is automatically controlled. For manual adjustment, set this switch to AUS. The recording level for normal and Hi-Fi audio is then automatically regulated at the setting of this switch.)

## PEGELENZEIGER switch and SPURLAGE buttons

The right-channel audio level indicator also functions as a tracking meter during playback. If none or too few audio track or noise bars are visible on the screen, perform manual tracking adjustment by using the SPURLAGE buttons to correct it (see page 78). The SPURLAGE buttons are used to adjust the level of this switch to Hi-Fi SPURLAGE and press the buttons to that the greatest number of elements of the right-channel indicator light. When this switch is set to the right-channel indicator light, regardless of whether during recording or playback.

Note: When playing back a tape with no recording on the Hi-Fi channel, the right-channel indicator light will remain on. The PEGELEZEIGER switch is set to Hi-Fi SPURLAGE.

## Audio level indicators

For manual control of the recording level, first set the relevant switches as follows:

AUDIO-REGENERATOR  $\odot \rightarrow$  AUS

AUDIO MONITOR  $\odot \rightarrow$  IN

Then slide the Hi-Fi AUFN. controls referring to these indicators. When indicators up to or near 0 dB light for the loudest signal being applied, the recording level is correct. When the recording level is too low, the indicator lights from time to time may be most appropriate.


During playback, these indicators show the level of audio signals recorded on the tape.

These indicators also light when the PEGELEZEIGER switch is set to the AUS position.

Note: With the AUDIO MONITOR and AUDIO MIX buttons pressed on either L, R or NORM lights on the FDP, the indicators show the level of audio signals being recorded. Select the L and R indicator when adjusting the recording level.

• The normal audio signal level is also displayed by these indicators, but cannot be adjusted.

ENGLISH




Note: When a microphone is connected to the MICROFON jack, set the AUDIO-REGENERATOR switch to the EIN position to protect against over-level input signals from the microphone.

Hi-Fi AUFN. controls  
Slide these controls, the upper for left channel and the lower for right channel, for manual adjustment of the Hi-Fi audio recording level.

## Dual-audio playback flexibility

Two different types of audio tracks (hi-fi and normal) allow a variety of playback options depending on the connection and the setting of relevant controls and buttons.



### HF AUSGANGS connector


Delivers audio (both hi-fi and normal) and video signals to a TV set. The audio signal is recorded on the tape and is played back through the TV's speaker system. When a video tape is played back through the HF AUSGANGS connector, the audio is reproduced as it was recorded on the tape. The audio signal is also available through the AUDIO MIX button. The AUDIO MIX button is used to select between the audio signal from the tape and the audio signal from the TV's speaker system. The AUDIO MIX button is also used to select between the audio signal from the tape and the audio signal from the TV's speaker system.

### A/V1 ENG/AUSG. connector

Delivers audio (both hi-fi and normal) and video signals to a TV set.

### KOPFHÖRER jack and KOPFHÖRER PEGEL control

Delivers the audio signals from both hi-fi and normal audio tracks. The headphones output level is adjustable with the KOPFHÖRER PEGEL control.



### AUDIO MIX button

Selects between the audio signal from the tape and the audio signal from the TV's speaker system. The AUDIO MIX button is used to select between the audio signal from the tape and the audio signal from the TV's speaker system. The AUDIO MIX button is also used to select between the audio signal from the tape and the audio signal from the TV's speaker system.

### Notes:

- This button functions during recording as well, although it has no effect on the recorded signal.
- When playing back a tape containing the same soundtracks, the AUDIO MIX button has no effect on the audio signal.
- With the AUDIO MIX button pressed for the NORM. and pressing the AUDIO MONITOR button has no effect.

## RECORDING OF D2-MAC PROGRAMMES

If you are not familiar with basic VCR operations, also refer to page 75, "PLAYING BACK A VIDEO CASSETTE", and page 77, "BASIC OPERATION FOR RECORDING TV PROGRAMMES".

### Audio Recording

- Specify the language priority. (See page 67.)
- Specify the sound recording mode. (See page 70.)
- Specified priority can be overridden manually at any time while maintaining the preset priority.

### To override the preset priority and record any other language, press the remote control's SPRACHE button.

- If you are recording and watching the same programme, you can check the soundtracks (languages) that are being recorded by using the AUDIO MONITOR and AUDIO MIX buttons.
- Selective monitoring of the soundtracks during recording does not have any effect on the recorded signal.
- If the HAD-ON indicator lights to show that the programme is being recorded, the HAD-ON indicator will also record it in place of language selection. For this purpose, press the SPRACHE button until the audio programme is selected.

### Subtitle Viewing and Recording

- Some D2-MAC programmes will be accompanied by subtitles. To view and record subtitles, press the remote control's SUBTITLES button. "PLEASE WAIT" will appear on screen until the subtitle is displayed. The subtitle will be recorded in place of language selection. For this purpose, press the SPRACHE button until the audio programme is selected.

### Wide-Angle Programmes

- Some D2-MAC programmes will be transmitted in the wide-angle format. To view and record wide-angle programmes, press the remote control's WIDE-ANGLE button. "PLEASE WAIT" will appear on screen until the wide-angle format is displayed. The wide-angle format will be recorded in place of language selection. For this purpose, press the SPRACHE button until the audio programme is selected.

### Wide-Angle Programmes

- Some D2-MAC programmes will be transmitted in the wide-angle format. To view and record wide-angle programmes, press the remote control's WIDE-ANGLE button. "PLEASE WAIT" will appear on screen until the wide-angle format is displayed. The wide-angle format will be recorded in place of language selection. For this purpose, press the SPRACHE button until the audio programme is selected.

- If your television is not compatible with the wide-angle format, images will be vertically elongated. To avoid this, press the remote control's WIDE-ANGLE button. "PLEASE WAIT" will appear on screen until the wide-angle format is displayed. The wide-angle format will be recorded in place of language selection. For this purpose, press the SPRACHE button until the audio programme is selected.

- However, the images recorded on the tape are vertically elongated.

### Recording One Programme While Watching Another


- Unless your television incorporates a D2-MAC timer/decoder, it is not possible to watch a D2-MAC programme while recording another D2-MAC programme.
- However, if your television is compatible with the D2-MAC PAL programme, the D2-MAC programme being recorded forces the television to engage the RGB mode in which television signals are recorded. This means that the recorded signal will be in RGB mode. To avoid this, press the remote control's RGB button. "PLEASE WAIT" will appear on screen until the RGB mode is displayed. The RGB mode will be recorded in place of language selection. For this purpose, press the SPRACHE button until the audio programme is selected.

- However, the images recorded on the tape are vertically elongated.

## LOADING AND UNLOADING A CASSETTE

### Loading

Insert a cassette as illustrated. Be sure to insert it firmly into the slot; otherwise, it will be automatically ejected.



- The automatic loading mechanism will operate only when the cassette is inserted correctly.
- When either a VHS or S-VHS cassette is inserted, the "cassette loaded" indicator (L) will appear in the PDP. When an S-VHS cassette is inserted, the S-VHS CASS. indicator also lights.

### Unloading

Press the CASSETTE button.

#### CAUTION

- If unloading of the cassette is not possible, check to see whether the TIMER indicator is lit. If so, press the STOP/PAUSE button to turn the TIMER indicator off, then try unloading.
- Do not attempt to pull out the cassette once automatic loading has started.
- Do not insert fingers or any foreign object beyond the cassette slot. This may cause damage to the tape and injury or damage to the mechanism. Show special caution with children.

#### AUTO POWER-ON AND AUTO PLAY SYSTEM

- The cassette can be loaded even when the power has not been turned on. Inserting a cassette into the loader will automatically turn the power on.
- Inserting a cassette, with its safety tab removed, turns the recorder on and playback of the cassette begins automatically.
- The CASSETTE EJECT SYSTEM
- The cassette can be unloaded even after the power has been turned off. Pressing the CASSETTE button turns the power on automatically and, after ejection of the cassette, shuts it off automatically.

## CHILD LOCK FUNCTION


The Child Lock function is for preventing accidental operation by young children, or other unwanted operation, such as playing back or recording on an important cassette you may have intentionally left inserted in the recorder. By engaging the Child Lock mode, the operation buttons on the recorder become inoperative, thus the remote control is useless.

### To engage the Child Lock mode


- Press the remote control's REMOTE VIDEO button.
- The Child Lock mode indicator (L) will appear in the PDP for about 2 seconds after the power LED indicator has gone off.
- The Child Lock indicator (L) will appear in the channel number display for about 2 seconds after the power LED indicator has gone off.
- The Child Lock indicator (L) will appear in the channel number display for about 2 seconds after the power LED indicator has gone off.

#### Notes:


- When the Child Lock mode is engaged, the recorder can receive time programmed data from the remote control.
- Time recording is possible also, even while in the Child Lock mode. After time recording has been performed, the Child Lock mode indicator (L) will disappear in the PDP.
- Even after automatic cassette ejection at tape end, following time recording, the Child Lock mode remains in effect.
- It is possible to insert a cassette while in the Child Lock mode. After inserting a cassette, the Child Lock mode remains in effect.



## PLAYING BACK A VIDEO CASSETTE



**Picture Sharpness Adjustment**  
Images on the screen can be adjusted to a preferred softer or sharper definition by turning the BILD-SCHARFE control (S) in the corresponding direction.



## DIGITAL AV TRACKING SYSTEM

- This system is a digital AV tracking system for automatic tracking and adjustment. In most cases you do not have to adjust tracking.
- When you start playback after inserting a tape, the digital tracking system automatically adjusts the tape path relative to the video head to obtain the best possible picture and Hi-Fi stereo sound.
- If there is no recorded Hi-Fi audio, tracking is set referring only to the video signal. The audio output is entering only to the video signal.
- This automatic adjustment also takes place when the playback output level reduces below a certain level.
- The AUTOMATIC SOURCE TRACKING indicator (S) blinks while the automatic tracking system is tracking, and remains lit as long as the automatic tracking mode continues.

- If automatic tracking fails, and some noise bars are visible on the screen, use the manual tracking mode.
- Immediately after the manual tracking mode is entered, the automatic mode is entered again when the noise bars disappear.
- To return to the automatic mode, press both buttons simultaneously.

## SHUTTLE SEARCH

- Shuttle Search allows high-speed playback at 9 times normal speed in either direction.
- 1. Press either REWIND or F.W. (Fast Forward) button.
- 2. To cancel the Search mode, press WINDER/PAUSE.
- For better searching, keep the Shuttle Search button pressed for more than 2 seconds; when you release the button, the Search mode will be cancelled.

- Turn the TV receiver on and set it as required. (See pages 30 and 61.)

- Load a pre-recorded cassette.

- Press the Shuttle Search button. The tape will start automatically.

- Make the AUDIO MONITOR and AUDIO MIX setting as required. (See page 72.)

- Press the STOP button. The tape will be reloaded automatically when its end is reached and the recorder will enter the Stop mode.

- The SP or LP mode recording is automatically detected and played back at the correct speed.

- The SP or LP mode button setting, the S-VHS mode button setting, and the S-VHS mode indicator light are all in effect.

- The S-VHS mode indicator light is on for playback of S-VHS recordings.

#### Notes:

- The SP or LP mode recording is automatically detected and played back at the correct speed.
- The SP or LP mode button setting, the S-VHS mode button setting, and the S-VHS mode indicator light are all in effect.
- The S-VHS mode indicator light is on for playback of S-VHS recordings.



### RECORDING A TV PROGRAMME WHILE WATCHING ANOTHER

A programme not being viewed can be recorded while you watch another. This is possible with the PAL and D2-MAC systems. The TV set must be set to the correct channel for the programme to be played back later at your convenience. This is explained in the previous page. The points to be remembered are:

- Select the channel you wish to record with the recorder's channel select buttons.
- Press the **RECORD** button when you wish to view with the TV receiver's channel selector.

### RECORDING PAL STEREO TV PROGRAMMES

(Applicable only to the West German Sound-Multiplex TV system)

TV programmes are broadcast in your area, the recorder automatically receives them in stereo. When a stereo programme is being received, the **STEREO** indicator lights and recording is made in stereo on the hi-fi audio track and in mono on the stereo soundtrack. During recording, press the **AUDIO MONITOR** button to watch L and R light. If this button is left pressed for either L or R, you will hear only one channel while recording, though the recording is being made in stereo.

### RECORDING PAL BILINGUAL TV PROGRAMMES

(Applicable only to the West German Sound-Multiplex TV system)

When a bilingual TV programme is being received, the 2-KANAL indicator lights. The hi-fi audio track and the stereo soundtrack to be recorded on the normal audio track, however, because both soundtrack fields are recorded always on the hi-fi track for selective listening, you can ignore the switch labelled PAL 2-KANAL. Turn on the hi-fi audio track when you need a stereo audio track.

- Set: PAL 2-KANAL TON switch to **HAUP** to record the main soundtrack (foreign language), to **HEBEN** to record the sub-soundtrack (foreign language).
- Press the **RECORD** button when you wish to record the hi-fi audio track while recording, press the **AUDIO MONITOR** button for either L or R.
- To listen to the soundtrack being recorded on the normal audio track, press the **AUDIO MIX** button for **MON**.

#### ATTENTION

Regarding D2-MAC programmes:


- The **STEREO** indicator is being received, the hi-fi audio track, the D2-MAC indicator lights. If it indicates a stereo soundtrack, the **STEREO** indicator also lights. If it indicates an independent audio programme, the **STEREO** indicator does not light.
- The recording procedure is identical to that of PAL programmes. For audio selection, see page 70.

**Notes:**

- The D2-MAC system requires a separate channel for the satellite wave, set the recorder to the AUX mode.
- Simultaneous recording is not possible with D2-MAC channels.

The Index Search function gives you automatic access to locations on the tape where index codes are recorded. Index codes are recorded automatically at the beginning of recordings which are started from the Stop or Timer Standby mode, or recorded manually when the **INDEX** button is pressed. The Index Search function can be used to find a specific index code, or to return to the last index code recorded. In either case, there is no effect on the audio or video recordings on the tape. With this recorder, you can access any one of up to 9 of these indexed segments in either the forward or reverse direction.


### Using the Index Search Function



- Press **INDEX** while in the Play or Stop mode.
- The channel display on the FDP will change to the index mode.
- Specify the index number using one of the numeric keys.
- The specified number will appear on the FDP.
- Press either **REVERSE** or **FORWARD** to move the tape to the specified index code.
- The index number will start.
- The INDEX button was pressed in the Play mode, the screen shows search pictures; if the button was pressed in the Stop mode, the screen shows the last frame recorded in the much faster **Reverse** or **Fast-Forward** mode.

**Notes:**

- To cancel the Index Search mode before completion, press **STOP**, **PAUSE**, or **REVERSE**.
- The **INDEX** indicator will blink while still in the Index Search mode, the mode is cancelled and the tape reversed.



### Marking extra index codes

- Press **INDEX** while in the Record or Play mode.
- Extra index codes will be recorded on the tape.
- The **MARKER** indicator will blink, while the index code is being recorded.

### Erasing index codes

- Press **INDEX** while in the Play mode.
- First the Stereo Search mode will be engaged and, when an index code is entered, it will be erased automatically.
- The **MARKER** indicator will blink, while the playback resumes.
- The **LOGIC** indicator remains lit during the searching process and blinks while the code is being erased.

**Notes:**


- Index codes cannot be added or erased on a tape with its Index Search function.
- While the index code is being searched for in the Erase mode, random noise appears on the screen.

## REALTIME TAPE COUNTER FUNCTIONS

Unlike usual tape counters which show tape locations in numbers, this realtime tape counter shows tape time precisely in hours, minutes and seconds in all modes (Record, Play, Rewind, Fast Forward).

### Time Go-to function

The Time Go-To function gives you direct access to any point on the tape by simply specifying the time from the beginning of the tape.


[illegible]

- If the recorder did not detect the leader tape when the cassette was loaded (indicated by "St-m-g" when the Go-to button is pressed), the tape is first reloaded to the beginning of the tape and then is fast-forwarded to the specified point.

### Fima Search function

The Time Search function lets you locate a point on the tape specified time span away from the current position in either

- direction.
- 1 Press ZIELLAUF  $\rightarrow$  while in the Play, Stop or Still mode.
  - 2 Press TV, PR,  $\vee$  or  $\wedge$  to specify the direction of search.
  - 3 Specify the time (from the current position) to the point to be located, by using the numeric keys  $\rightarrow$ .
  - 4 Press  $\rightarrow$  (X2) or  $\rightarrow$  (1).
- The tape will move to the specified point and automatically start playback or stop.



Notes:

Each step in the operation procedure must be followed by the next within 60 seconds, otherwise the Go-To or Search mode will be cancelled.

- If the ZIELLAUF button is pressed while in the Play or Still mode, a still picture can be obtained when the specified point is reached, if you press the (  ) button instead of the  button after keving in the time.

### COUNTER MEMORY FUNCTION/LAP TIME INDICATION


### Counter Memory function

**I** Press ZÄHLWERK-ROCKST. **1** at a point which you may wish to locate later.

- The counter will read "00s 00m 00s".  
Press ZAHLEWERK SPEICHER   will appear on the FDP.  
● Press RÖCKLAUF (or VORLAUF)  (or ) when you need to return to the designated point.  
The tape will rewind (or fast forward) and stop at about the "00s 00m 00s" counter reading automatically.

## Lap Time Indication

When you need to know the exact time of a recording, press the ZÄHLWERK-ROCKST. button before starting recording or playback. The counter will be reset to "00:00m 00s" and show the exact elapsed time as the tape runs.



## REMAINING TAPE TIME INDICATOR

The tape counter is switchable to the remaining tape time indicator.


1. Press **ANZEIGE**  or  to obtain the Remain mode 2 The remaining length will be shown in hours and minutes.

## Notes:

- During recording, the remaining tape length is calculated in reference to the recording mode selected by the SP/LP button; during playback, it is calculated in reference to the recording mode of the tape being played (SP/LP).

## INTRO SEARCH FUNCTION

The Intro Search function lets you visually check the contents of each recording by playing back in fast motion a short segment of a programme each time an index code is detected.



- Press **TITLE/BLD** while in the **Play or Stop** mode.
- The **INDEX** indicator on the **PDF** will light.
- Press the **[▶▶]** or **[◀◀]** button
  - within 2 seconds.
  - The **Info Search** will start in the corresponding direction.
- Each time an **index code** is detected, the corresponding part is played back at the search speed (9 times normal) for about 6 seconds.
- When you find the section you want to view, simply press the **[▶▶]** / **[XZ]** button **⑤**.
- Normal playback will start.




## NEXT-FUNCTION MEMORY

### Memory Play Function

If you want to watch the tape from its beginning after rewinding, press the **ROCKLAUF** button and then **WIEDERGABE** button. The tape will start from the beginning of the tape. (Check to see that the counter memory indicator **[E]** is off.)

If you want to watch the tape from the counter reading of the previous play, press the **ROCKLAUF** button and then **WIEDERGABE** button. The tape will start from the counter reading of the previous play. (Check to see that the counter memory indicator **[E]** is on.)

While the tape is being rewound, the **[E]** indicator (PLAY) is blinking. To cancel the Memory Play mode and go back to the normal mode, press the **STOP**, **WIEDERGABE**, **ROCKLAUF**, **ROCKLAUF**, **ROCKLAUF**, **ROCKLAUF**.



## AUDIO DUBBING

Audio dubbing means recording a new soundtrack on a pre-recorded tape. In other words, the previously recorded sound is erased and replaced with a new soundtrack. Audio dubbing is applicable only to the longitudinal audio tape. (Microcassette and compact cassette narration can be overwritten with the original full track.)

- Switch on the TV receiver and set it as required. (See pages 80 and 81.)
- Load a pre-recorded cassette. Power will be switched on.
- Connect a microphone or an audio source to the **MICROPHONE** jack, **[E]** or the **AV2 EINGANG** socket respectively.
- With both microphone and audio source connected, the audio dubbing will start.
- The **AV2 EINGANG** connectors can also be used for audio dubbing. In this case, let the **EINGANGS-MAHL** switch to "S".

### Notes:

- It is recommended that you use a lower-impedance microphone.
- When using a microphone, turn the TV volume or mute the microphone farther away from the TV. Recording is being performed even if sound is not heard from the TV speaker. If you want to monitor the sound being recorded, connect headphones to the **KOPFHÖRER** jack.
- When a microphone is connected to the **MICROPHONE** jack, set the **AUDIO BEGRENZER** switch to the **EIN** position.

## AUTOMATIC TIMER RECORDING

The built-in 1-year/8-event timer can be programmed in several ways. Use any method depending on your situation.

- Automatic programming:** Program the time channel and the event to be recorded while waiting to the big on-screen colour display.
- Colour co-ordinate programming:** Program the timer channel and the event to be recorded while waiting to the big on-screen colour display.
- Local programming:** Program the timer using the recorder's controls while referring to the recorder's FDP.
- Remote programming:** Program the timer using the recorder's controls while referring to the recorder's FDP.
- Independent remote programming:** Pre-programme the remote controls LCD memory and then transfer the data to the recorder whenever necessary.

### General Precautions On Time Recording

- Make it a rule to load a cassette (with safety lock in place) before starting timer programming.
- When programming, do not forget to engage the recorder in the Time Standby mode by pressing the **SCHALTUHR** button.
- After pressing the **SCHALTUHR** button, be sure to check the FDP for error indication.

### A. Automatic Programming

Since this method takes advantage of teletext broadcasts, use it to record programmes from those broadcasters which provide teletext services.

- Press the **STOP** button to enter the channel broadcasting your desired programme.
- Press numeric key "5" to select page 5 (teletext page) and press the **WIEDERGABE** button. The teletext page will be displayed. Press the yellow of green key.
- If "5, VPT WITH TOP" is not displayed, select "1". The VPT and clock will be displayed. Press the yellow of green key.
- Press the **WIEDERGABE** button. The screen will show one of the teletext pages. (See pages 50 through 53.)
- Press the **CURSOR** "←" button; the cursor will appear.



- Move the cursor to the programme you want to record.
- If you wish to check hidden information, press the **OK/SPEICHER** button.
- Press the **OK/SPEICHER** button.
- The screen will change to the Programme Check mode.



- Check whether all items have been read correctly. Also check the title of the programme.
- Press the **STOP** button to enter the channel broadcasting your desired programme.
- Hidden information, if any, in the title of the programme, cannot be read.
- The channel and date that have been set are the channel and date of the current teletext broadcast. If they do not correspond to your intended settings, correct them with the **WIEDERGABE** button.
- 10-key input.
- To cancel the title only, press the **ROCKLAUF** button. Pressing the same button again cancels all input data.
- When programming, do not forget to engage the recorder in the Time Standby mode with the **SCHALTUHR** button. If all memories are full, the message "PROC. OCCUPIED" will appear.
- When the VPS code of a VPS programme is also automatically read and "VPS" appears in the "VPS" column, if the VPS time differs from the actual schedule, pressing the **WIEDERGABE** button will change the time in the "VPS" column. This is possible only in the Programme Check mode.
- If the read-in data is not correct, correct it manually or repeat automatic programming.
- To repeat automatic programming, go back to the pre-programming step by pressing the **WIEDERGABE** button and repeat steps 4 to 7.
- To correct the data manually, use the **CURSOR** and numeric keys.
- When programming, pay attention to the differences in time. If the VPT clock and the teletext time information are different, a warning "DIFFERENT TIME ZONE" will appear. Correct the time difference.
- With some teletext broadcasting systems, data reading errors may occur.
- If all data is OK, press the **OK/SPEICHER** button.
- Timer programming is completed.




- To continue programming, go back to the previous teletext page by pressing the **SETTE** "←" button and repeat steps 5 to 8.

11. To go back to the menu screen, press the MENU/TEXT button.

**Note:**  
 • If the cursor will not advance to the desired programme on the offset screen, press the CURSOR "←" button for at least two seconds. This will expand the range of programmes that can be selected.


#### B. Colour on screen programming

- Press numeric key "2". The menu screen will change to the ready for entry "VCR JANNAHL" button to advance to the Programme Set mode, and programme number "1" is ready for entry.
- Press programme number.
- After making sure that the cassette is loaded, press the TIMER indicator, and the green programme number illuminated and the power turned off.
- With no cassette loaded, the TIMER and "cassette loader" A. cassette whose safety tab has been removed will be ejected automatically.



#### C. Local Programming


- Press ALFZ NR. ⑤
- The display will change to the Time Set mode for programme number "1". To advance to programme numbers 2 - 8, press ALFZ NR.



- Enter the start time using numeric keys.
  - To key in a one-digit number of hours or minutes, first press "0". Then press the nearest numeric key.
  - When the display changes to the next step, key in the stop time, date and month using numeric keys.
  - Press "VCR" without entering any day of setting.
  - To record a daily repeat starting on a certain day, press "1" and enter the desired day.
  - When not using the VPS recording system, before setting the channel, press KANALNR ⑥ to make "VPS" disappear on the display.
- For programming the timer to record an external source, press the numeric key "0" while the channel display is blanking. "AU" will appear on the display.


#### E. Independent Remote Programming

- The remote control incorporates 4 programme memories (A, B, C and D).
- When transferred to the recorder.



#### F. Press SP/LP

- The LCD will be activated
- When not using the VPS recording system, before setting time, stop time and channel in succession.
- For programming the timer to record an external source, press the numeric key "0" while the channel is blanking. "AU" will appear on the LCD and when transferred in the channel display action.
- After the channel has been entered, the transfer-ready mark will appear and blink.



- When the display changes to the next stage, enter the start time, stop time and channel in succession.
- For programming the timer to record an external source, press the numeric key "0" while the channel is blanking. "AU" will appear on the LCD and when transferred in the channel display action.
- After the channel has been entered, the transfer-ready mark will appear and blink.



- Press SP/LP ③ to obtain the desired recording mode indication on the display.
- When transferred to the recorder.

#### G. Direct the remote control to the recorder's Remote

- Press window ① and press UBERTRAG ②.
- The programmed data will be loaded in one of the recorder's memories (1 - 5), the vacant one of the recorder's memories will be null.
- All programme memories will be null, the recorder's clock will blink and time/date will not be placed.
- Call up the programming to be described by pressing the UBERTRAG button.
- To cancel it, data transfer can now be made by pressing UBERTRAG again.
- Press SCHALTNR ③.
- Check to see if the TIMER indicator and other items on the recorder's VPS repeat correctly. (See page 84)

#### Setting the date, start and stop times, and channel

- It is not possible to set the date, start and stop times unless the timer is in the "ready" state.
- Enter the date when the display is blanking.
- The stop time can be set within 24 hours from the start time.
- Non applicable numbers (such as January 32, February 30 or March 34) or numbers greater than 24 hours (such as 48 or larger for channel) will be rejected when keyed in.

#### Cancelling the preset data

- The preset data can be cancelled. First escape the Time Set mode for the programme number you wish to cancel and then press the LOSCHEN/UBERTRAGEN button ④ or VIDEO LOSCHEN ⑤. Or for the remote control memory, press SPEICHER LOSCHEN ⑥.
- An accepted programme is automatically deleted.

#### Checking the programmed data

- Checking and re-programming can be performed anytime, even when the SCHALTNR button has already been entered.
- While recording is actually taking place according to one preset programme, all other preset programmes can be checked or re-programmed.
- To check the Time Set mode, press the ANZEIGE button ⑦ (①).


#### Timer recording operation

- When recording is finished, recording starts.
- After timer recording, the power is switched off. If the tape and is reached during timer recording, the cassette is automatically ejected and the power is switched off.

#### How to use the cursor keys

- If you press a wrong key and the flashing position has advanced, press ZURÜCK to return to the previous position.
- One of the data has been programmed, you can reach any position for correction using ZURÜCK + VOR. The flashing position is ready for re-entry.
- Pressing ALFZ NR. on the recorder or VIDEO ALFZ NR. on the VCR will advance the flashing position to the next position in which no position flash and data correction is not possible. Pressing SPEICHER ALFZ NR. on the remote control erases the LCD in the transfer-ready mark and the transfer-ready mark disappears. The data, press either cursor key to move to the position which requires correction.

• For programming the timer to record an RM duplicate, press the SMALL button on the remote at any stage while programming. "31V" will appear on the display.




Press SP/LP ③ to obtain the desired recording mode indication on the display.

- When not using the VPS recording system, before setting time, stop time and channel in succession.
- For programming the timer to record an external source, press the numeric key "0" while the channel is blanking. "AU" will appear on the LCD and when transferred in the channel display action.
- After the channel has been entered, the transfer-ready mark will appear and blink.



- When the display changes to the next stage, enter the start time, stop time and channel in succession.
- For programming the timer to record an external source, press the numeric key "0" while the channel is blanking. "AU" will appear on the LCD and when transferred in the channel display action.
- After the channel has been entered, the transfer-ready mark will appear and blink.




- Press SP/LP ③ to obtain the desired recording mode indication on the display.
- When transferred to the recorder.

Following the procedure above, use the remote control's buttons instead of the recorder's with the remote control directed toward the recorder's Remote Sensor window ④.

#### D. Direct Remote Programming

- Following the procedure above, use the remote control's buttons instead of the recorder's with the remote control directed toward the recorder's Remote Sensor window ④.




Press SP/LP ③ to obtain the desired recording mode indication on the display.

- When not using the VPS recording system, before setting time, stop time and channel in succession.
- For programming the timer to record an external source, press the numeric key "0" while the channel is blanking. "AU" will appear on the LCD and when transferred in the channel display action.
- After the channel has been entered, the transfer-ready mark will appear and blink.



- When the display changes to the next stage, enter the start time, stop time and channel in succession.
- For programming the timer to record an external source, press the numeric key "0" while the channel is blanking. "AU" will appear on the LCD and when transferred in the channel display action.
- After the channel has been entered, the transfer-ready mark will appear and blink.



- Press SP/LP ③ to obtain the desired recording mode indication on the display.
- When transferred to the recorder.

Following the procedure above, use the remote control's buttons instead of the recorder's with the remote control directed toward the recorder's Remote Sensor window ④.



**INSERT EDITING**


Insert editing means recording a new scene into a section of pre-recorded tape so that a part of the original recording can be replaced with a new sequence without excessive planning and synchronization at edit-in and edit-out points. Thanks to the flying disc format, clean edits can be obtained. New video and audio signals to be inserted can come either from another video cassette recorder or the built-in tuner.

**CAUTION**

Since video and audio signals are recorded simultaneously, both are replaced with new recordings simultaneously. However, the normal audio soundtrack remains unchanged.

## Connection

or inverting video and audio labels from another video cassette recorder.



1000

- [illegible]

## Notes:

- [illegible]

**TELETEXT VIEWING**

The built-in teletext decoder is compatible with TOP and other teletext systems with automatic system selection. To view teletext pages, first set the tuner to the channel broadcasting your desired teletext programme.

1. Press the **MENU/TEXT** button.
2. Press numeric key "1" to engage the Teletext mode.
  - The Teletext contents page (page 100) will be called up.
  - Then select the page you wish to view using one of the page select methods described in this section.

The following keys are useful while viewing testtext properties of any system.





## Abstract


- TV/teletext mixed pictures are not available in an HCB-compatible AV television is used in the AV mode.
- Some of these buttons have other functions when operating in the Text mode. To use them in the Text mode, first cancel the previously engaged operation mode, or to use them in modes other than Text, first cancel the Text mode.
- Playback of recorded teletext pages may have colour coding or blurring. This is not due to any defect of the unit.

[TOP PAGE ACCESS](#)

The TOP system is a teletext service employed in West Germany. Pages are divided into colour-coded categories (BLOCK) such as "Sports", and sub-categories (GROUP) such as "Football", with all movement between Groups, Blocks, and pages controlled by the colour-coded keys (5).



- |                   |                     |
|-------------------|---------------------|
| ① AUFGABEN/ANWAHL | ⑧ SEITE (-n)        |
| ② LÖSCHEN/RÜCKST. | ⑨ GROSS/NORMAL      |
| ③ Namenic keys    | ⑩ MENÜ/TEXT         |
| ④ DURCHLAUF       | ⑪ Colour-coded keys |
| ⑤ FREIGABE        | ⑫ MISCHEN           |
| ⑥ CURSOR          | ⑬ OK/BEFEHLEN       |
| ⑦ ZEITSTRECKE     | ⑭ HALTEN            |



Yellow (Current field/block) (6/30)


Blue (Block) (6/30)

When a TOP broadcast is received, you will find category and sub-category names (Block and Group) at the bottom of the screen in blue and yellow.



- To move to the next block, press the blue key.
- To move to the next group in the same block, press the yellow key.
- To move to the next page in the same group, press the green key.
- To go back to the previous page in the same group, press the red key.

The TOP system offers a special "PAGE TITLE INDEX" page. To call up this page, press the LOSCHEN/ROCKST. button anytime while in the Teletext mode.



Third Green Yellow Blue

To go to the desired subject, move the cursor to the desired subject by pressing one of the coloured keys (3) and press the yellow key (4) to scan TV audio page (indicated in red).

- Use the green key to scan all titles in succession.
- Use the yellow button to scan "Group" titles (indicated in blue).
- Use the blue button to scan "Block" titles (indicated in red).

Notes:

- To go back to the contents page (page 100) from the page title block page, press the LOSCHEN/ROCKST. button (3).
- To go back to the contents page from any other page, press the LOSCHEN/ROCKST. button twice.
- To go back to the previous page by pressing the AUZFAHR/ANWAHL button (3) for 2 seconds. In this case, the TOP system, press the AUZFAHR/ANWAHL button for longer than 2 seconds.


### OTHER CONVENIENT PAGE ACCESS MODES

Access mode indication on a direct page



Access mode: DIRECT  
group  
TV PL

A. Serial page access mode  
In the Serial Access mode, when one page is specified, the subsequent pages are displayed in succession. To call up the page that precedes or follows these pages can also be called up by pressing the SETZE "v" or "v" button.



1. Press the MENU/TEXT button (8).

2. Press numeric key "1" (9).

3. Press the SETZE "v" button (10). The screen where the access mode and page numbers are displayed.

4. When the Serial Access mode, press the AUZFAHR/ANWAHL button (11) until "SERIAL" is obtained.

5. Enter the number of the page you wish to view with 10-key input (9).


6. The selected page will be searched and called up. The screen where the page number and page title are displayed.

7. If you want to successively view pages that precede or follow these pages, press SETZE "v" or "v" button (10).

8. Instead of DIRECT mode, you can also use the previous or next mode of DIRECT mode by pressing the SETZE "v" or "v" button with the page preceding or following it. This process is repeated each time you press the SETZE button so you can successively view as many pages as you like.

3. Direct page access mode

4. Independent page can be put in memory for instant call up. After specifying the desired page numbers with 10-key input, select the one to be viewed with the DURCHLAUF button.



1. Press the MENU/TEXT button (8).

2. Press numeric key "1" (9).

3. Check the bottom line of the screen where the access mode and page numbers are displayed.

4. When the Direct Access mode, press the AUZFAHR/ANWAHL button (11) until "DIRECT" is obtained.

5. Enter the number of the page you wish to view with 10-key input (9).

6. The selected page will be searched and called up.

7. Move the cursor to the next column and enter the number of the page you wish to view with 10-key input (9).

8. Pages in memory can be called up instantly in succession by pressing the DURCHLAUF button (12).

- C. Group page access mode

For quick access to subjects or frequently referred to pages, the TOP system offers a special "PAGE TITLE INDEX" page. These preset pages are called up by pressing the corresponding numeric key in the Group Access mode. To preset page, referring to the PAGE SET menu:

1. Press the MENU/TEXT button (8).
2. Press numeric key "3" (9).
3. Press the SETZE "v" button (10). The menu screen will change to the PAGE SET mode, and group number "v" is ready for entry.
4. Enter the preset page numbers 100, 200, 300 and 400 for all groups.



3. Press the AUZFAHR/ANWAHL button (11) to advance to the next group number.
4. After the cursor moves to the next page number column with the CURSOR button (12) and the preset page numbers in succession with 10-key input (9).
5. To preset third page, simply press the SETZE "v" button (10) for the second, third and fourth page number column, and the preset page numbers will be stored in the memory of the channel broadcasting these pages (10/10).
6. Repeat the same procedure for other groups.
7. To go back to the menu screen, press the MENU/TEXT button (8).

To preset pages referring to selected pages:

1. This procedure lets you preset page while confining the number of pages to be preset.
1. While in the Teletext mode, select the Direct Access mode with the AUZFAHR/ANWAHL button (11).
2. Enter the numbers of pages you wish to view with 10-key input (9) for the first and second columns at the bottom in 10. Direct page access mode.
3. Then, select the Group Access mode with the AUZFAHR/ANWAHL button.
4. Press and hold for about 2 seconds one of the numeric keys to which you want to attach a preset page.

To call up preset pages, proceed as follows:



1. Select "TV TEXT" on the screen access.
2. To select the Group Access mode, press the **AUFZNR./ANNAHL** button (1) until "GROUP" is obtained.
3. Press the numeric key (2) corresponding to the group number to which the desired page has been allocated.
4. To view the subsequent page, press the **DURCHLAUF** button (3).


**Notes:**

- Selecting subpages (timed pages) see "REGARDING TIMED PAGES".
- Timed pages cannot be preset in the Page Set mode.

#### D. Television channel access mode

You can switch from teletext programmes on one television channel to those on another channel without returning to the menu screen.

1. To view teletext pages on a different channel, press the **AUFZNR./ANNAHL** button (1) until the indication "TV PR." appears in place of the page access mode.
2. Select a different channel with 10-key input (2). The corresponding master page number of the selected channel will appear on the screen. This page will correspond to the page number on which the cursor was last placed.
3. Select the required page access mode by pressing the **AUFZNR./ANNAHL** button (1).
4. If the Direct or Serial Access mode is selected, the page numbers on the screen will function as they are.
5. If the Group Access mode is selected, select a page group preset for the new channel by pressing the corresponding numeric key.




#### REGARDING TIMED PAGES

Pages with content of several subpages (indicated by 1X, 2X, 3X, 4X, 5X, 6X, 7X, 8X, 9X, and 10X) are called timed pages. To stop automatic scrolling of timed pages, press the **HALTEN** button (3). If many subpages are included with one master page, you may want to view only required ones.

By specifying required subpages differs depending on the selected page access mode.

1. Subpage setting in the Group Access mode  
In the Group Access mode, one subpage can be put in memory for each of the four preset master pages. To do this, proceed as follows:  
1. While viewing teletext programmes in the Group Access mode, press the **DURCHLAUF** button (3) until the number on the number of the page which includes the subpage you wish to call up.
2. Press the **ZEITSEITE** button (2).

• "1" will appear in place of "GROUP 1".



#### 3. Enter the subpage number with 10-key input (3).

- The corresponding subpage will be called up.
- Pressing the **SEITE** "←" or "→" button (3) will change the subpage number in single increments in either direction.
- Pressing the **SEITE** "←" or "→" button (3) will change the subpage number in single increments in either direction.
- 4. To move to another master page, use the **DURCHLAUF** button, and repeat steps 2 and 3 to view its subpages.
- 6. After one subpage has been put in memory for each master page, the subpage number of the next master page and the corresponding master page number with the **DURCHLAUF** button.

6. To cancel the Timed Page mode, press the **ZEITSEITE** button (2).
- The previously engaged page access mode will resume.


#### B. Subpage setting in the Serial Access mode

In the Serial Access mode, it is possible to hold 4 serial subpages in memory for each master page.

1. While viewing teletext programmes in the Serial Access mode, press the **DURCHLAUF** button (3) until the master page number with the **DURCHLAUF** button (3).
2. Press **ZEITSEITE** button (2).

• This selected master page number will appear preceded by "1" in the page access mode.

• Example: P200



#### 3. Enter the subpage number with 10-key input (3).


- Pressing the **SEITE** "←" or "→" button (3) will change the subpage number in single increments in either direction.
- The following three subpages will be put in memory.
- 4. To move to another master page, use the **DURCHLAUF** button.
- 5. To cancel the Timed Page mode, press the **ZEITSEITE** button.
- The previously engaged page access mode will resume.

#### C. Subpage setting in the Direct Access mode

In the Direct Access mode, one subpage can be put in memory for each master page.

1. While viewing teletext programmes in the Direct Access mode, press the **DURCHLAUF** button (3) until the number on the number of the page which includes the subpage you wish to call up.
2. Press the **ZEITSEITE** button (2).

• "1" will appear in place of "DIRECT".



#### 3. Enter the subpage number with 10-key input (3).

- The selected subpage will be called up.
- Pressing the **SEITE** "←" or "→" button (3) will change the subpage number in single increments, press the **SEITE** "←" or "→" button.
- 4. To move to another master page, use the **DURCHLAUF** button, and repeat steps 2 and 3 to view its subpages.

#### CLOSED CAPTION (SUBTITLE) BROADCAST TYPING AND RECORDING

Closed caption (subtitles) can be viewed simply by selecting the page sampling options.

1. Engage the Teletext mode and check constants for closed-caption programming.
2. Select the relevant page using any of the page access methods.
3. The captioned programme will appear immediately.
4. If it is not necessary to press the **MISCHEN** button (3) by putting the VCR in the Record mode, this can also be recorded at a request on the screen.

#### Programming for recording of closed-caption (subtitled) broadcasts

Closed-caption (subtitled) broadcasts can also be time-recorded, either by manual programming or automatically programming.

#### Preparation

- First tune the VCR to a channel broadcasting the desired closed-caption programme.
- 1. Press the **MEMORY** button (3).
- 2. The screen will show the page access mode. The page access will change to the Page Set mode. In the page access section you will find the indication "CAP PAGE (TIMER REC)".



3. Press the **AUFZNR./ANNAHL** button (1) until the upper right corner of the screen shows the page number of the "CAP PAGE (TIMER REC)".
4. Using the numeric key (3), enter the page number of a closed-caption programme to be time-recorded.
5. Press the **ENTER** button (3) to obtain the indication "ON".

#### Timer programming

Programme the timer following the instructions in "A. Auto-timer programming", or "B. Colour on-screen programming".

- See page 83 and 84.
- The timer will be started with captions.
- Once "CAP PAGE (TIMER REC)" is set to ON for the respective channel, all preset programmes will be recorded with captions, provided that they are broadcast with caption on the selected page.
- When captions are not recorded.

## IN CASE OF DIFFICULTY

What may initially appear to be trouble is not always a real problem. Make sure first . . . .

### POWER AND TAPE TRANSPORT PROBLEMS

| Symptoms                                                           | Check points                                                                                                                                                  |
|--------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------|
| No power is applied to the recorder.                               | <ul style="list-style-type: none"> <li>Is the power cord disconnected?</li> <li>Connect it.</li> </ul>                                                        |
| Clock is functioning properly, but the recorder cannot be powered. | <ul style="list-style-type: none"> <li>Is the <b>TIMER</b> indicator lit on the FDP?</li> <li>Press <b>SCHLUTZ</b> button again.</li> </ul>                   |
| Tape does not run during recording.                                | <ul style="list-style-type: none"> <li>Is the <b>PAUSE/STANDBY</b> button engaged?</li> <li>Press the <b>WIEDERABSP.</b> button.</li> </ul>                   |
| Time stops in the Rewind or Fast Forward mode.                     | <ul style="list-style-type: none"> <li>Has the <b>ZÄHLWERK/SPEICHER</b> button been pressed?</li> <li>Press it once. No longer appears on the FDP.</li> </ul> |
| Tape will not rewind or fast forward.                              | <ul style="list-style-type: none"> <li>Is the tape correctly reloaded or fast forwarded?</li> <li>Check the cassette.</li> </ul>                              |

### RECORDING PROBLEMS

| Symptoms                                | Check points                                                                                                                                                                                                                                         |
|-----------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Recording cannot be started.            | <ul style="list-style-type: none"> <li>Is a cassette loaded?</li> <li>Is the safety tab on the cassette removed?</li> <li>Insert the side with ejection tape.</li> </ul>                                                                             |
| Camera recording is not possible.       | <ul style="list-style-type: none"> <li>Are the camera and the camera adapter correctly connected?</li> <li>Is the camera correctly connected to the unit?</li> <li>Does the channel display indicate "AUX"?</li> <li>Press <b>WAB.</b></li> </ul>    |
| Simultaneous recording is not possible. | <ul style="list-style-type: none"> <li>Has the <b>SIMUL</b> button been pressed?</li> <li>Press it so "SIM" appears on the FDP.</li> <li>Is the "SIM" correctly connected to the <b>AUDIO ENG.</b> connector?</li> <li>Check connections.</li> </ul> |
| Timer recording is not possible.        | <ul style="list-style-type: none"> <li>Have you set the clock correctly and programmed the time correctly?</li> <li>Is the <b>TIMER</b> indicator lit on the FDP?</li> <li>Press <b>SCHLUTZ</b>.</li> </ul>                                          |

### PLAYBACK PROBLEMS

| Symptoms                                                                  | Check points                                                                                                                              |
|---------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------|
| Playback picture can run appear while the tape is running.                | <ul style="list-style-type: none"> <li>Is the TV receiver set to the correct mode?</li> <li>See pages 89 and 90.</li> </ul>               |
| Noise appears during playback.                                            | <ul style="list-style-type: none"> <li>Press <b>SCHLUTZ</b> button. (See page 76.)</li> </ul>                                             |
| Playback picture is blurred or interrupted while TV broadcasts are clear. | <ul style="list-style-type: none"> <li>Video heads may be dirty.</li> <li>Head cleaning is necessary. Consult your JVC dealer.</li> </ul> |

CONTINUED ON NEXT PAGE . . .

### HI-FI AUDIO PROBLEMS

| Symptoms                                                  | Check points                                                                                                                                                                                                                                               |
|-----------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| TV sound cannot be recorded on hi-fi audio track.         | <ul style="list-style-type: none"> <li>Has the <b>SIMUL</b> button been pressed?</li> <li>Press it again so "SIM" no longer appears on the FDP.</li> </ul>                                                                                                 |
| Breaks are noticeable in hi-fi audio reproduction.        | <ul style="list-style-type: none"> <li>Press the <b>SCHLUTZ</b> button. (See pages 71 and 76.)</li> <li>Have you adjusted the recording level correctly?</li> <li>Over-level recordings could be a cause. Adjust the level correctly next time.</li> </ul> |
| Soundtrack on the hi-fi audio track cannot be reproduced. | <ul style="list-style-type: none"> <li>Is the <b>MONITOR</b> indicator on the FDP lit?</li> <li>Press the <b>WIEDERABSP.</b> button for L and R to light as required.</li> </ul>                                                                           |
| Audio level indicators do not function.                   | <ul style="list-style-type: none"> <li>Press the <b>AUDIO MIX</b> button for L and R to light as required.</li> <li>Is the <b>PERFECT/STRETCH</b> switch set to a position other than <b>EINT</b>?</li> <li>Set it to <b>EIN</b>.</li> </ul>               |

### OTHERS

| Symptoms                                                            | Check points                                                                                                                                                                                                                             |
|---------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Whistling or howling is heard from TV.                              | <ul style="list-style-type: none"> <li>Move camera or microphone away from TV or reduce TV sound volume.</li> </ul>                                                                                                                      |
| Some channels are skipped over often during a channel.              | <ul style="list-style-type: none"> <li>Those channels are preset to be skipped over. If you need them, restore them. (See page 80.)</li> </ul>                                                                                           |
| Channel cannot be switched.                                         | <ul style="list-style-type: none"> <li>Is the TV receiver set to the correct mode?</li> <li>Press <b>WIEDERABSP.</b>, select a desired channel and press <b>WIEDERABSP.</b></li> </ul>                                                   |
| The recorder cannot be operated with the remote control.            | <ul style="list-style-type: none"> <li>Is the <b>AB-CODE</b> indicator showing the proper code for the recorder being operated?</li> <li>Press the <b>AB-CODE</b> button to switch the remote control to the correct setting.</li> </ul> |
| The recorded videotext and subtitle channels are lost and unusable. | <ul style="list-style-type: none"> <li>This is normal.</li> </ul>                                                                                                                                                                        |

The recorder contains microcomputers. External electronic noise or interference could cause malfunctioning. In such case, switch the power off, wait a few minutes, then plug it in again and switch on. Take out the cassette. After checking the cassette, operate the unit as usual.

## HEAD CLEANING

- Picture playback may become blurred or interrupted while the TV programme received is clear. This does not mean that the recorded programme has been erased.
- Head cleaning is necessary. Head cleaning is required during periods of use causes such problems. In this case, head cleaning requiring highly technical care is necessary.



## SECTION 1

### DISASSEMBLY AND MECHANISM ADJUSTMENTS

#### 1.1 DISASSEMBLY

##### 1.1.1 External covers

##### 1. TOP cover

- 1) Take out four screws (A) from the side panel (L) and side panel (R) and remove them.
- 2) Take out one screw (B) and tilt up the rear end of the top cover in direction (1), then remove the top cover.

##### 2. Front panel

- 1) Remove the top cover.
- 2) Take out two screws (E) from the bottom of the set then remove two feet.
- 3) Carefully bend three hooks (C) of the front panel assembly from the upper side of the chassis in order to disengage the hooks from the chassis.
- 4) Pull the front panel assembly toward direction (2) to disengage three hooks (D) of the front panel assembly from the bottom of the chassis, then remove the front panel assembly.

##### 3. Bottom cover

- 1) Remove the top cover.
  - 2) Take out ten screws (F) from the bottom of the set, then remove the shield plate (R), (L) and bottom cover.
- ##### 4. Cassette housing assembly
- 1) Remove the front panel assembly.
  - 2) Take out two screws (G) and one screw (L) from the video board assembly.
  - 3) Take out two screws (H) from the mechanism base.
  - 4) Pull the cassette housing assembly toward front to disengage the two claws (J).
  - 5) Carefully tilt up the cassette housing assembly in direction (3) and disconnect connector (K), then remove the cassette housing assembly.




Fig. 1-1-1



### 1.1.2 Circuit boards (See Fig. 1-1-2)

#### 1. Video and Terminal board assemblies.

- 1) Take out three screws (L) and one screw (M), then raise the video and Terminal board assemblies to remove them.

#### 2. Tuner CTL and IF board assemblies

- 1) Take out two screws (N) and remove the Tuner CTL and IF board assemblies.

#### 3. Flying Erase board assembly

- 1) Take out one screw (P) and remove the shield plate assembly (1).

- 2) Raise the Flying Erase board assembly to remove it.

#### 4. Mechacon, AV IN/OUT and Servo board assemblies.

- 1) Take out three screws (Q), then remove the Mechacon, AV IN/OUT and Servo board assemblies.

**Note:** Servo and AV IN/OUT board assemblies are connected to the Mechacon board assembly.

#### 5. Servo Sub board assembly

- 1) Take out one screw (R) and remove the bracket.
- 2) Raise the Servo Sub board assembly to remove it.

#### 6. Audio board assembly

- 1) Take out two screws (S) and remove the Audio board assembly and shield plate assembly (2).

#### 7. Timer board assembly

- 1) Take out two screws (T) and remove the Timer board assembly.

#### 8. Switching Power Supply and Regulator board assemblies.

- 1) Take out three screws (U) and remove the Switching Power Supply and Regulator board assemblies.

#### 9. Demodulator board assembly

- 1) Take out two screws (W) and remove the Demodulator board assembly.

#### 10. Auto Tracking board assembly

- 1) Pull the Auto Tracking board assembly toward front to remove it.

#### 11. DECODER/VPT

- 1) Take out seven screws (V) and remove the DECODER /VPT board assembly.




Fig. 1-1-2

### 1.1.3 Disconnecting the flat wire

In addition to the normally employed cap housing, in some applications, special types are used for such purposes as flat wire connection. This type is mainly used on the deck terminal board.

Among the special type housings are the PU58798 and PU59833 series. These clamp the ends of the cable wires. See Fig. 1-1-3, -4 for methods of connecting and disconnecting the cables.

#### 1. PU58798 series

Pull the connector structure upward to release the clamp when removing or inserting the flat wire cable.




Fig. 1-1-3

#### 2. PU59833 series

With this type, release the clamp by pressing downward with the end of a flat blade screwdriver, as indicated below.




Fig. 1-1-4

**Note:** Wire removal method is the same for sets using the new lock type housing in the future. Either press or pull the housing to remove.

## 1.2 MECHANISM ADJUSTMENT

### 1.2.1 Precautions

1. Disconnect mainframe from AC power before soldering.
2. Avoid imparting stress to wires when disengaging connectors.
3. Determine and correct the cause of difficulty before proceeding to adjustments. Do not disturb settings unnecessarily.
4. Use care not to damage tabs, claws, etc. during repairs.
5. Install the cassette housing assembly only when the mechanism is in the Eject or Stop mode position. In the Eject mode, the internal holder of the housing is fully raised. This is fully lowered in the Stop mode.

### 1.2.2 Check without cassette housing

Mechanism operations can be observed easily by removing the cassette housing assembly. Note the following.

1. Disable the photo transistor sensor (END SENSOR) on the main-deck by applying an opaque cover.
2. Connect pins 1 and 4 of MECHACON board connector CN2.
3. Connect VCR to AC power.
4. The loading arms move. The Stop mode is produced at loading end and power is cut off.
5. Again press the power button.
6. Select the desired modes with the operation buttons. However, notice that without tape, setting for the reverse direction modes produces the Stop mode after a few seconds due to absence of the reel sensor output.

### 1.2.3 Manually removing cassette tape

In event of electrical system failure that prevents the tape from being unloaded, the tape can be removed manually by the following procedure. Refer to Figs. 1-3-1, 1-3-2 and 1-3-3.

1. Disconnect VCR from AC outlet.
2. Turn the mode motor pulley (from the bottom of the deck) by hand toward the drum motor assy.
3. Turn the mode motor pulley so that the control cam rotates clockwise. This retracts the pole base assembly to the unloading position.
4. Turn the take-up reel disk (from the bottom of the deck) to absorb slack tape within the cassette.
5. Again turn the mode motor in the same direction to stop rotation of control cam.
6. Turn the cassette motor counterclockwise to raise the cassette and remove it.

### 1.2.4 Test equipment

The following special tools and fixtures are required for mechanism adjustment.

1. Alignment tapes : MH-2 and MH-2L  
Stairstep signal is employed for interchangeability checks and adjustments.
2. Torque gauge : PUJ48075-2  
Measures tape take-up torque.
3. Back tension cassette gauge : PUJ48076-2  
Measures tape tension at the supply side.
4. A/C head positioning tool : PUJ47351-2  
Shifts the head base for adjusting the control head position.




Fig. 1-2-1 Test equipment

### 1.3 MAIN MECHANISM PARTS




Fig. 1-3-1 Top view of main-deck




Fig. 1-3-2 Bottom view of main-deck




Fig. 1-3-3 Cassette housing

#### A. Cleaning

Periodic cleaning of the tape transport system is desirable, but ordinarily not feasible in practice. Therefore, perform cleaning when a set is brought in for repairs or maintenance. Heavy contamination of the video heads, tape guides and brushes can detract from playback picture quality and in extreme cases, even damage the tape. For cleaning, use a fine-mesh cotton cloth (about the texture of a white dress-shirt) moistened in alcohol.

- To clean the video heads, press the moistened cloth gently against the upper drum with fingertip and turn the drum by hand.  
Do not use a vertical stroke, as this may damage the heads.

#### B. Lubrication

Oil and grease do not require periodic replenishing. Apply only when replacing lubricated parts (also clean and replace lubrication of mating parts if soiled).

- Table 1-3-1 indicates the oil and grease used in this set. Use these or recommended locally available equivalents.

| Category | Part Name            | Part number  |
|----------|----------------------|--------------|
| Oil      | Video Oil            | COSMO-HV56   |
| Grease   | Video Grease (Black) | MOS2-C       |
|          | " (Ivory)            | DAPHNE-XLA-2 |

Table 1-3-1

- Grease is not required for a replacement cassette housing assembly, as this has been applied at the factory.

**Note:** Stir grease that has been stored for an extended period.

#### C. Main mechanical parts

See Fig. 1-3-1, 1-3-2 and 1-3-3.

| No. | Parts No./Symbol No. | Parts Name             |
|-----|----------------------|------------------------|
| 1   | PDM2119A/(M3-2A)     | Upper drum assy        |
| 2   | PQ43298A/(M4-110)    | Roller assy            |
| 3   | PV60646/(M4-5)       | Full erase head        |
| 4   | PQ41955/(M4-9)       | Impedance roller       |
| 5   | PN268R-NC/(54-Q1)    | End sensor             |
| 6   | PU60556-1-2/(M4-23)  | Supply pole base assy  |
| 7   | PQ43710A/(M4-1)      | Tension arm assy       |
| 8   | PQ41948A/(M4-3)      | Tension band           |
| 9   | PU59250-1-2/(M4-42)  | Supply reel disk       |
| 10  | PU58644-1-3/(53-S1)  | Rac safety swtch       |
| 11  | PDM4015B/(M3-2D)     | Brush                  |
| 12  | PDM2113C/(M3-2C)     | Lower drum assy        |
| 13  | PU60557-1-4/(M4-22)  | Take-up pole base assy |
| 14  | PU53629-3/(M4-25)    | Tape guide             |
| 15  | —                    | —                      |
| 16  | PU60560-2/(M4-15)    | Audio/control head     |
| 17  | PQ42006B/(M4-68)     | Pinch roller arm assy  |
| 18  | PU60201V/(M4-29)     | Capstan motor          |
| 19  | PQ42013B-4/(M4-72)   | Guide arm assy         |
| 20  | PU59925-1-1/(M4-82)  | LED holder             |
| 21  | PU58638-1-2/(M4-43)  | Take-up reel disk      |
| 22  | PU58645-1-4/(M4-32)  | Idler arm              |
| 23  | PU59926V/(M4-39)     | Reel motor             |
| 24  | PQ41996B/(M4-51)     | Mode motor assy        |
| 25  | PQM30003-20/(M4-58)  | Mode motor belt        |
| 26  | PQ42979A-2/(M4-89)   | Half loading arm assy  |
| 27  | PU60444/(M4-86)      | Slide encoder          |
| 28  | PU58879/(56-PHS1)    | Cassette sensor        |
| 29  | PN268R-NC/(56-Q1)    | Start sensor           |
| 30  | PQ42385A/(M3-7A)     | Cassette motor assy    |
| 31  | PQM30003-19/(M3-7C)  | Cassette motor belt    |
| 32  | PUS2827H/(M3-7)      | Cassette housing assy  |

#### • Symbol interpretation example




Table 1-3-2

## 1.4 INSPECTION AND MAINTENANCE

This product employs rotary and moving parts which wear out in the course of usage. Periodic inspection, cleaning, lubrication and maintenance are therefore important for ensuring maximum performance. Worn parts must also be replaced at regular intervals.

### 1.4.1 Suggested servicing schedule for main components

The following table indicates the suggested period for such service measures as cleaning, lubrication and replacement. In practice, the indicated periods will vary widely according to environmental and usage conditions. However, the indicated components should be inspected when a set is brought for service and the maintenance work performed if necessary.

Also note that rubber parts may deform in time, even if the set is not used.

| System         | Parts Name         | Symbol No. | Periodic servicing schedule (operation hours) |     |     |      |      |      |      |      |      |
|----------------|--------------------|------------|-----------------------------------------------|-----|-----|------|------|------|------|------|------|
|                |                    |            | 250                                           | 500 | 750 | 1000 | 1250 | 1500 | 1750 | 2000 | 3000 |
| Tape Transport | Upper drum         | M3-2A      | ★                                             | ★   | ☆   | ●    | ★    | ★    | ☆    | ●    | ●    |
|                | Audio/control head | M4-15      | ★                                             | ★   | ★   | ★    | ★    | ★    | ★    | ☆    | ●    |
|                | Pinch roller       | M4-68      | ★                                             | ★   | ★   | ★    | ★    | ★    | ★    | ★    | ●    |
|                | Full erase head    | M4-5       | ★                                             | ★   | ★   | ★    | ★    | ★    | ★    | ★    | ●    |
|                | Tension arm        | M4-1       |                                               |     |     |      |      |      |      |      |      |
|                | Lower drum         | M3-2C      |                                               |     |     |      |      |      |      |      |      |
|                | Capstan (shaft)    | M4-29      |                                               |     |     |      |      |      |      |      |      |
|                | Half loading arm   | M4-89      |                                               |     |     |      |      |      |      |      |      |
|                | Guide arm          | M4-72      |                                               |     |     |      |      |      |      |      |      |
|                | Tape guide         | M4-25      | ★                                             | ★   | ★   | ★    | ★    | ★    | ★    | ★    | ★    |
|                | Supply slant pole  | M4-23      |                                               |     |     |      |      |      |      |      |      |
|                | Take-up slant pole | M4-22      |                                               |     |     |      |      |      |      |      |      |
|                | Impedance roller   | M4-9       |                                               |     |     |      |      |      |      |      |      |
|                | Roller assy        | M4-110     |                                               |     |     |      |      |      |      |      |      |
| Drive          | Capstan motor      | M4-29      |                                               |     |     |      |      |      |      | ●    |      |
|                | Reel motor         | M4-39      |                                               |     |     |      |      |      |      | ●    |      |
|                | Cassette motor     | M3-7A      |                                               |     |     |      |      |      |      |      | ●    |
|                | Mode motor         | M4-51      |                                               |     |     |      |      |      |      |      | ●    |
|                | Supply reel disk   | M4-42      |                                               |     |     | △    |      |      |      | △    | ●    |
|                | Take-up reel disk  | M4-43      |                                               |     |     | △    |      |      |      | △    | ●    |
|                | Idler arm          | M4-32      |                                               |     |     | ○    |      |      |      | ●    |      |
|                | Cassette belt      | M3-7C      |                                               |     |     | ○    |      |      |      | ●    |      |
|                | Mode motor belt    | M4-58      |                                               |     |     | ○    |      |      |      | ●    |      |
| Others         | Brush              | M3-2D      |                                               |     |     | ○    |      |      |      | ○    | ○    |
|                | Tension band       | M4-3       |                                               |     |     | ○    |      |      |      | ○    | ○    |

★ : Cleaning

☆ : Cleaning (or Replacement if necessary)

△ : Lubrication

No: Refer to Main mechanical parts

▲ : Lubrication (or Replacement if necessary)

● : Replacement


○ : Inspection (or Replacement if necessary)



Table 1-3-3 Approximate maintenance schedule

## 1.5 MAIN ASSEMBLY REPLACEMENT

| No. | Item                                   | Adjustment parts | Operating mode | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
|-----|----------------------------------------|------------------|----------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1   | Upper drum assembly<br><br>— Removal — |                  |                | <p><b>Note:</b> When installing the new upper drum, use care not to touch the video heads. If heads are soiled, clean with a soft, finely woven cotton cloth or chamois that has been moistened in alcohol. Hold lightly against the heads and turn the drum clockwise. By no means clean with a vertical stroke.</p> <ol style="list-style-type: none"> <li>1) Refer to Fig. 1-5-1. Take out screw (1) and remove the brush assembly.</li> <li>2) Use a desoldering tool or desoldering braid to unsolder the upper drum boards.</li> <li>3) Take out two screws (2) and raise the upper drum to remove it together with the upper drum board. (If this drum is to be re-installed, use care not to touch or damage the heads.)</li> </ol> |
|     | — Installation —                       |                  |                | <ol style="list-style-type: none"> <li>1) Refer to Fig. 1-5-1. Align the black relay pin of the new upper drum with the white marking of the lower drum.</li> <li>2) Reinsert screws (2) and tighten them in a balanced manner.</li> <li>3) Reinstall and solder the upper drum boards.</li> <li>4) Clean the drum assemblies (see above note).</li> <li>5) Reinstall the brush assembly and secure with screw (1).</li> </ol>                                                                                                                                                                                                                                                                                                              |
|     | — Checks and adjustments —             |                  |                | <p>After installing the upper drum, perform the following checks and adjustments (refer to appropriate Sections of this Manual).</p> <ol style="list-style-type: none"> <li>1) FM waveform</li> <li>2) Servo circuit</li> <li>3) Video circuit</li> <li>4) FM audio circuit</li> </ol>                                                                                                                                                                                                                                                                                                                                                                                                                                                      |




Fig. 1-5-1 Upper drum assembly




| No. | Item                                             | Adjustment parts                                                                                                                   | Operating mode | Description                                                                                                                                                                                                                                                                                                                                                                                      |
|-----|--------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------|----------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 2   | A/C head (Audio/Control head)<br><br>— Removal — |  <p>(To main-deck)</p> <p>Fig. 1-5-2 A/C head</p> |                | <ol style="list-style-type: none"> <li>1) Disengage connectors attached to the A/C head board.</li> <li>2) Take out two screws (1) and remove the A/C head together with the head base.</li> <li>3) Unsolder and remove the A/C head board from the A/C head.</li> <li>4) Take out three screws (3) and remove the A/C head from the head base. Use care regarding the three springs.</li> </ol> |
|     | — Installation —                                 |  <p>Fig. 1-5-3 A/C head height</p>               |                | <ol style="list-style-type: none"> <li>1) Install the A/C head by reversing the removal steps of above.</li> <li>2) Temporarily set the A/C head height above the head base for 6.6 mm (see Fig. 1-5-3).</li> </ol>                                                                                                                                                                              |
|     | — Checks and adjustments —                       |                                                                                                                                    |                | <ol style="list-style-type: none"> <li>1) Use a spare tape (not Alignment tape) and confirm proper operation of the tape transport (see Section 1.8).</li> <li>2) Perform interchangeability adjustment (see Section 1.9).</li> </ol>                                                                                                                                                            |








| No. | Item                                                                                                                     | Adjustment parts | Operating mode | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
|-----|--------------------------------------------------------------------------------------------------------------------------|------------------|----------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 2   | Control cam                                                                                                              |                  |                | <p>1) Install the half loading cam on the cam bracket assembly, then mount the slide cam plate assembly so that its stud sets into the groove on the half loading cam.</p> <p>2) Install the arm gear assembly on the cam bracket assembly.</p> <p>3) Assemble the second gear and the control cam so that the stud of the control cam sets into the hole of the second gear.</p> <p>4) Mount the above assembly (control cam and second gear) on the cam bracket assembly to satisfy the relation indicated in figure.</p> <p>5) Do not turn the control cam from this position for the next step.</p> |
|     |  <p>Fig. 1-6-3 Control cam</p>          |                  |                |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| 3   | Cam bracket assembly                                                                                                     |                  |                | <p>1) Refer to Fig. 1-6-4 and press the plate assembly toward the right to overlap the indicated hole with that of the main deck.</p> <p>2) Then install the cam bracket assembly.</p> <p><i>Note: If the arm and loading gears do not mesh properly, use a jeweler's screwdriver or similar tool to engage the gear teeth while installing the cam bracket assembly.</i></p>                                                                                                                                                                                                                           |
|     |  <p>Fig. 1-6-4 Cam bracket assembly</p> |                  |                |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| 4   | Mode switch position                                                                                                     |                  |                | <p>1) Engage the plate assembly and mode switch as shown in Fig. 1-6-5. Partially tighten screw (1) to where the switch can still be shifted for adjusting the position.</p> <p>2) Press the plate assembly toward the right to where the holes are overlapped as in Fig. 1-6-4. Insert a jeweler's screwdriver into the holes to keep them aligned.</p> <p>3) Shift the mode switch to align the V-notch as indicated in Fig. 1-6-5. Then tighten screw (1) to secure.</p> <p>4) Remove the jeweler's screwdriver, then reinstall and solder the circuit board.</p>                                    |
|     |  <p>Fig. 1-6-5 Mode switch</p>        |                  |                |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |

## 1.7 CONFIRMATION AND ADJUSTMENT

| No. | Item                  | Adjustment parts                                                                                                         | Operating mode | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
|-----|-----------------------|--------------------------------------------------------------------------------------------------------------------------|----------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1   | Tension pole position |  <p>Fig. 1-7-1 Tension pole position</p> |                | <ol style="list-style-type: none"> <li>1) Without a cassette tape, set for the Play mode (see Section 1.2).</li> <li>2) Refer to Fig. 1-7-1. Slightly loosen screw (1). Adjust the tension band holder position for 0 mm separation between A and B.</li> <li>3) Tighten screw (1) to secure the tension band holder.</li> <li>4) Use the back tension cassette gauge and set for the Play mode.</li> <li>5) Check for a scale reading between 25 and 45.</li> <li>6) If outside this range, clean the tension band contacting portions of the supply reel disk with alcohol, or check the condition of the tension arm spring. If necessary, replace the tension band assembly.</li> </ol> |
| 2   | Take-up torque        |                                                                                                                          |                | <ol style="list-style-type: none"> <li>1) Without a cassette tape, set for the Play mode (see Section 1.2).</li> <li>2) Set the torque gauge on the take-up reel disk.</li> <li>3) Grasp the torque gauge lightly so that it rotates and read the value when the scale matches the indicator needle. Confirm a value between 45 and 155.</li> <li>4) If outside this range, clean the rubber portion of the idler arm with alcohol, or if necessary, check the reel motor drive circuit.</li> </ol>                                                                                                                                                                                         |

## 1.8 TAPE TRANSPORT CHECKS AND ADJUSTMENT PREPARATIONS

| No. | Item                                                                                                                                                                                                                                                                                                                                                   | Adjustment parts                                                                                                                                  | Operating mode | Description                                                                                                                                                                                                                                                                                                                                                                                                                                      |
|-----|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------|----------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|     | <p>The tape transport system has been precision-adjusted at the factory and ordinarily does not require readjustment. However, adjustment may become necessary after long term usage or after replacing parts that affect the tape transport. The following steps mainly cover preparations for the interchangeability adjustments of Section 1.9.</p> |                                                                                                                                                   |                |                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| 1   | Guide roller                                                                                                                                                                                                                                                                                                                                           | <p>Turn with screw-driver.</p>  <p>Fig. 1-8-1 Guide roller</p>   |                | <p>1) During interchangeability adjustments, the guide roller is turned with a flat-blade screwdriver to adjust its height and correct FM waveform linearity. Use a metric hex key (1.25 mm) to slightly loosen the setscrew at the base of the guide roller (see Fig. 1-8-1). Loosen the setscrew just sufficiently to allow the guide roller to be turned. If too loose, tape transport will be too unstable to permit correct adjustment.</p> |
| 2   | Impedance roller                                                                                                                                                                                                                                                                                                                                       | <p>Turn with nut-driver.</p>  <p>Fig. 1-8-2 Impedance roller</p> |                | <p>1) This compensates for tape running stability between the cassette and head drum. After adjusting the supply guide roller, the impedance roller height is adjusted for smooth tape transport at the lower flange.</p> <p>2) Use a metric nutdriver (5.5 mm) to adjust by turning the upper nut (see Fig. 1-8-2). However, note that excess turning can disturb the FM waveform stability.</p>                                                |
| 3   | A/C head (audio/control head)                                                                                                                                                                                                                                                                                                                          | <p>Audio/control head</p>  <p>Fig. 1-8-3 A/C head</p>          |                | <p>1) After adjusting the take-up guide roller, adjust the A/C head inclination for smooth tape travel at the lower flange of the take-up guide pole. Refer to Fig. 1-8-3.</p>                                                                                                                                                                                                                                                                   |

## 1.9 INTERCHANGEABILITY CHECKS AND ADJUSTMENTS

| No. | Item                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           | Adjustment parts | Operating mode | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
|-----|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------|----------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|     | <p>Before using costly Alignment tape, use a spare tape and confirm correct operation of the tape transport.</p> <p>If this adjustment is performed, after turning off the indicator by pressing the + and - tracking buttons simultaneously, perform interchangeability adjustment.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |                  |                |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
| 1   | FM waveform                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |                  |                | <p>1) Connect oscilloscope to the FM OUT testpoint of the video playback circuit. Trigger the oscilloscope externally with the signal from the drum flipflop (D-FF or FF) testpoint. Set the trigger slope to minus (-).</p> <p>2) Play the MH-2 Alignment tape and adjust the tracking for maximum FM waveform output. Refer to Fig. 1-9-1. Confirm the relationships indicated in the figure for maximum output (a), minimum center output (b), minimum output at the drum intake (c) and minimum output at the drum output (d).</p> <p>3) Adjustment is required if the above specifications are not fulfilled. Even when these are fulfilled, check that the FM waveform varies linearly overall. If not, slight deviation in tracking will cause a large proportional level drop to result in noise appearing in the picture. Therefore, in this condition, proceed to the following checks and perform adjustments where necessary.</p> <p>4) Operate the tracking adjustment between minimum and maximum outputs of the FM waveform. Observe the portion of the waveform corresponding to the drum intake (see Fig. 1-9-2). As the tracking is adjusted, although the gain may increase or decrease, the geometric shape of this part of the waveform should remain consistent.</p> <p>If the shape varies, as shown by the incorrect examples in the figure, carefully perform adjustment of the supply guide roller height.</p> <p>5) Next observe the portion of the waveform corresponding to the drum output (see Fig. 1-9-3), while operating the tracking adjustment. This should also vary only in gain, but not in shape.</p> <p>If the shape varies, as shown by the incorrect examples in the figure, carefully perform adjustment of the take-up guide roller height.</p> <p>6) Check the overall FM waveform. Fine-adjust both guide rollers so that variation is as minimum and linear as possible.</p> <p>7) Observe the tape travel at the guide rollers and guide poles. Confirm absence of tape creasing or curling. Confirm that the tape properly rides at the lower flange of the supply guide pole. Carefully adjust the guide pole height if necessary. This adjustment is important and affects FM waveform response.</p> <p>If creasing or curling is observed at the take-up guide pole, carefully adjust the audio/control head inclination so that the tape rides properly at the lower flange of the guide pole. Finally, again check the FM waveform.</p> |
|     | <p>Before using costly Alignment tape, use a spare tape and confirm correct operation of the tape transport.</p> <p>If this adjustment is performed, after turning off the indicator by pressing the + and - tracking buttons simultaneously, perform interchangeability adjustment.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |                  |                |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
|     | <p>1) Connect oscilloscope to the FM OUT testpoint of the video playback circuit. Trigger the oscilloscope externally with the signal from the drum flipflop (D-FF or FF) testpoint. Set the trigger slope to minus (-).</p> <p>2) Play the MH-2 Alignment tape and adjust the tracking for maximum FM waveform output. Refer to Fig. 1-9-1. Confirm the relationships indicated in the figure for maximum output (a), minimum center output (b), minimum output at the drum intake (c) and minimum output at the drum output (d).</p> <p>3) Adjustment is required if the above specifications are not fulfilled. Even when these are fulfilled, check that the FM waveform varies linearly overall. If not, slight deviation in tracking will cause a large proportional level drop to result in noise appearing in the picture. Therefore, in this condition, proceed to the following checks and perform adjustments where necessary.</p> <p>4) Operate the tracking adjustment between minimum and maximum outputs of the FM waveform. Observe the portion of the waveform corresponding to the drum intake (see Fig. 1-9-2). As the tracking is adjusted, although the gain may increase or decrease, the geometric shape of this part of the waveform should remain consistent.</p> <p>If the shape varies, as shown by the incorrect examples in the figure, carefully perform adjustment of the supply guide roller height.</p> <p>5) Next observe the portion of the waveform corresponding to the drum output (see Fig. 1-9-3), while operating the tracking adjustment. This should also vary only in gain, but not in shape.</p> <p>If the shape varies, as shown by the incorrect examples in the figure, carefully perform adjustment of the take-up guide roller height.</p> <p>6) Check the overall FM waveform. Fine-adjust both guide rollers so that variation is as minimum and linear as possible.</p> <p>7) Observe the tape travel at the guide rollers and guide poles. Confirm absence of tape creasing or curling. Confirm that the tape properly rides at the lower flange of the supply guide pole. Carefully adjust the guide pole height if necessary. This adjustment is important and affects FM waveform response.</p> <p>If creasing or curling is observed at the take-up guide pole, carefully adjust the audio/control head inclination so that the tape rides properly at the lower flange of the guide pole. Finally, again check the FM waveform.</p> |                  |                |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |

b IV 0.7, c IV 0.5 and d IV 0.5




Fig. 1-9-1 FM envelope




Fig. 1-9-2 Drum entrance






Fig. 1-9-3 Drum exit

| No. | Item                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       | Adjustment parts                                                                                                        | Operating mode | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
|-----|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------|----------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|     | <p>Proper adjustment of the A/C head position is important for ensuring adequate audio output and S/N. Severe misalignment can prevent control signal pick-up and cause servo instability. Precise adjustment is particularly important for models that include tape indexing and addressing features, since these rely on control signal coding for operation.</p> <p>To observe the audio signal, connect an oscilloscope to the test point (AUDIO OUT) of the audio circuit, or directly to the audio output terminal. In some cases, monitoring the sound with headphones may be helpful.</p>                                                          |                                                                                                                         |                |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| 2   | A/C head adjustments                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |  <p>Fig. 1-9-4 A/C head</p>            |                | <ol style="list-style-type: none"> <li>1) Play the staircase (audio 6 kHz) portion of the MH-2 Alignment tape.</li> <li>2) Adjust screw (3) (Fig. 1-9-4), which is the azimuth adjustment, for maximum output.</li> <li>3) Turn screws (1), (2) and (3) by small and equal increments (about 45° at a time) to adjust the A/C head height for maximum audio output. Slightly raise and lower the height to confirm the maximum output position.</li> <li>4) Observe the FM waveform and tighten the guide roller set-screws. Use care not to disturb the height adjustments. Then again confirm the FM waveform.</li> </ol>                                                                                                                                                                                                                                                                                                                                                   |
|     | <p>This determines the distance between the sound and picture information on the tape. Correct adjustment is important for providing synchronization of picture and sound in the program. Incorrect adjustment is particularly noticeable in the slow speed (LP) mode.</p> <p>Observe the FM waveform by connecting an oscilloscope to the video play-back circuit test point (FM OUT). Trigger the oscilloscope externally with the drum flipflop signal. Use plus (+) trigger to view the CH1 waveform. Set the tracking adjustment to the neutral (AUTO) position. (Turn off the indicator by pressing the + and - tracking buttons simultaneously)</p> |                                                                                                                         |                |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| 3   | Control head phase (X value)                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |  <p>Fig. 1-9-5 Control head phase</p> |                | <ol style="list-style-type: none"> <li>1) Play the staircase portion of the MH-2 Alignment tape.</li> <li>2) See Fig. 1-9-5. Slightly loosen screws (4) and (5). Set the A/C head positioning tool over screw (4) with the pin of the tool inserted into the indicated hole.</li> <li>3) Turn the tool counterclockwise to shift the A/C head fully toward the capstan direction.</li> <li>4) While observing the CH-1 FM waveform, gradually turn the tool clockwise. Stop at the peak output position and tighten screw (5). Remove the tool and tighten screw (4).</li> <li>5) Replace alignment tape MH-2L with MH-2, play back the staircase segment of the alignment tape MH-2L.</li> <li>6) Operate the tracking adjustment and confirm that the maximum FM waveform is obtained at the neutral setting.</li> <li>7) If the FM output peak is not obtained at tracking neutral position, shift the A/C head at the FM output peak nearest to this position.</li> </ol> |

| No. | Item         | Adjustment parts | Operating mode | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
|-----|--------------|------------------|----------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 4   | Final checks |                  |                | <p>1) Supply a video or TV signal (monochrome is preferable). Use a spare tape and record and play back. Confirm that the play-back FM signal conforms to the parameters indicated in Fig. 1-9-1. Check for both SP and LP modes.</p> <p>2) Connect the oscilloscope to the test point (FM OUT) of the FM audio play-back circuit. Play the stairstep portion (which includes the FM audio carrier) of the MH-2L Alignment tape. Confirm absence of severe drop in FM waveform level.</p> <p>3) Perform the checks and, if necessary adjustments, of the Electrical Adjustments Section for the servo, video and audio (and FM audio) circuits.</p> |

## SECTION 2 ELECTRICAL ADJUSTMENTS

### 2.1 PREPARATION

Electrical adjustments are required after replacing circuit components and certain mechanical parts.

It is important to perform these adjustments only after all repairs and replacements have been completed. Also, do not attempt these adjustments unless the proper equipment is available.

#### 2.1.1 Required test equipment

1. Color television or monitor
2. Oscilloscope: wide-band, dual-trace, triggered delayed sweep
3. Frequency counter
4. Vectorscope
5. Audio oscillator
6. Audio voltmeter
7. Digital voltmeter
8. Signal generator: RF/IF sweep/marker
9. Signal generator: PAL color bar, staircase, video sweeper
10. Signal generator: Audio multiplex TV signal generator
11. Recording tape
12. Alignment tape: MH-2, MH-2H
13. RCA-S adapter: PTU93001A
14. Patch cord: PTU94001  
(PRE/REC board to CONNECTOR board)
15. Extension cable: PTU93004A  
(AV IN/OUT board to MECHACON board)  
(SERVO board to MECHACON board)
16. Head resonance adjust coil : PTU94004A
17. Head resonance adjust fixture : PTU94006A




Fig. 2-1-1 Color bar signal of pattern generator




Fig. 2-1-2 Color bar signal waveform

|       |        |            |       |         |     |      |
|-------|--------|------------|-------|---------|-----|------|
| White | Yellow | Cyan       | Green | Magenta | Red | Blue |
| (75%) |        |            |       |         |     |      |
| V     | U      | White 100% |       |         |     |      |
|       |        |            |       |         |     |      |

Fig. 2-1-3 Color bar pattern




Fig. 2-1-4 Input signal level for video sweeper



### 2.1.2 Check and adjustment steps

The check and adjustment steps are provided in the following in the form of charts. For clarity, the nomenclature used in the charts is outlined below.

|                          |                                                                                                                                                                                                                              |
|--------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>No.</b>               | Checks and adjustments are numbered in the recommended sequence in which they are to be performed.                                                                                                                           |
| <b>Item</b>              | Name assigned to the particular check and adjustment step.                                                                                                                                                                   |
| <b>Check Point</b>       | Location to which measuring instrument (oscilloscope unless otherwise noted) is to be connected.                                                                                                                             |
| <b>Adjustment Parts</b>  | Variable component (resistor, capacitor, etc.) to be adjusted in this step. Dash (—) indicates check only.                                                                                                                   |
| <b>Signal &amp; Mode</b> | <ul style="list-style-type: none"> <li>• Input signal required to perform adjustment. Dash (—) indicates that special signal is not required.</li> <li>• Equipment operating mode at time of check or adjustment.</li> </ul> |
| Color bars               | Color bars signal as video input.                                                                                                                                                                                            |
| Stairstep                | Stairstep signal as video input.                                                                                                                                                                                             |
| 1 kHz                    | 1 kHz sinewave as audio input signal.                                                                                                                                                                                        |
| MH-2 color bars          | Color bars segment of MH-2 alignment tape.                                                                                                                                                                                   |
| MH-2 stairstep           | Stairstep segment of MH-2 alignment tape.                                                                                                                                                                                    |
| MH-2 1 kHz               | 1 kHz audio signal segment of MH-2 alignment tape.                                                                                                                                                                           |
| MH-2 RF sweep            | RF sweep segment of MH-2 alignment tape.                                                                                                                                                                                     |
| MH-2L color bars         | Color bars segment of MH-2L alignment tape.                                                                                                                                                                                  |
| MH-2L stairstep          | Stairstep segment of MH-2L alignment tape.                                                                                                                                                                                   |
| MH-2L RF sweep           | RF sweep segment of MH-2L alignment tape.                                                                                                                                                                                    |
| MH-2H color bars         | Color bars segment of MH-2H alignment tape.                                                                                                                                                                                  |
| MH-F2 stairstep          | Stairstep segment of MH-F2 alignment tape.                                                                                                                                                                                   |
| MH-F2 1 kHz              | 1 kHz FM audio signal segment of MH-F2 alignment tape.                                                                                                                                                                       |

|            |                                      |
|------------|--------------------------------------|
| E-E        | Power on and machine in Stop mode.   |
| REC        | Recording mode                       |
| PB         | Playback mode                        |
| SEARCH     | Search (FWDS and REVS) playback mode |
| SLOW       | Slow motion playback mode            |
| STILL      | Pause during playback mode           |
| A DUB      | Audio dubbing mode                   |
| SP mode    | SP recording speed                   |
| EP mode    | EP recording speed                   |
| LP mode    | LP recording speed                   |
| S-VHS mode | Super-VHS recording mode             |
| VHS mode   | VHS recording mode                   |

|                    |                                                                               |
|--------------------|-------------------------------------------------------------------------------|
| <b>Description</b> | This column provides an explanation of the step, notes and adjustment values. |
|--------------------|-------------------------------------------------------------------------------|

## 2.2 SWITCHING REGULATOR CIRCUIT

Note: Unless otherwise noted, all test points and adjustments are located on the SWITCHING REGULATOR board.

| No. | Item                         | Check Point | Adjustment Parts  | Signal & Mode    | Description                                                                                                                       |
|-----|------------------------------|-------------|-------------------|------------------|-----------------------------------------------------------------------------------------------------------------------------------|
| 1   | 5 V DC output voltage        | TP1         | R26 (SWD 5V)      | • REC<br>• TUNER | 1) Connect a digital voltmeter between TP1 and TP-GND.<br>2) Record in the TUNER mode, and adjust R26 for $5.345 \pm 0.05$ V.     |
| 2   | Semi-REG 15 V output voltage | CN3 pin 10  | R9 (SEMI REG 15V) | • REC<br>• TUNER | 1) Connect a digital voltmeter between CN3 pin 10 and TP-GND.<br>2) Record in the TUNER mode, and adjust R9 for $15.2 \pm 0.2$ V. |


## 2.3 TIMER CIRCUIT

Note: Unless otherwise noted, all test points and adjustments are located on the TIMER board.

| No. | Item        | Check Point      | Adjustment Parts | Signal & Mode | Description                                                                                                                                                                                                                                                 |
|-----|-------------|------------------|------------------|---------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1   | Timer clock | TP2<br>TP1 (GND) | C10              | • E-E         | 1) Connect a frequency counter between TP2 and GND.<br>2) Short between TP3 (TEST) and GND, then short the leads of electrolytic capacitor C8 once in order to reset IC1.<br>3) Adjust C10 for $2048.000 \pm 0.002$ Hz ( $488.2808$ to $488.2818$ $\mu$ s). |

## 2.4 SERVO CIRCUIT

Note: Unless otherwise noted, all test points and adjustments are located on the SERVO board.

| No. | Item                         | Check Point        | Adjustment Parts           | Signal & Mode                                                                                                                                                                                                        | Description                                                                                                                                                                                                                                                                                                                                                                        |
|-----|------------------------------|--------------------|----------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1   | SP PB switching point        | TP10 (VIDEO board) | R32 (SW POINT)             | <ul style="list-style-type: none"> <li>• PB</li> <li>• MH-2 (stairstep)</li> <li>• Trigger slope (—)</li> <li>• SP mode</li> </ul>  | <ol style="list-style-type: none"> <li>1) Connect an oscilloscope to TP10 of the VIDEO board.</li> <li>2) Play back the stairstep segment of MH-2 alignment tape.</li> <li>3) Trigger the oscilloscope externally (— slope) with the signal from TP11 of the VIDEO board.</li> <li>4) Adjust R32 to position the trigger point <math>6.5 \pm 0.5 H</math> from V. sync.</li> </ol> |
| 2   | SP slow tracking preset      | Monitor            | R55 (SP SLOW)              | <ul style="list-style-type: none"> <li>• REC</li> <li>↓</li> <li>• Slow PB (1/6)</li> <li>• SP</li> </ul>                                                                                                            | <ol style="list-style-type: none"> <li>1) Set the TRACKING control of the FRONT to the preset position by simultaneously pressing the + and — TRACKING buttons.</li> <li>2) Record a color bar signal in the SP mode, then play back in the Slow mode.</li> <li>3) Adjust R55 to minimize noise bars on the video monitor screen.</li> </ol>                                       |
|     | LP slow tracking preset      | Monitor            | R59 (LP SLOW)              | <ul style="list-style-type: none"> <li>• REC</li> <li>↓</li> <li>• Slow PB (1/6)</li> <li>• LP</li> </ul>                                                                                                            | <ol style="list-style-type: none"> <li>4) In the same manner, adjust R59 for the LP mode.</li> </ol>                                                                                                                                                                                                                                                                               |
| 3   | SP X2 normal tracking preset | Monitor            | R38 (SP X2)                | <ul style="list-style-type: none"> <li>• SP</li> <li>• REC</li> <li>↓</li> <li>• X2 Play</li> </ul>                                                                                                                  | <ol style="list-style-type: none"> <li>1) Set the TRACKING control of the FRONT panel to the preset position by simultaneously pressing the + and — TRACKING buttons.</li> <li>2) Record a color bar signal in the SP mode, then play back in the 2X Play mode.</li> <li>3) Adjust R38 to minimize noise bars on the video monitor screen.</li> </ol>                              |
|     | EP X2 normal tracking preset | Monitor            | R36 (LP X2)                | <ul style="list-style-type: none"> <li>• LP</li> <li>• REC</li> <li>↓</li> <li>• X2 Play</li> </ul>                                                                                                                  | <ol style="list-style-type: none"> <li>4) In the same manner, adjust R36 for the LP mode.</li> </ol>                                                                                                                                                                                                                                                                               |
| 4   | V. pulse position            | Monitor            | R11 (V. LOCK) (REAR panel) | <ul style="list-style-type: none"> <li>• REC then PB</li> <li>↓</li> <li>• STILL</li> <li>• SP</li> <li>• Color bar</li> </ul>                                                                                       | <ol style="list-style-type: none"> <li>1) Record the color bar signal, then play back.</li> <li>2) In the Still mode, observe the monitor and adjust R11 (REAR panel) for the minimum vertical jitter.</li> </ol>                                                                                                                                                                  |

## 2.5 VIDEO CIRCUIT

Note: Unless otherwise noted, all test points and adjustments are located on the VIDEO board.






| No. | Item                                                                               | Check Point  | Adjustment Parts     | Signal & Mode                                                                                                    | Description                                                                                                                                                                                                                                                                                                          |
|-----|------------------------------------------------------------------------------------|--------------|----------------------|------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1   | Y comb level                                                                       | TP25<br>TP26 | R107                 | <ul style="list-style-type: none"> <li>• S-VHS mode</li> <li>• SP</li> <li>• E-E</li> <li>• Color bar</li> </ul> | <ol style="list-style-type: none"> <li>1) Connect one channel of a dual trace oscilloscope to TP25 and the other channel to TP26.</li> <li>2) Adjust R107 so that TP25 and TP26 become the same level.</li> </ol>                                                                                                    |
|     |   |              |                      |                                                                                                                  |                                                                                                                                                                                                                                                                                                                      |
| 2   | 2H delayed chroma                                                                  | TP31<br>TP32 | R110<br>T2           | <ul style="list-style-type: none"> <li>• S-VHS mode</li> <li>• SP</li> <li>• E-E</li> <li>• Color bar</li> </ul> | <ol style="list-style-type: none"> <li>1) Connect CH-1 of a dual trace oscilloscope to TP31 and CH-2 to TP32.</li> <li>2) Set VOLT/DIV controls of both channels to the same range (e.g., 50 mV).</li> <li>3) Invert CH-2 and use ADD mode.</li> <li>4) Alternately adjust R110 and T2 for minimum level.</li> </ol> |
| 3   | 4H delayed chroma                                                                  | TP31<br>TP33 | R108<br>T1           | <ul style="list-style-type: none"> <li>• S-VHS mode</li> <li>• SP</li> <li>• E-E</li> <li>• Color bar</li> </ul> | <ol style="list-style-type: none"> <li>1) In the same manner, adjust R108 and T1 for minimum level.</li> </ol>                                                                                                                                                                                                       |
| 4   | Y-comb                                                                             | TP34         | R119<br>R118<br>R197 | <ul style="list-style-type: none"> <li>• VHS mode</li> <li>• SP</li> <li>• E-E</li> <li>• Color bar</li> </ul>   | <ol style="list-style-type: none"> <li>1) Connect an oscilloscope to TP34.</li> <li>2) Adjust R118, R119 and R197 alternately for minimum chromatic level (less than 40 mVp-p of the magenta portion).</li> </ol>                                                                                                    |
|     |  |              |                      |                                                                                                                  |                                                                                                                                                                                                                                                                                                                      |

Fig. 2-5-1

| No. | Item                    | Check Point                                                                         | Adjustment Parts     | Signal & Mode                                                                                                         | Description                                                                                                                                                                                                                                                                                                                                    |
|-----|-------------------------|-------------------------------------------------------------------------------------|----------------------|-----------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 5   | E-E level               | TP10                                                                                | R75                  | <ul style="list-style-type: none"> <li>• S-VHS mode</li> <li>• SP</li> <li>• E-E</li> <li>• Color bar</li> </ul>      | 1) Connect an oscilloscope to TP10.<br>2) Adjust R75 for $0.97 \pm 0.03$ Vp-p (with $75 \Omega$ load).                                                                                                                                                                                                                                         |
|     |                         |     |                      |                                                                                                                       |                                                                                                                                                                                                                                                                                                                                                |
| 6   | Sub emph. input level   | TP39                                                                                | R57                  | <ul style="list-style-type: none"> <li>• S-VHS mode</li> <li>• SP</li> <li>• E-E</li> <li>• Color bar</li> </ul>      | 1) Connect an oscilloscope to TP39.<br>2) Adjust R57 for $400 \pm 20$ mVp-p signal level in the SP mode.                                                                                                                                                                                                                                       |
|     |                         |    |                      |                                                                                                                       | Fig. 2-5-2                                                                                                                                                                                                                                                                                                                                     |
| 7   | S-VHS mode REC FM level | TP3 (PRE/REC)                                                                       | R103 (S-MODE REC FM) | <ul style="list-style-type: none"> <li>• S-VHS mode</li> <li>• LP mode</li> <li>• REC</li> <li>• Color bar</li> </ul> | <p><b>Note:</b> Connect an oscilloscope's GND terminal to TP-GND near the shield case of the PRE/REC board.</p> 1) Connect an oscilloscope to TP3 of the PRE/REC board and record a color bar signal in the LP mode.<br>2) Adjust R103 for $3.0 \pm 0.2$ Vp-p pedestal level, between centers of the waveform outline at the pedestal portion. |
|     |                         |  |                      |                                                                                                                       | Fig. 2-5-3                                                                                                                                                                                                                                                                                                                                     |
| 8   | VHS mode REC FM level   | TP3 (PRE/REC)                                                                       | R95 (VHS REC FM)     | <ul style="list-style-type: none"> <li>• VHS mode</li> <li>• LP mode</li> <li>• REC</li> <li>• Color bar</li> </ul>   | 1) In the same manner as above (2.5.7), adjust R95 for $2.0 \pm 0.1$ Vp-p pedestal level.                                                                                                                                                                                                                                                      |

| No.                                                                                                  | Item                           | Check Point       | Adjustment Parts       | Signal & Mode                                                                                                                                                                                                                                              | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
|------------------------------------------------------------------------------------------------------|--------------------------------|-------------------|------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 9                                                                                                    | SP REC color level and balance | TP307             | R355 (SP REC COLOR)    | <ul style="list-style-type: none"> <li>• S-VHS mode</li> <li>• PB mode</li> <li>• MH-2H color bars</li> <li>• SP mode</li> <li>• AUTO TRACKING OFF</li> <li>• REC then PB</li> <li>• Color bars</li> <li>• SP mode</li> <li>• AUTO TRACKING OFF</li> </ul> | <p><b>Note:</b> Use larger-level waveform for adjustment.</p> <ol style="list-style-type: none"> <li>1) Connect an oscilloscope to TP307. Play back the color bar segment of the MH-2H and observe color signal level.</li> <li>2) Adjust by pressing the + and - TRACKING buttons of the FRONT panel for maximum level of the color waveform and make a note of the higher color level "A".</li> <li>3) Set the TRACKING control of the FRONT panel to the preset position by simultaneously pressing the + and - TRACKING buttons.</li> <li>4) Record and play back the color bar signal. If necessary, before recording, adjust R355 so that the higher level channel becomes 110% of the noted level "A" during playback. At this time, confirm that the channel difference is within 3 dB.</li> </ol>                             |
|                     |                                |                   |                        |                                                                                                                                                                                                                                                            |  <p>Fig. 2-5-4</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| 10                                                                                                   | LP REC color level and balance | TP307             | R353 (LP REC COLOR)    | <ul style="list-style-type: none"> <li>• S-VHS mode</li> <li>• PB mode</li> <li>• LP mode</li> <li>• MH-2H color bar</li> <li>• AUTO TRACKING OFF</li> <li>• REC then PB</li> <li>• Color bar</li> <li>• LP mode</li> <li>• AUTO TRACKING OFF</li> </ul>   | <p><b>Note:</b> Perform the LP mode adjustment after completing that for the SP mode.</p> <ol style="list-style-type: none"> <li>1) Connect an oscilloscope to TP307. Play back the color bar segment of the MH-2H and observe color signal level.</li> <li>2) Adjust by pressing the + and - TRACKING buttons of the FRONT panel for maximum level of the color waveform and make a note of the higher color level "A".</li> <li>3) Set the TRACKING control of the FRONT panel to the preset position by simultaneously pressing the + and - TRACKING buttons.</li> <li>4) Record and play back the color bar signal. If necessary, before recording, adjust R353 so that the higher level channel becomes 110% of the noted level "A" during playback. At this time, confirm that the channel difference is within 3 dB.</li> </ol> |
|  <p>Fig. 2-5-5</p> |                                |                   |                        |                                                                                                                                                                                                                                                            |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| 11                                                                                                   | S-VHS mode PB Y level          | VIDEO OUT or TP10 | R92 (S VHS PB Y LEVEL) | <ul style="list-style-type: none"> <li>• S-VHS mode</li> <li>• SP mode</li> <li>• REC then PB</li> <li>• Color bars</li> </ul>                                                                                                                             | <ol style="list-style-type: none"> <li>1) Connect an oscilloscope to VIDEO OUT (TP10).</li> <li>2) Record the color bar signal in the SP mode, then play it back.</li> <li>3) Adjust R92 for <math>0.97 \pm 0.03</math> Vp-p (with 75 <math>\Omega</math> load).</li> </ol>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |

| No. | Item                                                  | Check Point             | Adjustment Parts           | Signal & Mode                                                                                                                                                                                                                                                | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
|-----|-------------------------------------------------------|-------------------------|----------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 12  | VHS mode<br>PB Y level                                | VIDEO OUT<br>or<br>TP10 | R91<br>(VHS<br>PB Y LEVEL) | <ul style="list-style-type: none"> <li>• VHS mode</li> <li>• SP mode</li> <li>• REC then PB</li> <li>• Color bars</li> </ul>                                                                                                                                 | 1) In the same manner as above (2.5.11), adjust R91 for $0.97 \pm 0.03$ Vp-p (with $75 \Omega$ load).                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 13  | Sharpness<br>preset                                   | TP24                    | R42                        | <ul style="list-style-type: none"> <li>• S-VHS mode</li> <li>• SP</li> <li>• E-E</li> <li>• Sweeper</li> </ul> <hr/> <ul style="list-style-type: none"> <li>• S-VHS mode</li> <li>• SP</li> <li>• PB</li> <li>• Color bar</li> <li>• EDIT SW: OFF</li> </ul> | 1) Connect an oscilloscope to TP24.<br>2) Set the SHARPNESS control of the FRONT panel to the center detent position.<br>3) Adjust R42 so that the 2 MHz mark, in the state of EDIT SW "OFF", becomes nearly equal to that in the state of EDIT SW "ON".<br><br><b>Alternate method:</b><br>1) Connect an oscilloscope to TP110 (Y OUT).<br>2) Set the SHARPNESS control of the FRONT panel to the center detent position.<br>3) Play the color bar signal of the MH-2H (or MH-2 if MH-2H is not available) alignment tape.<br>4) Adjust R42 (SHARPNESS PRESET) to where slight overshoot appears at the sync tip as shown in Fig. 2-5-6. |
|     |                                                       |                         |                            |                                                                                                                                                                                                                                                              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| 14  | S-VHS mode<br>SP frequency<br>response and<br>balance | TP110                   | R108<br>[PRE/REC<br>board] | <ul style="list-style-type: none"> <li>• S-VHS mode</li> <li>• SP mode</li> <li>• REC then PB</li> <li>• Sweeper</li> </ul>                                                                                                                                  | 1) Terminate TP110 (S-OUT) with a $75 \Omega$ load and set the SHARPNESS control to the center detent position.<br>2) Connect a signal generator to S-IN and an oscilloscope to TP110.<br>3) Record in the SP mode, then play back and set 100 kHz level to 3 scale divisions on X axis at CH-1 waveform.<br>4) Adjust R108 (PRE/REC board) so that the 3.0 MHz level becomes 2.5 to 2.8 scale divisions ( $-1 \pm 0.5$ dB).<br>5) Confirm that the level difference between both channels is less than 2 dB.                                                                                                                             |
|     |                                                       |                         |                            |                                                                                                                                                                                                                                                              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
|     |                                                       |                         |                            |                                                                                                                                                                                                                                                              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |

Fig. 2-5-6

Fig. 2-5-7

| No. | Item                                                  | Check Point | Adjustment Parts                             | Signal & Mode                                                                                                                               | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
|-----|-------------------------------------------------------|-------------|----------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 15  | S-VHS mode<br>LP frequency<br>response and<br>balance | TP110       | R106<br>[PRE/REC<br>board]                   | <ul style="list-style-type: none"> <li>• S-VHS mode</li> <li>• LP mode</li> <li>• REC then PB</li> <li>• Sweeper</li> </ul>                 | <ol style="list-style-type: none"> <li>1) In the same manner as above (2.5.14), perform adjustment for LP mode.</li> <li>2) Record in the LP mode, then play back and set 100 kHz level to 3 scale divisions on X axis at CH-1 waveform.</li> <li>3) Adjust R106 so that the 3.0 MHz level becomes 2.0 to 2.3 scale divisions (<math>-3 \pm 0.5</math> dB).</li> <li>4) Confirm that the level difference between both channels is less than 2 dB.</li> </ol>                                                                                                                                            |
|     |                                                       | Monitor     | R108 (SP)<br>R106 (LP)<br>[PRE/REC<br>board] | <ul style="list-style-type: none"> <li>• S-VHS mode</li> <li>• SP and LP modes</li> <li>• REC then PB</li> <li>• Philips pattern</li> </ul> | <p><b>Alternate method:</b></p> <ol style="list-style-type: none"> <li>1) Record and playback a Philips pattern.</li> <li>2) During playback, observe the picture and adjust R108 (SP mode) and R106 (LP mode) for the best resolution, without impaired S/N, at about 250 lines (3 MHz region).</li> <li>3) So after this adjustment, confirm black or white spot on edges of playback picture in the Still mode.</li> </ol>                                                                                                                                                                            |
| 16  | VHS mode<br>SP frequency<br>response and<br>balance   | TP110       | R130<br>[PRE/REC<br>board]                   | <ul style="list-style-type: none"> <li>• VHS mode</li> <li>• SP mode</li> <li>• REC then PB</li> <li>• Sweeper</li> </ul>                   | <ol style="list-style-type: none"> <li>1) Terminate TP110 (S-OUT) with a <math>75 \Omega</math> load and set the SHARPNESS control to the center detent position.</li> <li>2) Connect a signal generator to S-IN and an oscilloscope to TP110.</li> <li>3) Record in the SP mode, then play back and set 100 kHz level to 3 scale divisions on X axis at CH-1 waveform.</li> <li>4) Adjust R130 (PRE/REC board) so that the 2.0 MHz level becomes 2.4 to 3 scale divisions (<math>-1 \pm 1</math> dB).</li> <li>5) Confirm that the level difference between both channels is less than 2 dB.</li> </ol> |










Fig. 2-5-8



| No.                                                                                 | Item                                                | Check Point | Adjustment Parts                             | Signal & Mode                                                                                                                        | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
|-------------------------------------------------------------------------------------|-----------------------------------------------------|-------------|----------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 17                                                                                  | VHS mode<br>LP frequency<br>response and<br>balance | TP110       | R131<br>[PRE/REC<br>board]                   | <ul style="list-style-type: none"><li>• VHS mode</li><li>• LP mode</li><li>• REC then PB</li><li>• Sweeper</li></ul>                 | <ol style="list-style-type: none"><li>1) In the same manner as above (2.5.16), perform adjustment for LP mode.</li><li>2) Record in the LP mode, then play back and set 100 kHz level to 3 scale divisions on the screen at CH-1 waveform.</li><li>3) Adjust R131 (PRE/REC board) so that the 2 MHz level becomes 1.5 to 2.4 scale divisions (<math>-5^{+3}_{-1}</math> dB).</li><li>4) Confirm that the level difference between both channels is less than 2 dB.</li></ol> |
|                                                                                     |                                                     | Monitor     | R130 (SP)<br>R131 (LP)<br>[PRE/REC<br>board] | <ul style="list-style-type: none"><li>• VHS mode</li><li>• SP and LP modes</li><li>• REC then PB</li><li>• Philips pattern</li></ul> | <p><b>Alternate method:</b></p> <ol style="list-style-type: none"><li>1) Record and play back a Philips pattern.</li><li>2) During playback, observe the picture and adjust R130 (SP mode) and R131 (LP mode) for the best resolution, without impaired S/N, at about 160 lines (2 MHz region).</li><li>3) So after this adjustment, confirm black or white spot.</li></ol>                                                                                                  |
|    |                                                     |             |                                              |                                                                                                                                      |                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| 18                                                                                  | 0.5H delayed<br>color level                         | TP10        | R9 (incl. IC6)                               | <ul style="list-style-type: none"><li>• Color bar</li><li>• LP mode</li><li>• REC then PB</li><li>↓</li><li>• SEARCH FF</li></ul>    | <ol style="list-style-type: none"><li>1) Connect an oscilloscope to VIDEO OUT or TP10 and set the time base of the oscilloscope to 2 ms/div. Trigger the oscilloscope externally (+ slope) with the signal from TP11 (DRUM FF) or the VIDEO board.</li><li>2) During Search, adjust R9 so that the Y level difference is uniform at VIDEO OUT as shown in the figure 2-5-9.</li></ol>                                                                                        |
|  |                                                     |             |                                              |                                                                                                                                      |                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| Fig. 2-5-9                                                                          |                                                     |             |                                              |                                                                                                                                      |                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |

| No.                                                                                                                              | Item                  | Check Point    | Adjustment Parts | Signal & Mode                                                                                           | Description                                                                                                                                                                                                                                                                                                                                                                                                                                              |
|----------------------------------------------------------------------------------------------------------------------------------|-----------------------|----------------|------------------|---------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 19                                                                                                                               | APC error phase       | TP305<br>TP328 | T301             | <ul style="list-style-type: none"> <li>• REC then PB</li> <li>• Color bar</li> <li>• SP mode</li> </ul> | <ol style="list-style-type: none"> <li>1) Connect one channel of a dual trace oscilloscope to TP305 and the other channel to TP328. Trigger the oscilloscope externally (— slope) with the signal from TP12 (H. SYNC).</li> <li>2) Set the oscilloscope for ALT mode.</li> <li>3) Adjust T301 to position the zero-cross <math>30 \mu\text{sec} \pm 3 \mu\text{sec}</math> from the center of the burst signal as shown in the figure 2-5-10.</li> </ol> |
|                                                 |                       |                |                  |                                                                                                         |  <p style="text-align: center;">Fig. 2-5-10</p>                                                                                                                                                                                                                                                                                                                         |
| 20                                                                                                                               | SECAM DET.            | TP401          | T401             | <ul style="list-style-type: none"> <li>• E-E</li> <li>• SECAM color bar</li> </ul>                      | <ol style="list-style-type: none"> <li>1) Connect an oscilloscope to TP401.</li> <li>2) Adjust T401 so that A and B are related as follows:<br/><math>A : B = 3 : 4</math></li> </ol>                                                                                                                                                                                                                                                                    |
|  <p style="text-align: center;">Fig. 2-5-11</p> |                       |                |                  |                                                                                                         |                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| 21                                                                                                                               | 0.25H delayed VIDEO-1 | TP36           | R163             | <ul style="list-style-type: none"> <li>• E-E</li> <li>• Color bar</li> </ul>                            | <ol style="list-style-type: none"> <li>1) Connect an oscilloscope to TP36.</li> <li>2) Adjust R163 for maximum output level.</li> </ol>                                                                                                                                                                                                                                                                                                                  |
| 22                                                                                                                               | 0.25H delayed VIDEO-2 | TP36<br>TP37   | R27              | <ul style="list-style-type: none"> <li>• E-E</li> <li>• Color bar</li> </ul>                            | <ol style="list-style-type: none"> <li>1) Connect one channel of a dual-trace oscilloscope to TP36 and the other channel to TP37.</li> <li>2) Set the oscilloscope for ALT mode.</li> <li>3) Adjust R27 for equal channel levels.</li> </ol>                                                                                                                                                                                                             |



## 2.6 AUDIO CIRCUIT

**Note:** Unless otherwise noted, all test points and adjustments are located on the AUDIO board.

| No. | Item             | Check Point      | Adjustment Parts                                    | Signal & Mode                                                                                                                                    | Description                                                                                                                                                                                                                                                                                                                                                                             |
|-----|------------------|------------------|-----------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1   | Audio bias level | TP31<br>TP32     | R9 (BIAS ADJ)                                       | <ul style="list-style-type: none"> <li>• VHS mode</li> <li>• SP mode</li> <li>• No signal</li> </ul>                                             | 1) Connect a millivoltmeter between TP31 and TP32.<br>2) Set for REC mode without signal.<br>3) Adjust R9 for 2.2 mVrms.                                                                                                                                                                                                                                                                |
| 2   | Audio PB level   | AUDIO OUT        | R28 (PB LEVEL ADJ)                                  | <ul style="list-style-type: none"> <li>• REC then PB</li> <li>• SP and LP mode</li> <li>• VHS mode</li> <li>• Audio monitor to Normal</li> </ul> | 1) Connect an audio tester to AUDIO OUT.<br>2) Supply an audio signal ( $-8$ dBs/1 kHz) to Peri. IN and record together with a video signal, then play back.<br>3) Adjust R28 so that the audio output level during playback becomes $-6 \pm 1$ dBs at SP mode ( $-6 \pm 2$ dBs at LP mode).                                                                                            |
| 3   | REC FM level     | TP53             | R80 (FM REC ADJ)                                    | <ul style="list-style-type: none"> <li>• S-VHS mode</li> <li>• SP mode</li> <li>• REC then PB</li> <li>• No signal</li> </ul>                    | 1) Connect an oscilloscope to TP53.<br>2) Record in the SP mode, without an audio signal, then play back.<br>3) Adjust R80 for 50 mVp-p $\pm 5$ mVp-p FM audio playback voltage.                                                                                                                                                                                                        |
| 4   | E-E level        | AUDIO OUT        | R40 (E-E LEVEL [L])<br>-----<br>R41 (E-E LEVEL [R]) | <ul style="list-style-type: none"> <li>• ALC: OFF</li> <li>• REC mode</li> <li>• Audio monitor to Hi-Fi</li> </ul>                               | 1) Supply a 1 kHz, $-8$ dBs audio signal to Peri. IN and a video signal to Peri. IN.<br>2) Set Hi-Fi REC level controls to detent position. In the REC mode, adjust R40 to obtain $-6 \pm 0.5$ dBs at AUDIO OUT.<br>3) In the same manner, adjust R41 for the R (CH-2) channel.                                                                                                         |
| 5   | Level indicator  | FDP (LEVEL IND.) | R73 (LEVEL IND [L])<br>-----<br>R74 (LEVEL IND [R]) | <ul style="list-style-type: none"> <li>• Audio monitor to Hi-Fi</li> <li>• E-E (Stop) mode</li> <li>• LEVEL INDICATOR SW: ON</li> </ul>          | <b>Note: Perform the level indicator adjustment after completing the E-E level adjustment (section 2.6.4).</b><br>1) Supply a 1 kHz, $-8$ dBs audio signal to Peri. IN.<br>2) Set Hi-Fi REC level controls to detent position. In the E-E (Stop) mode, adjust R73 to the point where the FDP level indicators show 0 dB.<br>3) In the same manner, adjust R74 for the R (CH-2) channel. |

## 2.7 TUNER/IF CIRCUIT

Note: Unless otherwise noted, all test points and adjustments are located on the TUNER/IF board.

| No. | Item                                                                                                                                                                                                                                                     | Check Point                                                                                                                                                                                                                                                                                                                                                                                                                      | Adjustment Parts | Signal & Mode                                                                                                                    | Description                                                                                                                                                                                                                                                                                                                                                                 |
|-----|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------|----------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|     | <ul style="list-style-type: none"> <li>Equipment required:</li> <li>1. Oscilloscope</li> <li>2. IF sweep signal generator with suitable markers (PIF, SIF, etc.)</li> <li>3. Sweeper probe (sweep signal supply cable) as shown on the right.</li> </ul> |                                                                                                                                                                                                                                                                                                                                                                                                                                  |                  |                                                                                                                                  |  <p>Fig. 2-7-1</p>                                                                                                                                                                                                                                                                         |
| 1   | VCO                                                                                                                                                                                                                                                      | IC1 pin 28                                                                                                                                                                                                                                                                                                                                                                                                                       | T2 (VCO)         | <ul style="list-style-type: none"> <li>Sweep generator out: 70 dBμ (38.9 MHz)</li> <li>Tuner mode with-out antenna IN</li> </ul> | <p>1) Use a sweeper probe as shown in Fig. 2-7-1 and connect the sweep generator output to pin 1 of SAW 1.</p> <p>Adjust the sweep gain so that the waveform does not distort as observed with the oscilloscope.</p> <p>Connect the oscilloscope to pin 28 of IC1 (VIDEO DET OUT) and adjust T2 to align the waveform with the frequency marker as shown in Fig. 2-7-2.</p> |
|     |                                                                                                                                                                                                                                                          |  <p>Fig. 2-7-2</p>                                                                                                                                                                                                                                                                                                                              |                  | <ul style="list-style-type: none"> <li>TV broadcast</li> <li>Tuner mode</li> </ul>                                               | <p>Alternate method:</p> <p>1) Receive a color broadcast on a VHF-HI channel (7 to 13).</p> <p>2) Adjust T2 to obtain a fine picture on the monitor.</p>                                                                                                                                                                                                                    |
|     |                                                                                                                                                                                                                                                          | <ul style="list-style-type: none"> <li>Before the following adjustments:</li> <li>1. Connect a cable to ANT IN and terminate TV OUT at 75 Ω.</li> <li>2. Set a TV channel signal generator as follows.</li> </ul> <div style="border: 1px solid black; padding: 5px; width: fit-content; margin: 10px auto;"> <p>Video : 70 dBμ/75 Ω, color bar 87.5% modulation</p> <p>Audio : 62 dBμ/75 Ω, 1 kHz ± 25 kHz deviation</p> </div> |                  |                                                                                                                                  |                                                                                                                                                                                                                                                                                                                                                                             |
| 2   | RF AGC                                                                                                                                                                                                                                                   | IF terminal of Front end                                                                                                                                                                                                                                                                                                                                                                                                         | R21 (RF AGC)     | <ul style="list-style-type: none"> <li>TV signal</li> <li>Tuner mode</li> </ul>                                                  | <p>1) Connect the oscilloscope to IF terminal of U/V Tuner (Front end). Adjust R21 for maximum level, then again adjust R21 for -10 dB gain.</p>                                                                                                                                                                                                                            |
|     |                                                                                                                                                                                                                                                          | Monitor                                                                                                                                                                                                                                                                                                                                                                                                                          | R21 (RF AGC)     | <ul style="list-style-type: none"> <li>TV broadcast</li> <li>Tuner mode</li> </ul>                                               | <p>Alternate method:</p> <p>Note: Adjust R21 (RF AGC) to correct for excess noise in the picture or when streaky cross interference occurs due to strong electrical fields.</p> <p>1) Adjust R21 to minimize noise or streaks on the TV screen.</p> <p>2) Check for absence of abnormality on all channels.</p>                                                             |

| No.                                                                                                                                                                         | Item        | Check Point | Adjustment Parts  | Signal & Mode                                                                                               | Description                                                                                                                                 |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------|-------------|-------------------|-------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------|
| 3                                                                                                                                                                           | Color level | JP1 pin 12  | R40 (COLOR LEVEL) | <ul style="list-style-type: none"> <li>• TV broadcast</li> <li>• Tuner mode</li> <li>• Color bar</li> </ul> | 1) Receiving a color bar signal, set the Y level for 100% reference signal and then adjust R40 for a magenta level of 56% at pin 12 of JP1. |
|  <p>Y level = 1<br/>Magenta level = 0.56<br/>a : b = 1 : 0.56</p> <p><b>Fig. 2-7-3</b></p> |             |             |                   |                                                                                                             |                                                                                                                                             |

## 2.8 DEMODULATOR CIRCUIT

Note: Unless otherwise noted, all test points and adjustments are located on the DEMODULATOR board.

### Audio Multiplex TV Signal Generator





#### Recommended Specifications

|                            |                                                           |                           |                               |        |
|----------------------------|-----------------------------------------------------------|---------------------------|-------------------------------|--------|
| 1. Signal Format           | Based on CCIR-B                                           | 9. Sound Modulation Modes | $S_1$                         | $S_2$  |
| 2. Frequency               |                                                           | Mono                      | Mono 1                        | Mono 2 |
| Video Carrier $F_v$        | 38.9 MHz                                                  | Stereo                    | (L + R)/2                     | R      |
| 1st Sound Carrier $f_{s1}$ | 33.4 MHz                                                  | Dual                      | Mono 1                        | Mono 2 |
| 2nd Sound Carrier $f_{s2}$ | 33.1578125 MHz                                            | 10. Functions             | $S_1$                         | $S_2$  |
| 3. Modulator               |                                                           | Mono (M)                  | 100%                          | 100%   |
| Video                      | Crosshatch (black on white)                               | Stereo (L, R)             | (L + R)/2                     | R      |
|                            | V: 50 Hz, H: 15.625 kHz                                   | (L)                       | L/2                           | —      |
| Audio                      | Sinewave 1 kHz; CH1 and CH2 outputs switchable            | (R)                       | R/2                           | R      |
|                            | CH-2 outputs switchable                                   | (OFF)                     | —                             | —      |
| 4. Output                  | 97 dB/ $\mu$ V (open) $\pm$ 2 dB fixed, BNC-R 75 $\Omega$ | Mult ( $S_1, S_2$ )       | 100%                          | 100%   |
| 5. P-S Ratio               | $S_1$ P - 13 dB $\pm$ 2 fixed                             | ( $S_1$ )                 | 100%                          | 0      |
|                            | $S_2$ P - 20 dB $\pm$ 2 fixed                             | ( $S_2$ )                 | 0                             | 100%   |
| 6. Modulation              |                                                           | (OFF)                     | 0                             | 0      |
| Video                      | 87.5% $\pm$ 3%                                            | V. MOD (ON/OFF)           |                               |        |
| Audio                      | $\pm$ 30 kHz $\pm$ 2 kHz                                  | 11. Frequency Accuracy    | Within $\pm 5 \times 10^{-5}$ |        |
| 7. Stereo Separation       | Less than -40 dB                                          | 12. Spurious              | Less than -50 dB              |        |
| 8. Pilot Signal            |                                                           | 13. Saw Filter            | Self-contained                |        |
| Carrier Frequency          | 54.6875 kHz $\pm$ 5 Hz synchro-nized type                 |                           |                               |        |
| Stereo                     | 117.5 Hz AM 50%                                           |                           |                               |        |
| Dual                       | 274.1 Hz AM 50%                                           |                           |                               |        |

| No. | Item                       | Check Point                    | Adjustment Parts   | Signal & Mode                                                                                                    | Description                                                                                                                                                                                                                                                                             |
|-----|----------------------------|--------------------------------|--------------------|------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1   | First audio detector coil  | IC1 pin 3                      | T4 [IF PWB]        | <ul style="list-style-type: none"> <li>•BILING mode</li> <li>•SUB: unmod.</li> <li>•MAIN: mod.</li> </ul>        | 1) Apply Main audio modulated signal to the front end IF terminal.<br>2) Connect a distortion meter to IC1 pin 3.<br>3) Adjust T4 of the IF board for minimum distortion.<br><br><b>Note: Audio multiplex TV signal generator connection is the same for the following adjustments.</b> |
| 2   | Second audio detector coil | IC1 pin 2                      | T1                 | <ul style="list-style-type: none"> <li>•BILING mode</li> <li>•SUB: mod.</li> <li>•MAIN: unmod.</li> </ul>        | 1) Connect a distortion meter to IC1 pin 2.<br>2) Adjust T1 of the IF board for minimum distortion.                                                                                                                                                                                     |
| 3   | Stereo separation          | IC1 pin 5                      | R2                 | <ul style="list-style-type: none"> <li>•STEREO mode</li> <li>•R: mod.</li> <li>•L: unmod.</li> </ul>             | 1) Set a signal generator to Stereo mode, but adjust only the R channel.<br>2) Connect an oscilloscope to IC1 pin 5.<br>3) Adjust R2 for minimum output level.                                                                                                                          |
| 4   | Buzz                       | CN2 pin 2                      | T8, T2 [IF PWB]    | <ul style="list-style-type: none"> <li>•STEREO mode</li> <li>•R/L: unmod.</li> </ul>                             | 1) Connect a noise meter to CN2 pin 2 and an oscilloscope to AC output of the noise meter.<br>2) Adjust T8 of the IF board for minimum Philips pattern noise.<br>3) Adjust T2 of the IF board for minimum crosshatch noise.                                                             |
| 5   | Audio output level         | CN2 pin 2 (L)<br>CN2 pin 4 (R) | R21 (L)<br>R24 (R) | <ul style="list-style-type: none"> <li>•STEREO mode</li> <li>•R: mod./unmod.</li> <li>•L: unmod./mod.</li> </ul> | 1) Set a signal generator for Stereo mode.<br>2) Connect an audio meter to CN2 pin 2.<br>3) Adjust R21 (L channel) for -14.0 dBs.<br>4) Similarly, connect an audio meter to pin 4 of CN2 and adjust R24 for the R channel.                                                             |

## 2.9 PRE/REC CIRCUIT

Note: Unless otherwise noted, all test points and adjustments are located on the PRE/REC board.

| No.                                                                                                  | Item                                      | Check Point | Adjustment Parts          | Signal & Mode                                                                                     | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
|------------------------------------------------------------------------------------------------------|-------------------------------------------|-------------|---------------------------|---------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1                                                                                                    | Video head resonance & Q (quality factor) | TP6         | CH-1<br>C7 (F)<br>R11 (Q) | <ul style="list-style-type: none"> <li>• Sweep signal</li> <li>• PB</li> <li>• SP mode</li> </ul> | <p>Note: 1) This adjustment is required only when flicker or black fringe noise appears after replacing the upper drum (video heads).</p> <p>2) Connect ground of probe (oscilloscope) to shield case of the PRE/REC board.</p> <p>3) Set the adjust coil after loading and remove it before unloading to prevent damage by loading poles.</p> <p>1) Disconnect a connector of CN1 from the SERVO board. Connect and use the Q adjust fixture (PTU94006A) as shown in Fig. 2-9-1.</p> <p>2) Set for the playback mode with a dummy cassette.</p> <p>* Dummy cassette: Cut the tape and cover the photo sensing holes with opaque tape.</p> <p>3) Set the adjust coil onto the upper drum as shown in Fig. 2-9-2.</p> <p>4) Connect an oscilloscope to TP6 of the PRE/REC board.</p> <p>Supply a sweeper generator output to the adjustment as shown in Fig. 2-9-2.</p> <p>Then, adjust the sweeper generator gain so that the waveform does not distort at TP6.</p> <p>5) Trigger the oscilloscope externally with the signal from TP11 (DRUM FF) of the VIDEO board. Use (—) trigger for CH-1 and (+) trigger for CH-2.</p> <p>6) Adjust C7 to set the CH-1 resonance point to 8 MHz. Use the control of the oscilloscope to position the 1 MHz region at graduation 2 of the oscilloscope scale.</p> <p>7) Adjust R11 to position the 8 MHz portion at 4 of the oscilloscope graduation as shown in Fig. 2-9-3.</p> |
|  <p>Fig. 2-9-1</p>  |                                           |             |                           |                                                                                                   |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
|  <p>Fig. 2-9-2</p>  |                                           |             |                           |                                                                                                   |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
|  <p>Fig. 2-9-3</p>  |                                           |             |                           |                                                                                                   |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
|  <p>Fig. 2-9-4</p> |                                           |             |                           |                                                                                                   |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
|                                                                                                      |                                           |             | CH-2<br>C5 (F)<br>R15 (Q) |                                                                                                   | 8) Change the adjust coil to CH-2 position, and, in the same manner as for CH-1, adjust C5 and R15 for CH-2.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
|                                                                                                      |                                           | TP7         | CH-1<br>C4 (F)<br>R13 (Q) | <ul style="list-style-type: none"> <li>• Sweep signal</li> <li>• PB</li> <li>• LP mode</li> </ul> | 9) Repeat the above steps (1 to 7) for the LP mode. Adjust resonance with C4 and Q with R13.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
|                                                                                                      |                                           |             | CH-2<br>C2 (F)<br>R12 (Q) |                                                                                                   | 10) Similarly, perform adjustment in the same manner as for CH-1. Adjust resonance with C2 and Q with R12.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |

## 2.10 DECORDER/VPT CIRCUIT

**Note:** Unless otherwise noted, all test points and adjustments are located on the DECORDER/VPT board.


| No. | Item         | Check Point | Adjustment Parts | Signal & Mode                                                                                                | Description                                                                                                                                                                                                  |
|-----|--------------|-------------|------------------|--------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1   | VCO          | IC505-17    | C524             | <ul style="list-style-type: none"> <li>• E-E</li> <li>• NO SIGNAL</li> </ul>                                 | 1) Do not connect anything to the antenna input connector.<br>2) Connect a frequency counter between IC505-17 and GND.<br>3) Adjust C524 for $6000 \pm 0.2$ kHz.                                             |
| 2   | Baseband AGC | IC13-29     | R55              | <ul style="list-style-type: none"> <li>• E-E</li> <li>• D2-MAC colour bar signal</li> <li>• TUNER</li> </ul> | 1) Connect an oscilloscope to IC13-29.<br>2) Short between Q65-Base and GND.<br>3) Adjust R55 for $1.85 \pm 0.05$ Vp-p.<br> |
| 3   | Colour level | Q40-E       | R231             | <ul style="list-style-type: none"> <li>• E-E</li> <li>• D2-MAC colour bar signal</li> <li>• TUNER</li> </ul> | 1) Connect an oscilloscope to Q40-Emitter.<br>2) Adjust R231 for $170 \pm 10$ mVp-p.                                                                                                                         |
| 4   | Fsc          | Q40-E       | C167             | <ul style="list-style-type: none"> <li>• E-E</li> <li>• D2-MAC colour bar signal</li> <li>• TUNER</li> </ul> | 1) Connect a frequency counter between Q40-Emitter and GND.<br>2) Adjust C167 for $4.433619 \pm 0.00001$ MHz.                                                                                                |


Fig. 2-10-1





## SECTION 3 CHARTS AND DIAGRAMS

### 3.1 CIRCUIT BOARD LOCATION






## 3.2 GENERAL INFORMATION

### 3.2.1 Connections

#### Note:

Unless otherwise specified, only signal input flow is indicated.

Connection arrows indicate only signal outputs.



VS : Connected pattern in the board.

Abbreviations


MS V : Video M : Mechacon

SM S : Servo A : Audio


VS : Signal flow from video to servo..

### 3.2.2 Disconnecting the flatwire

1. Pull the connector structure upward to release the clamp when removing or inserting the flat wire cable.



2. Depress the connector structure downward to release the clamp when removing or inserting the flat wire cable, as indicated below.









### 3.2.3 Indications

AUX : Active only at high.

AUX : Active only at low.

AUX : Active only at middle.

AUX : Active only at open.




### 3.2.4 Schematic diagram values

Unless otherwise specified.


1. All resistance values are in ohms, 1/6 W, 1/8 W, (refer to parts list).
2. All capacitance values are in  $\mu\text{F}$ , (P; PF).
3. All inductance values are in  $\mu\text{H}$ , (m; mH).
4. All diodes are 1SS133 or MA165, (refer to parts list).
5. Voltages are DC-measured (reference to ground) with a digital voltmeter during recording (SP mode) and playback (SP mode) with alignment tape. Where voltages differ between recording and playback, the voltage during playback is shown in parentheses.
6. Waveforms (VIDEO System) are measured (reference to ground) with a color bar during recording (SP mode) and playback (SP mode) with alignment tape.
7. Waveforms (AUDIO System) are measured (reference to ground) with 1 kHz (-8 dBs) during recording and playback with alignment tape (1 kHz).
8. Shaded ( ) parts are critical for safety. Replace only with specified parts numbers.

### 3.2.5 Signal flow in the schematic




### 3.2.6 Semiconductors


#### 1. Digital transistor



#### 2. Chip transistor



#### 3. Chip diode



#### Note:

The digital transistor includes built in resistors. It features small size and high reliability. Both PNP and NPN types are available.

#### Uses:

Inverter, interface, driver circuits.

### 3.2.7 Replacement of chip parts

For replacing chip parts, proceed it as follows.

Use a well insulated fine-tipped soldering iron (approx. 17 W, 130°C ~ 260°C in temp.).

In addition, it is recommended to use a soldering iron (55 W approx.) with solder absorber for convenience.

**Caution:** • Do not apply heat for more than 3 seconds.

- Do not rub electrodes.
- Do not reuse chips removed once. Discard them.
- Supplementary cementing is not required.

#### 1. Soldered condition of chip parts

- Resistors, capacitors, etc.




Fig. 3-2-1 Soldering condition-1

- Transistors, diodes, etc.




Fig. 3-2-2 Soldering condition-2

#### 2. How to remove chip parts

- Resistors, capacitors, etc.

1) Set a chip parts replacing tool onto the chip parts to hold it down.

2) Unsolder at a side of the chip parts.




Fig. 3-2-3 R/C removal-1

3) Remove the chip parts by twisting and sliding it.




Fig. 3-2-4 R/C removal-2

### 3. How to remove transistors, diode.

- 1) Unsolder at the one-lead side of the chip parts.



Fig. 3-2-5 Tr/Diode removal-1

- 2) Lift the unsoldered side upwards.



Fig. 3-2-6 Tr/Diode removal-2

- 3) Heat the other two leads simultaneously and remove the chip parts upwards.



Fig. 3-2-7 Tr/Diode removal-3

### 4. Preheating and soldering

When setting new chip parts, especially capacitors, but except transistors, preheat them with hot air (150°C approx.) by use of a blower type of hair dryer for about 2 minutes just before soldering. For soldering, use a soldering iron of 30 watt approximately.

### 5. How to set and solder chip parts

- 1) Presolder the contact points of the circuit pattern to which the chip parts will be soldered.



Fig. 3-2-8 Soldering-1

- 2) Holding down the chip parts with the chip parts replacing tool, solder it with a soldering iron.






Fig. 3-2-9 Soldering-2

### 3.3 BOARD INTERCONNECTIONS



### 3.4 SERVO BLOCK DIAGRAM




## 6













## 6




| NIFI |    |    | MIX |    |    | NORM |    |    | PIN |
|------|----|----|-----|----|----|------|----|----|-----|
| REC  | EE | PB | REC | EE | PB | REC  | EE | PB |     |
| L    | L  | H  | L   | L  | H  | L    | L  | H  | 31  |
| L    | M  | M  | L   | M  | M  | L    | M  | M  | 30  |


## 3.9 DECODER/VPT BLOCK DIAGRAM - (1) -








### 3.11 POWER SYSTEM BLOCK DIAGRAM






|   |  |
|---|--|
| 6 |  |
| 5 |  |
| 4 |  |
| 3 |  |
| 2 |  |
| 1 |  |







### 3.14 MECHANISM CONTROL SCHEMATIC DIAGRAM



### 3.15 DECK TERMINAL, CASSETTE HOUSING, RELAY, END SENSOR AND REC SAFETY SCHEMATIC DIAGRAMS




### 3.15 DECK TERMINAL, CASSETTE HOUSING, RELAY, END SENSOR AND REC SAFETY SCHEMATIC DIAGRAMS






### 3.17 MECHANISM CONTROL AND AUDIO CONTROL HEAD CIRCUIT BOARDS


— DECK TERMINAL —



— A/C HEAD —




— MECHACON —




E F G H 3-35 3-36 J K L M

### 3.17 MECHANISM CONTROL AND AUDIO CONTROL HEAD CIRCUIT BOARDS

— A/C HEAD —




— MECHACON —







## 6











### 3.21 VIDEO CIRCUIT BOARD






### 3.19 SERVO AND SERVO SUB CIRCUIT BOARDS

— SERVO —



— SERVO SUB —



A

B

C

3-41

3-42

E

F

G

H

## 6






## 6

5



## 3




# 3.24 PRE/REC AMP SCHEMATIC DIAGRAM



# 3.25 PRE/REC AMP CIRCUIT BOARD

Note: Double edging indicates not used in this model.

Examples: Resistor, Capacitor, Transistor, DIODE



A

B

C

355

356

E


F

G

H



# 3.27 AUDIO CIRCUIT BOARD



A

B

C

3-59

3-60

E


F

G

H



### 3.29 AV IN/OUT CIRCUIT BOARD



A

B

C

3-63

3-64


E

F

G

H

# 3.30 IF SCHEMATIC DIAGRAM




Note: Voltages are DC-measured with a digital voltmeter during stop and tuner mode. (3 ch)



6  
5  
4  
3  
2  
1

### 3.31 IF CIRCUIT BOARD

Note: Double edging indicates not used in this model.  
Examples; Resistor, Capacitor, Transistor, DIODE




IF PWB PB10047-01-03  
IF PWB ASS'Y PB10047AL

A B C 3-67 3-68 E F G H

## 6



# 3.33 TUNER CONTROL CIRCUIT BOARD





4


3

2


1



### 3.36 TIMER SCHEMATIC DIAGRAM



# 3.37 TIMER CIRCUIT BOARD



A

B

C

3-79

3-80

E

F

G

H

## 5

## 4





## 6



4

6

5

4

6

## 6





## C






## 3.42 DECODER/VPT CIRCUIT BOARD


REAR  
(B)



### 3.43 VPT/CTL SCHEMATIC DIAGRAM




# 3.44 AUTO TRACKING SCHEMATIC DIAGRAM







3.45 AUTO TRACKING CIRCUIT BOARD



## 3.46 TERMINAL SCHEMATIC DIAGRAM




# 3.47 TERMINAL CIRCUIT BOARD




A B C 3-103 3-104 E F G H

### 3.48 OPERATION AND STEP SCHEMATIC DIAGRAM




3.49 OPERATION AND STEP CIRCUIT BOARDS

— OPERATION —



— STEP —



A

B

C

3-107

3-108


E

F


G

H


## 3.50 SWITCH SCHEMATIC DIAGRAM



# 3.51 SWITCH CIRCUIT BOARD



## 3.52 RF CONVERTER SCHEMATIC DIAGRAM




## NOTES:

1. All parts shown in this schematic are critical for safety.
2. This schematic is only for reference.  
Avoid replacing individual parts.  
Replace the entire unit only.



### 3.53 REMOTE CONTROLLER SCHEMATIC DIAGRAM

- Notes: 1. All parts shown in this schematic are critical for safety.  
2. This schematic is only for reference.  
Avoid replacing individual parts.  
Replace the entire unit only.



## SECTION 4

### EXPLODED VIEWS AND PARTS LIST


#### SAFETY PRECAUTION

Parts identified by the  $\Delta$  symbol are critical for safety. Replace only with specified part numbers.

#### NOTE:

[M ] indicates mechanical symbol number.

#### 4.1 PACKING ASSEMBLY <M1>



# $\Delta$  REF No. PART No. PART NAME, DESCRIPTION  
\*\*\*\*\*

#### 1. PACKING ASSEMBLY (M1)

|             |               |                   |
|-------------|---------------|-------------------|
| 1           | PQ33232       | PACKING CASE      |
| 2           | PQ33231A      | CUSHION ASSY      |
| 3           | PU57777-9     | WADDING PAPER     |
| 4           | PQM30021-79   | POLY BAG          |
| 5           | PU56142-3     | PIN CORD ASSY     |
| or          | PU56142-5     | PIN CORD ASSY     |
| 6           | PU59168-3     | RF CABLE          |
| or          | PU59167-3     | RF CABLE          |
| 7           | PU80111       | S CABLE           |
| or          | PU61113       | S CABLE           |
| 8           | UM-3DJ2P      | BATTERY           |
| 9           | QPGA020-02005 | POLY BAG          |
| 10          | SE-180P-2     | S-VHS CAS TAPE    |
| $\Delta$ 11 | PU30425-1113  | INSTRUCTIONS      |
| 12          | TCN-3379      | TAPE CATALOG      |
| 13          | BT-20114      | WARRANTY CARD     |
| $\Delta$ 14 | —             | DBP INF SHEET     |
| 16          | QPGA025-03505 | POLY BAG          |
| $\Delta$ 17 | PQ10779AP     | REMOTE CONTROLLER |
| 17A         | PQ32715       | BATTERY CAP       |
| 17B         | PQ32901B      | DOOR ASSY         |
| 18          | PU60961       | PERI CABLE ASSY   |

This exploded view diagram illustrates the front panel assembly for a radio receiver. The components are shown in their relative positions and are labeled with callouts and assembly letters (A through S). The main components include:

- FRONT PANEL (1)**: The main outer casing of the front panel.
- OPERATION BOARD ASSY (22)**: The base board for the front panel controls.
- DISPLAY BOARD ASSY (27)**: The board that houses the digital display.
- STEP BOARD ASSY (37)**: A board that interfaces with the display and other controls.
- SWITCH BOARD ASSY (26)**: The board containing the various function switches.
- JACK BOARD ASSY (36)**: The board for the external speaker and antenna connections.
- CHASSIS ASSY (M3)**: The main internal chassis of the radio receiver.
- RATING LABEL (29)**: A label providing technical specifications.
- OPERATION BOARD ASSY (22)**: The base board for the front panel controls.
- COMPONENTS**: Various screws, washers, and small parts are labeled with numbers (e.g., 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15, 16, 17, 18, 19, 20, 21, 23, 24, 25, 26, 27, 28, 29, 30, 31, 32, 33, 34, 35, 36, 37, 38, 39, 40, 41, 42, 43, 44, 45, 46, 47, 48, 49, 50, 51, 52, 53, 54, 55, 56, 57, 58, 59, 60, 61, 62, 63, 64, 65, 66, 67, 68, 69, 70, 71, 72, 73, 74, 75, 76, 77, 78, 79, 80, 81, 82, 83, 84, 85, 86, 87, 88, 89, 90, 91, 92, 93, 94, 95, 96, 97, 98, 99, 100).

The diagram shows the assembly sequence from the chassis up to the final front panel assembly, including the installation of the display, switches, and controls.

\*\*\*\*\*


|              |                       |
|--------------|-----------------------|
| PQ1068H-27   | FRONT PANEL ASSY      |
| PQ32347-3    | BUTTON (POWER)        |
| PQ32499-15-9 | DISPLAY SHEET         |
| PQ43395      | HINGE (POWER)         |
| PQ43394      | IND (POWER)           |
| PQ43487      | EARTH PLATE           |
| PQ32351-11   | COVER (JACK)          |
| PQ32348-6    | COVER                 |
| PQ43363      | PLATE (MAGNET), X2    |
| PQ32395-1-2  | EARTH PLATE           |
| PQ32485      | D. WINDOW             |
| PQ43455      | BUTTON (TR)           |
| PQ32352      | GUIDE (SLIDE)         |
| PQ32353      | KNB (SLIDE), X2       |
| SDSF2608Z    | SCREW, X2             |
| SDSF2608Z    | SCREW, X2             |
| PQ32571      | PLATE (FRONT)         |
| PQ43467      | HOLDER                |
| PUJ60109     | CATCHER               |
| PQ32462M-5   | DOOR ASSY             |
| SDSF2608Z    | SCREW, X3             |
| PQ20710G-4   | DOOR ASSY (UPPER)     |
| PQ32534-4    | BUTTON (I)            |
| PQ32518-5    | BUTTON (2)            |
| PUJ5891-2    | MAGNET ASS'Y, X2      |
| PQ20686H-10  | DOOR ASSY (LOWER)     |
| PQ10545-16   | TOP COVER             |
| PQ1070E-2    | BOTTOM COVER          |
| PQ20996-2    | SHIELD PLATE (R)      |
| PQ20985-1-2  | SHIELD PLATE (L)      |
| SDSA4020M    | SCREW, X4             |
| SDSF3010M    | SCREW                 |
|              |                       |
| SDSF3008Z    | SCREW, X10            |
| PQ44602A     | FOOT ASS'Y, X2        |
| SDSF3002Z    | SCREW, X2             |
| PQ3704-1     | SPRING                |
| SDSF2608Z    | SCREW, X11            |
| PQ32519-3    | BUTTON (3)            |
| PQ32362-1-2  | SHAFT                 |
| PQ43470      | GEAR                  |
| PQ43467      | HOLDER                |
| PUJ60527     | DAMPER UNIT           |
|              |                       |
| SPSF2008M    | SCREW, X4             |
| SDSF2010Z    | SCREW, X2             |
| SDSF2608Z    | SCREW, X2             |
| PQ32556      | FPC                   |
| PQ20990A     | SIDE W. ASSY (L)      |
| PQ20990A     | SIDE W. ASSY (R)      |
| PQ21819-2-1  | CASSETTE HOUSING DOOR |
| PQ42140-1-1  | TORSION SPRING        |
| PQ2062-1-1   | FILTER (L)            |

\*\*\*\*\*


|    |               |                                  |
|----|---------------|----------------------------------|
| 1  | PQ32749       | EARTH PLATE                      |
| 2  | PDV2146A      | DRUM ASSY                        |
| 2A | PM2M119A      | UPPER DRUM ASSY                  |
| 2B | PM4M165A      | DRUM SCREW ASSY, X2              |
| 2C | PM2M119C      | LOWER DRUM MOTOR ASSY            |
| 2D | PM4M165B      | BRUSH ASSY                       |
| 3E | SPSP2602Z     | SCREW, X3, DRUM ASSY             |
| 3  | SDSP2608Z     | SPECIAL, SCREW, X2, MECHANISM    |
| 4  | PQ43831-2     | SPECIAL, SCREW, MECHANISM        |
| 5  | PQ43831-2     | SCREW, X2, CASSETTE HOUSING      |
| 6  | SDS72605Z     | CASSETTE HOUSING ASSY            |
| 7  | PUS28277H     | MOTOR ASSY                       |
| 7A | PQ42385A      | MOTOR ASSY                       |
|    | or PQ42385C   | MOTOR ASSY                       |
|    | or PQ42385B   | MOTOR ASSY                       |
|    | or PQ42385E   | MOTOR ASSY                       |
| 7B | SPSP2603Z     | SCREW, X2                        |
|    | or SPSP3003Z  | SCREW, X2                        |
| 7C | PQM40003-19   | BELT                             |
| 7D | SPSP2604Z     | SCREW                            |
| 7E | SDS72605Z     | SCREW, X2                        |
| 7F | DV710SR223M16 | VARISTOR                         |
| 8  | PQ3171-5      | DRUM SHIELD                      |
| 9  | SDS72605Z     | SCREW, X2, DRUM SHIELD           |
| 10 | PQ43831-2     | SPECIAL SCREW, X3, TRANS BRACKET |
| 11 | SDSF3008Z     | SCREW, X2, TUNER BOARD           |
| 12 | PQ43012-1-1   | EARTH PLATE, RF CONV.            |
| 13 | SDSF2608Z     | SCREW, X2, RF, CONV.             |
| 14 | GFSP2610Z     | SCREW, X2, TERMINAL BOARD        |
| 15 | GRSP2610Z     | SCREW, MAIN BOARD                |
| 16 | SDSF3008Z     | SCREW, X2, AUDIO BOARD           |
| 17 | PQ43010       | TAP TIGHT SCREW, X2, MAIN BOARD  |
| 18 | SDSF3010M     | SCREW, TERMINAL BOARD            |
| 19 | SDSF3008Z     | SCREW, X3, M. CTL. BOARD         |
| 20 | SDSF2605Z     | SCREW, RF, CONV.                 |
| 21 | SDSF3008Z     | SCREW, X2, DEMODULATOR BOARD     |
| 22 | SDSF3006Z     | SCREW, X7, D/VPT BOARD           |
| 23 | SDSF2605Z     | SCREW, X2, PHE/REC               |
| 24 | PQ3257B       | SHIELD (FAC)                     |
| 25 | PQ4368B       | SHIELD (RF)                      |
| 26 | PQ32255A      | BRACKET PLATE ASSY               |
| 27 | PQ43714       | BRACKET (FE), SERVO SUB          |
| 28 | SDSF3008Z     | SCREW, SERVO SUB                 |
| 29 | SDSF3008Z     | SCREW, X2, TIMER                 |
| 34 | SDSF3008Z     | SCREW, F.E. BOARD                |
| 35 | PM4485-4      | WIRE CLAMP                       |
| 36 | PQ33165A      | S. PLATE ASSY                    |
| 37 | PQ32568-5-3   | PLATE                            |
| 38 | PQ20950       | SHIELD PLATE                     |

**BEWARE OF BOGUS PARTS**

Parts that do not meet specifications may cause trouble in regard to safety and performance. We recommend that genuine JVC parts be used.




#### 4.4 MECHANISM ASSEMBLY (1) <M4>



| Category       | Part number  | Mark |
|----------------|--------------|------|
| Oil            | COSMO-HV56   | (A)  |
| Grease (Black) | MOS2-C       | (B)  |
| Grease (Ivory) | DAPHNE-XLA-2 | (C)  |

NOTE: The section marked in red ((A), (B) and (C)) indicate lubrication and greasing areas.

#### MECHANISM ASSEMBLY (2) <M4>



#△ REF No. PART No. PART NAME, DESCRIPTION  
\*\*\*\*\*

#### 4. MECHANISM ASSEMBLY (M4)

|      |              |                           |
|------|--------------|---------------------------|
| 1    | PQ43710A     | TENSION ARM ASSY          |
| 1A   | PQ41952-5    | SPRING                    |
| 3    | PQ41948A     | TENSION BAND ASSY         |
| 4    | SDST2606Z    | SCREW                     |
| 5    | PU60646      | FULL ERASE HEAD           |
| 6    | PQ43299A-2   | FE HEAD SUB ASSY          |
| 7    | LPSP2004Z    | SCREW                     |
| 8    | PQ41954-1-1  | TORSION SPRING            |
| 9    | PQ41955      | IMPEDANCE ROLLER          |
| 10   | PQ41956      | COLLAR                    |
| 11   | PQ41957      | LOWER FLANGE              |
| or   | PQ42958      | LOWER FLANGE              |
| 12   | PQM30018-39  | SPACER                    |
| or   | PQM30018-50  | SPACER                    |
| 13   | PQM30002-124 | COMPRESSION SPRING        |
| 14   | PQ40383      | NYLON NUT                 |
| 15   | PU60560-2    | AUDIO/CONTROL HEAD        |
| 18   | PQ42984-2    | HEAD BASE                 |
| 19   | PQ43687A     | SPECIAL SCREW, X3         |
| 20   | PU30080-49   | SPRING, X3                |
| 21   | SDSP2606Z    | SCREW, X2                 |
| 22   | PU60557-1-4  | POLE BASE ASSY (TAKE-UP)  |
| or   | PU59994      | POLE BASE ASSY (TAKE-UP)  |
| or   | PQ43148A     | POLE BASE ASSY (TAKE-UP)  |
| 23   | PU60556-1-2  | POLE BASE ASSY (SUPPLY)   |
| or   | PU59993      | POLE BASE ASSY (SUPPLY)   |
| or   | PQ43147A     | POLE BASE ASSY (SUPPLY)   |
| 24   | PQM30017-5   | SLIT WASHER, X2           |
| 25   | PU53629-3    | TAPE GUIDE                |
| 26   | PQ40268-2    | GUIDE FLANGE              |
| 27   | PQ42899-2-1  | GUIDE POLE CAP            |
| 28   | SDSP2006Z    | SCREW                     |
| △ 29 | PU60201V     | CAPSTAN MOTOR             |
| 30   | SPSP2605N    | SCREW, X3                 |
| 31   | PQ41974A-3   | REEL MOTOR BRACKET ASSY   |
| 32   | PU58645-1-4  | IDLER ARM                 |
| 33   | Q03093-834   | WASHER                    |
| 34   | PQ41976A-1   | SPRING ARM ASSY           |
| 34A  | PQ42212-1-4  | SPRING                    |
| 36   | PQM30017-22  | SLIT WASHER               |
| 37   | PQ41978      | HOLDER                    |
| 38   | SPST2606Z    | SCREW                     |
| △ 39 | PU59926V     | REEL MOTOR                |
| 40   | LPSP2604Z    | SCREW, X2                 |
| 41   | SPST2606Z    | SCREW, X2                 |
| 42   | PU59250-1-2  | REEL DISK (SUPPLY)        |
| 43   | PU58638-1-2  | REEL DISK (TAKE-UP)       |
| 44   | PQM30017-5   | SLIT WASHER, X2           |
| 45   | Q03093-828   | WASHER, X2                |
| 46   | PQ41979A-5   | LOADING ARM ASSY (SUPPLY) |
| 47   | PQ41985B-3   | LOADING ARM AY (TAKE-UP)  |
| 48   | PQ42873A     | CAM BKT ASSY              |
| 49   | PQ41994A-3   | ARM GEAR ASSY             |
| 50   | PQ20577      | CONTROL CAM               |
| 51   | PQ41996B     | MODE MOTOR ASSY           |
| or   | PQ41996C     | MODE MOTOR ASSY           |

| #△  | REF No. | PART No.     | PART NAME, DESCRIPTION   |
|-----|---------|--------------|--------------------------|
| 52  |         | PQ41988A     | WORM ASSY                |
| 53  |         | LPSP2604Z    | SCREW, X2                |
| 54  |         | PQ42001      | WINDMILL                 |
| 55  |         | PQ42002      | CLUTCH SPRING            |
| 56  |         | PQ42003      | WORM SHAFT               |
| 57  |         | PQM30017-5   | SLIT WASHER, X2          |
| 58  |         | PQM30003-20  | BELT, FOR MODE MOTOR     |
| 59  |         | PQM30018-22  | SPACER                   |
| 60  |         | SPST2606Z    | SCREW, X2                |
| 61  |         | SPST2606Z    | SCREW, X2                |
| 62  |         | LPSP2604Z    | SCREW                    |
| 63  |         | PQ42038C     | PLATE ASSY               |
| 63A |         | PQ31044-1-2  | LOCK LEVER               |
| 63B |         | PQM30001-223 | TENSION SPRING           |
| 63C |         | PQM30001-211 | TENSION SPRING           |
| 67  |         | PQM30017-28  | SLIT WASHER, X2          |
| 68  |         | PQ42006B     | PINCH ROLLER ARM ASSY    |
| 69  |         | PQM30017-28  | SLIT WASHER              |
| 70  |         | Q03093-833   | WASHER                   |
| 71  |         | PQM30001-229 | TENSION SPRING           |
| 72  |         | PQ42019B-4   | GUIDE ARM ASSY           |
| 72A |         | PQ42029      | SPRING                   |
| 74  |         | PQM30017-6   | SLIT WASHER              |
| 75  |         | PQ42019B-6   | MAIN BRAKE ASSY (SUPPLY) |
| 76  |         | PQ42020B     | MAIN BRAKE AY (TAKE-UP)  |
| 77  |         | PQM30001-216 | TENSION SPRING           |
| 78  |         | PQ42021A-3   | SUB BRAKE ASSY (SUPPLY)  |
| 78A |         | PQ42023-1-2  | TENSION SPRING           |
| 80  |         | PQ42037A-2   | SUB BRAKE ASSY (TAKE-UP) |
| 81  |         | PQM30017-6   | SLIT WASHER              |
| 82  |         | PU59925-1-1  | LED HOLDER               |
| 83  |         | SPST2606Z    | SCREW                    |
| 84  |         | SPST2606Z    | SCREW                    |
| 85  |         | PU60444      | SLIDE SWITCH             |
| 86  |         | SDSP2610Z    | SCREW                    |
| 87  |         | SDSP2606Z    | SCREW, X3                |
| 88  |         | SDST2606Z    | SCREW                    |
| 89  |         | PQ42979A-2   | HALF LOADING ARM ASSY    |
| 90  |         | PQM30017-29  | SLIT WASHER              |
| 91  |         | PQ42974A     | SLIDE CAM PLATE ASSY     |
| 91A |         | PQM30001-224 | SPRING                   |
| 93  |         | PQ31677      | H.LOADING CAM            |
| 94  |         | PQ42963      | SECOND GEAR              |
| 95  |         | PQM30017-24  | SLIT WASHER, X2          |
| 96  |         | PU61088      | REEL SENSOR (SUPPLY)     |
| 97  |         | LPSP2604Z    | SCREW                    |
| 98  |         | PQ43295A-1   | MOTOR BRAKE ASSY         |
| 98A |         | PQ43296      | SPRING                   |
| 108 |         | PU59919-1-1  | CASSETTE SWITCH          |
| 109 |         | SDST2608Z    | SCREW                    |
| 110 |         | PQ43296A     | ROLLER ASSY              |
| 111 |         | Q03093-829   | WASHER                   |
| 112 |         | PQM30017     | SLIT WASHER              |
| 120 |         | PQ43330B-2   | FE HEAD ASSY             |
| 130 |         | PQ20248H-20  | MECHANISM DECK ASSY      |



## SECTION 5 ELECTRICAL PARTS LIST

### SAFETY PRECAUTION

Parts identified by the  $\Delta$  symbol are critical for safety. Replace only with specified part numbers.

| # $\Delta$ REF No.                            | PART No.          | PART NAME, DESCRIPTION      | # $\Delta$ REF No. | PART No.       | PART NAME, DESCRIPTION              |
|-----------------------------------------------|-------------------|-----------------------------|--------------------|----------------|-------------------------------------|
| *****                                         |                   |                             |                    |                |                                     |
| <b>5. SW POWER SUPPLY BOARD ASSY (01)(02)</b> |                   |                             |                    |                |                                     |
| PWBA                                          | PB10313A-01       | SWITCH/REGULATOR BOARD ASSY | D1                 | 10E6-F2        | DIODE                               |
| $\Delta$ BRT1                                 | PQ20946           | TRANS BRACKET               | D2                 | 10E6-F2        | DIODE                               |
| BRT2                                          | PQ33112           | BASE (FAN)                  | D3                 | 10E6-F2        | DIODE                               |
|                                               |                   |                             | D4                 | 10E6-F2        | DIODE                               |
| CV1                                           | PQ33111           | COVER (FAN)                 | D5                 | RU1A           | FR DIODE                            |
|                                               |                   |                             | D6                 | RU1A           | FR DIODE                            |
| MT1                                           | PELM0149          | FAN MOTOR                   | D8                 | AU01Z          | FR DIODE                            |
|                                               |                   |                             |                    | or ERA48-02-T  | FR DIODE                            |
| $\Delta$ POC1                                 | QMP4019-200       | POWER CORD                  | D9                 | AU01Z          | FR DIODE                            |
| $\Delta$ AO1                                  | QMC9021-001       | AC OUTLET                   | D10                | AU01Z          | FR DIODE                            |
| $\Delta$ HD1                                  | QHS3771-108       | STRAIN RELIEF               | D11                | F6P20F         | FR DIODE                            |
| $\Delta$ HS1                                  | PQ43230           | HEAT SINK (2)               |                    | or FML-12S     | FR DIODE                            |
|                                               |                   |                             | D12                | F5KQ40B        | BARRIER DIODE                       |
| SCW1                                          | DPSP3006Z         | ASSY SCREW, X2              |                    | or FMB-24      | BARRIER DIODE                       |
| SCW2                                          | DPSP3012Z         | SCREW, X2                   | D13                | AUG1Z          | FR DIODE                            |
| SCW3                                          | SDST3006Z         | SCREW, X3                   |                    | or ERA48-02-T  | FR DIODE                            |
| SCW4                                          | SDSG3006Z         | SCREW, X3                   | D14                | AU01Z          | FR DIODE                            |
| SCW5                                          | SDSG3006Z         | SCREW, X2, FOR Q21, IC101   |                    | or ERA48-02-T  | FR DIODE                            |
| SCW6                                          | PQ44355           | SPECIAL SCREW, X2, FOR FAN  | D15                | RD16S-T1B2     | ZENER DIODE                         |
| SCW7                                          | PQ44355-2         | SPECIAL SCREW, X2, FOR FAN  |                    | or UZ16BSB     | ZENER DIODE                         |
| SLD1                                          | PQ32071           | SHILD CASE (2)              | D28                | AU01           | FR DIODE                            |
| $\Delta$ SPC1                                 | PQ43773           | SHEET (AC)                  | R1                 | QRZ0078-2R2    | W.W.RESISTOR 2.2 $\Omega$           |
| SPC2                                          | PQ44361           | SPACER (FAN), X2            | R2                 | QRD181J-564    | RESISTOR 560K $\Omega$ , 1/8W       |
|                                               |                   |                             | R3                 | QRD181J-334    | RESISTOR 330K $\Omega$ , 1/8W       |
| $\Delta$ F1                                   | QMF51E2-1R25      | FUSE 1.25A, AC250V          | R4                 | QRG028J-104    | OMF RESISTOR 100K $\Omega$ , 2W     |
| $\Delta$                                      | or QMF51E2-1R25J1 | FUSE 1.25A, AC250V          | R5                 | QRD161J-473    | RESISTOR 47K $\Omega$ , 1/8W        |
| $\Delta$ F2                                   | QMF51E2-2R0       | FUSE 2.0A, AC250V           | R6                 | QRG029J-201    | OMF RESISTOR 200 $\Omega$ , 2W      |
| $\Delta$                                      | or QMF51E2-2R0J1  | FUSE 2.0A, AC250V           | R7                 | QRZ0078-R39    | WW RESISTOR 0.39 $\Omega$           |
|                                               |                   |                             | R9                 | QVZ3507-101    | V RESISTOR, SR 15V ADJ 100 $\Omega$ |
| <b>— SWITCHING BOARD ASSEMBLY (01) —</b>      |                   |                             |                    |                |                                     |
| PWBA1                                         | PB10313A1         | SWITCH BOARD ASSEMBLY (01)  | R11                | QRD161J-333    | RESISTOR 33K $\Omega$ , 1/8W        |
| IC1                                           | STR-D1706         | IC                          | $\Delta$ C1        | QFZ9022-823    | MM CAPACITOR 0.082 $\mu$ F          |
|                                               |                   |                             | $\Delta$ C3        | QCZ9016-221K   | CAPACITOR 220PF                     |
|                                               |                   |                             | $\Delta$ C4        | QCZ9016-221K   | CAPACITOR 220PF                     |
|                                               |                   |                             | $\Delta$ C5        | QCZ9016-221K   | CAPACITOR 220PF                     |
|                                               |                   |                             | $\Delta$ C6        | QCZ9016-221K   | CAPACITOR 220PF                     |
|                                               |                   |                             | $\Delta$ C7        | QCZ9016-222M   | CAPACITOR 0.0022 $\mu$ F            |
|                                               |                   |                             | $\Delta$           | or QCZ9048-222 | CAPACITOR 0.0022 $\mu$ F            |
|                                               |                   |                             | $\Delta$ C8        | QCZ9016-222M   | CAPACITOR 0.0022 $\mu$ F            |
|                                               |                   |                             | $\Delta$           | or QCZ9048-222 | CAPACITOR 0.0022 $\mu$ F            |
|                                               |                   |                             | C9                 | QETG1JM-475    | E CAPACITOR 4.7 $\mu$ F, 63V        |
|                                               |                   |                             | C10                | PECA0732-167   | E CAPACITOR                         |
|                                               |                   |                             | C11                | QCR13AK-472    | CAPACITOR 0.0047 $\mu$ F, 1000V     |
|                                               |                   |                             | C12                | QCZ0213-101Z   | CAPACITOR 100PF                     |
|                                               |                   |                             | C13                | QFL41HJ-222    | M CAPACITOR 0.0022 $\mu$ F, 50V     |
|                                               |                   |                             | C14                | QFV41HJ-474    | -TF CAPACITOR 0.47 $\mu$ F, 50V     |



| # | REF No. | PART No.       | PART NAME, DESCRIPTION         |
|---|---------|----------------|--------------------------------|
|   |         | or QFV11HJ-474 | TF CAPACITOR 0.47 $\mu$ F, 50V |
|   | C15     | QEZ0108-187Z   | E CAPACITOR 180 $\mu$ F        |
| △ | C16     | QCZ9016-101K   | CAPACITOR 100PF                |
| △ | C17     | QCZ9016-101K   | CAPACITOR 100PF                |
| △ | C19     | QCZ9016-101K   | CAPACITOR 100PF                |
| △ | C20     | QCZ9016-101K   | CAPACITOR 100PF                |
|   | C31     | QEMB1EM-228    | E CAPACITOR 2200 $\mu$ F, 25V  |
|   | C32     | QEMB1AM-398    | E CAPACITOR 3900 $\mu$ F, 10V  |
|   | C33     | QEZ0104-476Z   | E CAPACITOR 47 $\mu$ F         |
|   | C34     | QEZ0107-476Z   | E CAPACITOR 47 $\mu$ F         |
|   | C35     | QETB1EM-477    | E CAPACITOR 470 $\mu$ F, 25V   |
|   | C36     | QETB1EM-108    | E CAPACITOR 1000 $\mu$ F, 25V  |
|   | C37     | QETB1AM-108    | E CAPACITOR 1000 $\mu$ F, 10V  |
|   | C38     | QETC1JM-226    | E CAPACITOR 22 $\mu$ F, 63V    |
|   | C39     | QETC1HM-226    | E CAPACITOR 22 $\mu$ F, 50V    |
|   | C40     | QFL41HJ-102    | M CAPACITOR 0.001 $\mu$ F, 50V |
|   | C41     | QFL41HJ-102    | M CAPACITOR 0.001 $\mu$ F, 50V |
|   | C42     | QFL41HJ-472    | CAPACITOR 0.0047 $\mu$ F, 50V  |
|   | L11     | PU60943-330K   | COIL 33 $\mu$ H                |
|   | L12     | PU60944-330K   | COIL 33 $\mu$ H                |
|   | L13     | PU60944-330K   | COIL 33 $\mu$ H                |
|   | L14     | PU48530-101K   | COIL 100 $\mu$ H               |
|   | L15     | PU48530-101K   | COIL 100 $\mu$ H               |
|   | L16     | PU48530-8R2K   | COIL 8.2 $\mu$ H               |
|   | L17     | PU48530-8R2K   | COIL 8.2 $\mu$ H               |

|   |      |             |                         |
|---|------|-------------|-------------------------|
| △ | T1   | PU60683-2   | SW TRANS                |
| △ | HS1  | PQ44322-1-1 | HEAT SINK, FOR D11, D12 |
|   | HS2  | PU60798     | HEAT SINK               |
| △ | LF2  | PU60347     | LINE FILTER             |
|   | SLD1 | PQ32558-1-1 | SHIELD CASE(1)          |
|   | CN1  | PU58844-10  | CAP HOUSING             |
|   | CN2  | PU58844-3   | CAP HOUSING             |
|   | CN17 | PU58844-2   | CAP HOUSING             |

# — REGULATOR BOARD ASSEMBLY (02) —

|       |            |                               |
|-------|------------|-------------------------------|
| PW5A2 | PB10313A2  | REGULATOR BOARD ASSEMBLY (02) |
| IC2   | BA10324    | IC                            |
| IC101 | M54647L    | IC                            |
| Q11   | 2SD1856    | TRANSISTOR                    |
|       | or 2SD1796 | TRANSISTOR                    |
| Q12   | 2SC1740S   | TRANSISTOR                    |
| Q13   | 2SD1856    | TRANSISTOR                    |

| #   | REF No. | PART No.        | PART NAME, DESCRIPTION        |
|-----|---------|-----------------|-------------------------------|
|     |         | or 2SD1796      | TRANSISTOR                    |
| Q14 |         | 2SD1856         | TRANSISTOR                    |
|     |         | or 2SD1796      | TRANSISTOR                    |
| Q15 |         | 2SD1856         | TRANSISTOR                    |
|     |         | or 2SD1796      | TRANSISTOR                    |
| Q16 |         | 2SA720          | TRANSISTOR                    |
| Q17 |         | 2SA720          | TRANSISTOR                    |
| Q18 |         | DTA114ES        | TRANSISTOR                    |
| Q19 |         | DTB123ES        | TRANSISTOR                    |
| Q20 |         | 2SC1740S        | TRANSISTOR                    |
| Q21 |         | 2SD1856         | TRANSISTOR                    |
|     |         | or 2SD1796      | TRANSISTOR                    |
| Q22 |         | DTB114ES        | TRANSISTOR                    |
| Q23 |         | DTC114ES        | TRANSISTOR                    |
| Q24 |         | DTC114ES        | TRANSISTOR                    |
| D16 |         | RD6.2ES-T1B3    | ZENER DIODE                   |
|     |         | or UZ6.2BSC     | ZENER DIODE                   |
| D17 |         | RD5.1ES-T1B2    | ZENER DIODE                   |
|     |         | or UZ5.1BSC     | ZENER DIODE                   |
| D18 |         | 1SS133          | DIODE                         |
|     |         | or MA165        | DIODE                         |
| D19 |         | HZ6B1TE         | DIODE                         |
|     |         | or HZ6B1TJ      | DIODE                         |
| D20 |         | RD13ES-T1B3     | DIODE                         |
|     |         | or UZ13BSC      | ZENER DIODE                   |
| D21 |         | HZS33EB1        | ZENER DIODE                   |
|     |         | or MTZ33AT-77   | ZENER DIODE                   |
| D22 |         | 1SS133          | DIODE                         |
|     |         | or MA165        | DIODE                         |
| D23 |         | 1SS133          | DIODE                         |
|     |         | or MA165        | DIODE                         |
| D24 |         | 1SS133          | DIODE                         |
|     |         | or MA165        | DIODE                         |
| D25 |         | 1SS133          | DIODE                         |
|     |         | or MA165        | DIODE                         |
| D26 |         | 1SS133          | DIODE                         |
|     |         | or MA165        | DIODE                         |
| D27 |         | RD20ES-T1B2     | ZENER DIODE                   |
|     |         | or MTZ20BT-77   | ZENER DIODE                   |
| D30 |         | 11ES2           | DIODE                         |
| D31 |         | 1SS133          | DIODE                         |
|     |         | or MA165        | DIODE                         |
| D32 |         | 1SS133          | DIODE                         |
|     |         | or MA165        | DIODE                         |
| D33 |         | 1SS133          | DIODE                         |
|     |         | or MA165        | DIODE                         |
| D34 |         | UZ3.3BSA        | ZENER DIODE                   |
|     |         | or RD3.3ES-T1B1 | ZENER DIODE                   |
| D35 |         | 1SS133          | DIODE                         |
|     |         | or MA165        | DIODE                         |
| D36 |         | 11ES2           | DIODE                         |
| D37 |         | 1SS133          | DIODE                         |
|     |         | or MA165        | DIODE                         |
| R14 |         | QRD161J-222     | RESISTOR 2.2K $\Omega$ , 1/6W |
| R15 |         | QRD161J-362     | RESISTOR 3.6K $\Omega$ , 1/6W |

| #△ REF No. | PART No.     | PART NAME, DESCRIPTION |              | #△ REF No. | PART No.     | PART NAME, DESCRIPTION     |              |
|------------|--------------|------------------------|--------------|------------|--------------|----------------------------|--------------|
| R16        | QRD161J-472  | RESISTOR               | 4.7KΩ, 1/8W  | C54        | QETCIHM-106  | E CAPACITOR                | 10μF, 50V    |
| R17        | QRD161J-102  | RESISTOR               | 1KΩ, 1/8W    | C55        | QFN31HJ-102  | M CAPACITOR                | 0.001μF, 50V |
| R18        | QRD161J-622  | RESISTOR               | 6.2KΩ, 1/8W  | C56        | QFN31HJ-103  | M CAPACITOR                | 0.01μF, 50V  |
| R19        | QRD161J-472  | RESISTOR               | 4.7KΩ, 1/8W  | C57        | QETCIAM-107  | E CAPACITOR                | 100μF, 10V   |
| R20        | QRD161J-102  | RESISTOR               | 1KΩ, 1/8W    | C58        | QETCIHM-226  | E CAPACITOR                | 22μF, 50V    |
| R21        | QRD161J-153  | RESISTOR               | 15KΩ, 1/8W   | C59        | QETCIHM-226  | E CAPACITOR                | 22μF, 50V    |
| R22        | QRD161J-472  | RESISTOR               | 4.7KΩ, 1/8W  | C60        | QETCIHM-226  | E CAPACITOR                | 22μF, 50V    |
| R23        | QRD161J-102  | RESISTOR               | 1KΩ, 1/8W    | C63        | QETCIHM-107  | E CAPACITOR                | 100μF, 16V   |
| R24        | QRD161J-102  | RESISTOR               | 1KΩ, 1/8W    | C64        | QETCIHM-106  | E CAPACITOR                | 10μF, 50V    |
| R25        | QRD161J-153  | RESISTOR               | 15KΩ, 1/8W   | C101       | QETCIEM-476  | E CAPACITOR                | 47μF, 25V    |
| R26        | QVZ3244-222  | V RESISTOR, SWD 5V ADJ | 2.2KΩ        | C102       | QETCIHM-105  | E CAPACITOR                | 1μF, 50V     |
| R27        | QRD161J-223  | RESISTOR               | 22KΩ, 1/8W   |            |              |                            |              |
| R28        | QRD161J-222  | RESISTOR               | 2.2KΩ, 1/8W  |            |              |                            |              |
| R29        | QRD161J-103  | RESISTOR               | 10KΩ, 1/8W   |            |              |                            |              |
| R30        | QRD161J-392  | RESISTOR               | 3.9KΩ, 1/8W  | △ RY1      | PU59457      | RELAY                      |              |
| R31        | QRD161J-102  | RESISTOR               | 1KΩ, 1/8W    | △ CL1      | PU57505      | FUSE CLIP, X4, FOR F1, F2  |              |
| R32        | QRD161J-472  | RESISTOR               | 4.7KΩ, 1/8W  | HS1        | PQ43701-1-1  | HEAT SINK                  |              |
| R33        | QRD161J-331  | RESISTOR               | 330Ω, 1/8W   | △ LF1      | PU60020      | LINE FILTER                |              |
| R34        | QRD161J-272  | RESISTOR               | 2.7KΩ, 1/8W  | △ TAB1     | A74316       | TAB, X2                    |              |
| △ R35      | QRZ0077-220X | FUSIBLE RESISTOR       | 22Ω          | TP1        | PU55774      | TEST PIN, X4, (TP1-3, GND) |              |
| △ R36      | QRZ0077-101X | FUSIBLE RESISTOR       | 10Ω          | CN4        | PU58844-102  | CAP HOUSING                |              |
| R37        | QRD161J-103  | RESISTOR               | 10KΩ, 1/8W   | CN5        | PU58844-102R | CAP HOUSING                |              |
| R38        | QRD161J-222  | RESISTOR               | 2.2KΩ, 1/8W  | CN6        | PU58844-107  | CAP HOUSING                |              |
| R39        | QRD161J-751  | RESISTOR               | 750Ω, 1/8W   | CN7        | PU59555-4    | CAP HOUSING                |              |
| R40        | QRD161J-221  | RESISTOR               | 220Ω, 1/8W   | CN8        | PU59555-108  | CAP HOUSING                |              |
| R41        | QRD161J-222  | RESISTOR               | 2.2KΩ, 1/8W  | CN9        | PU58844-103R | CAP HOUSING                |              |
| R43        | QRD161J-392  | RESISTOR               | 3.9KΩ, 1/8W  | CN10       | PU58844-103R | CAP HOUSING                |              |
| R44        | QRD161J-1R0  | RESISTOR               | 1.0Ω, 1/8W   | CN11       | PU58844-103Y | CAP HOUSING                |              |
| R45        | QRD161J-1R0  | RESISTOR               | 1.0Ω, 1/8W   | CN12       | PU59555-108  | CAP HOUSING                |              |
| R46        | QRD161J-1R0  | RESISTOR               | 1.0Ω, 1/8W   | CN14       | PU58844-106  | CAP HOUSING                |              |
| R47        | QRD161J-1R0  | RESISTOR               | 1.0Ω, 1/8W   | CN15       | PU58844-3    | CAP HOUSING                |              |
| R48        | QRD161J-1R0  | RESISTOR               | 1.0Ω, 1/8W   | CN16       | PU58844-2    | CAP HOUSING                |              |
| R49        | QRD161J-1R0  | RESISTOR               | 1.0Ω, 1/8W   | △ CP1      | ICP-N38      | CIRCUIT PROTECTOR          |              |
| R50        | QRD161J-1R0  | RESISTOR               | 1.0Ω, 1/8W   | △          | or ICP-F38   | CIRCUIT PROTECTOR          |              |
| R51        | QRD161J-1R0  | RESISTOR               | 1.0Ω, 1/8W   | △ CP2      | ICP-N25      | CIRCUIT PROTECTOR          |              |
| R52        | QRD161J-562  | RESISTOR               | 5.6KΩ, 1/8W  | △          | or ICP-F25   | CIRCUIT PROTECTOR          |              |
| R53        | QRD161J-562  | RESISTOR               | 5.6KΩ, 1/8W  | △ CP3      | ICP-N20      | CIRCUIT PROTECTOR          |              |
| R54        | QRD161J-103  | RESISTOR               | 10KΩ, 1/8W   | △          | or ICP-F20   | CIRCUIT PROTECTOR          |              |
| R55        | QRD161J-102  | RESISTOR               | 1KΩ, 1/8W    | △ CP4      | ICP-N38      | CIRCUIT PROTECTOR          |              |
| R56        | QRD12U-560   | RESISTOR               | 56Ω, 1/2W    | △          | or ICP-F38   | CIRCUIT PROTECTOR          |              |
| R57        | QRD161J-103  | RESISTOR               | 10KΩ, 1/8W   | △ CP101    | ICP-F25      | CIRCUIT PROTECTOR          |              |
| R58        | QRD161J-103  | RESISTOR               | 10KΩ, 1/8W   |            |              |                            |              |
| R59        | QRD161J-103  | RESISTOR               | 10KΩ, 1/8W   |            |              |                            |              |
| R60        | QRD161J-102  | RESISTOR               | 1KΩ, 1/8W    |            |              |                            |              |
| C43        | QFN31HJ-102  | M CAPACITOR            | 0.001μF, 50V |            |              |                            |              |
| C44        | QETCIAM-107  | E CAPACITOR            | 100μF, 16V   |            |              |                            |              |
| C45        | QETCIHM-106  | E CAPACITOR            | 10μF, 50V    |            |              |                            |              |
| C46        | QFN31HJ-102  | M CAPACITOR            | 0.001μF, 50V |            |              |                            |              |
| C47        | QFN31HJ-102  | M CAPACITOR            | 0.001μF, 50V |            |              |                            |              |
| C48        | QETCIAM-107  | E CAPACITOR            | 100μF, 16V   |            |              |                            |              |
| C49        | QFN31HJ-102  | M CAPACITOR            | 0.001μF, 50V |            |              |                            |              |
| C50        | QFN31HJ-102  | M CAPACITOR            | 0.001μF, 50V |            |              |                            |              |
| C51        | QETCIAM-107  | E CAPACITOR            | 100μF, 10V   |            |              |                            |              |
| C52        | QETCIHM-476  | E CAPACITOR            | 47μF, 50V    |            |              |                            |              |
| C53        | QETCIAM-107  | E CAPACITOR            | 100μF, 16V   |            |              |                            |              |

| #     | REF No. | PART No. | PART NAME, DESCRIPTION |
|-------|---------|----------|------------------------|
| ***** |         |          |                        |

## 6. MECHACON BOARD ASSEMBLY (04)

| PWBA | PB10310A-02 | MECHACON BOARD ASSEMBLY |
|------|-------------|-------------------------|
|------|-------------|-------------------------|

|     |               |    |
|-----|---------------|----|
| IC1 | M50938A-322SP | IC |
| IC2 | TA8405S       | IC |
| IC4 | BA6222        | IC |
| IC5 | M50255P       | IC |

|    |              |            |
|----|--------------|------------|
| Q1 | 2SD1468S(RS) | TRANSISTOR |
| Q2 | DTC144ES     | TRANSISTOR |
| Q3 | DTC144ES     | TRANSISTOR |

|     |           |             |
|-----|-----------|-------------|
| D1  | HZ34.3EB2 | ZENER DIODE |
| D2  | MA165     | DIODE       |
|     | or 1SS133 | DIODE       |
| D3  | MA165     | DIODE       |
|     | or 1SS133 | DIODE       |
| D4  | MA165     | DIODE       |
|     | or 1SS133 | DIODE       |
| D5  | HZ37.5EB2 | ZENER DIODE |
| D6  | MA165     | DIODE       |
|     | or 1SS133 | DIODE       |
| D7  | MA165     | DIODE       |
|     | or 1SS133 | DIODE       |
| D8  | MA165     | DIODE       |
|     | or 1SS133 | DIODE       |
| D9  | MA165     | DIODE       |
|     | or 1SS133 | DIODE       |
| D10 | MA165     | DIODE       |
|     | or 1SS133 | DIODE       |
| D11 | MA165     | DIODE       |
|     | or 1SS133 | DIODE       |

|     |             |          |                      |
|-----|-------------|----------|----------------------|
| R1  | QRD161J-162 | RESISTOR | 1.5K $\Omega$ , 1/6W |
| R2  | QRD161J-332 | RESISTOR | 3.3K $\Omega$ , 1/6W |
| R3  | QRD161J-122 | RESISTOR | 1.2K $\Omega$ , 1/6W |
| R4  | QRD161J-823 | RESISTOR | 82K $\Omega$ , 1/6W  |
| R5  | QRD161J-471 | RESISTOR | 470 $\Omega$ , 1/6W  |
| R6  | QRD161J-102 | RESISTOR | 1K $\Omega$ , 1/6W   |
| R7  | QRD161J-102 | RESISTOR | 1K $\Omega$ , 1/6W   |
| R8  | QRD161J-102 | RESISTOR | 1K $\Omega$ , 1/6W   |
| R9  | QRD161J-103 | RESISTOR | 10K $\Omega$ , 1/6W  |
| R10 | QRD161J-472 | RESISTOR | 4.7K $\Omega$ , 1/6W |

|     |             |          |                      |
|-----|-------------|----------|----------------------|
| R11 | QRD161J-472 | RESISTOR | 4.7K $\Omega$ , 1/6W |
| R12 | QRD161J-472 | RESISTOR | 4.7K $\Omega$ , 1/6W |
| R13 | QRD161J-472 | RESISTOR | 4.7K $\Omega$ , 1/6W |
| R14 | QRD161J-472 | RESISTOR | 4.7K $\Omega$ , 1/6W |
| R15 | QRD161J-472 | RESISTOR | 4.7K $\Omega$ , 1/6W |
| R16 | QRD161J-103 | RESISTOR | 10K $\Omega$ , 1/6W  |
| R17 | QRD161J-103 | RESISTOR | 10K $\Omega$ , 1/6W  |
| R18 | QRD161J-103 | RESISTOR | 10K $\Omega$ , 1/6W  |
| R19 | QRD161J-333 | RESISTOR | 33K $\Omega$ , 1/6W  |

| #   | REF No.     | PART No. | PART NAME, DESCRIPTION |
|-----|-------------|----------|------------------------|
| R20 | QRD161J-472 | RESISTOR | 4.7K $\Omega$ , 1/6W   |

|     |             |          |                      |
|-----|-------------|----------|----------------------|
| R21 | QRD161J-472 | RESISTOR | 4.7K $\Omega$ , 1/6W |
| R22 | QRD161J-472 | RESISTOR | 4.7K $\Omega$ , 1/6W |
| R23 | QRD161J-472 | RESISTOR | 4.7K $\Omega$ , 1/6W |
| R24 | QRD161J-472 | RESISTOR | 4.7K $\Omega$ , 1/6W |
| R25 | QRD161J-472 | RESISTOR | 4.7K $\Omega$ , 1/6W |
| R26 | QRD161J-472 | RESISTOR | 4.7K $\Omega$ , 1/6W |
| R27 | QRD161J-472 | RESISTOR | 4.7K $\Omega$ , 1/6W |
| R28 | QRD161J-472 | RESISTOR | 4.7K $\Omega$ , 1/6W |
| R29 | QRD161J-472 | RESISTOR | 4.7K $\Omega$ , 1/6W |
| R30 | QRD161J-124 | RESISTOR | 120K $\Omega$ , 1/6W |

|     |             |          |                      |
|-----|-------------|----------|----------------------|
| R31 | QRD161J-124 | RESISTOR | 120K $\Omega$ , 1/6W |
| R32 | QRD161J-333 | RESISTOR | 33K $\Omega$ , 1/6W  |
| R33 | QRD161J-821 | RESISTOR | 820 $\Omega$ , 1/6W  |
| R34 | QRD161J-331 | RESISTOR | 330 $\Omega$ , 1/6W  |
| R35 | QRD161J-822 | RESISTOR | 8.2K $\Omega$ , 1/6W |
| R36 | QRD161J-103 | RESISTOR | 10K $\Omega$ , 1/6W  |
| R37 | QRD161J-472 | RESISTOR | 4.7K $\Omega$ , 1/6W |
| R38 | QRD161J-472 | RESISTOR | 4.7K $\Omega$ , 1/6W |
| R39 | QRD161J-333 | RESISTOR | 33K $\Omega$ , 1/6W  |
| R40 | QRD161J-333 | RESISTOR | 33K $\Omega$ , 1/6W  |

|     |             |          |                     |
|-----|-------------|----------|---------------------|
| R41 | QRD161J-105 | RESISTOR | 1M $\Omega$ , 1/6W  |
| R42 | QRD161J-561 | RESISTOR | 560 $\Omega$ , 1/6W |
| R43 | QRD161J-561 | RESISTOR | 560 $\Omega$ , 1/6W |

|     |                |                  |
|-----|----------------|------------------|
| RA1 | QRB049J-103C   | RESISTOR ARRAY   |
|     | or QRB049J-103 | RESISTOR ARRAY   |
|     | or QRB047J-103 | RESISTOR ARRAY   |
| RA2 | QRB049J-472C   | RESISTOR ARRAY   |
|     | or QRB047J-472 | NETWORK RESISTOR |
|     | or QRB049J-472 | RESISTOR ARRAY   |
| RA3 | QRB049J-103C   | RESISTOR ARRAY   |
|     | or QRB047J-103 | RESISTOR ARRAY   |
|     | or QRB049J-103 | RESISTOR ARRAY   |

|     |             |             |                    |
|-----|-------------|-------------|--------------------|
| C1  | QCQB1EZ-223 | CAPACITOR   | 0.022 $\mu$ F, 25V |
| C2  | QETCIEM-335 | E CAPACITOR | 3.3 $\mu$ F, 25V   |
| C5  | QETCIEM-106 | E CAPACITOR | 10 $\mu$ F, 25V    |
| C6  | QETCIEM-106 | E CAPACITOR | 10 $\mu$ F, 25V    |
| C7  | QCQB1EZ-223 | CAPACITOR   | 0.022 $\mu$ F, 25V |
| C8  | QETCIEM-475 | E CAPACITOR | 4.7 $\mu$ F, 25V   |
| C9  | QCQB1EZ-223 | CAPACITOR   | 0.022 $\mu$ F, 25V |
| C10 | QCCH1CK-104 | CAPACITOR   | 0.1 $\mu$ F, 16V   |

|     |             |           |                     |
|-----|-------------|-----------|---------------------|
| C11 | QCXB1CM-222 | CAPACITOR | 0.0022 $\mu$ F, 16V |
| C12 | QCXB1CM-222 | CAPACITOR | 0.0022 $\mu$ F, 16V |

|    |              |      |              |
|----|--------------|------|--------------|
| L1 | PU53223-R22G | COIL | 0.22 $\mu$ H |
|----|--------------|------|--------------|

|     |              |                |
|-----|--------------|----------------|
| CF1 | PU60414      | CERAMIC FILTER |
|     | or PU60942-Z | CERAMIC FILTER |

|    |           |               |
|----|-----------|---------------|
| K1 | PU60281-5 | FERRITE BEADS |
| K2 | PU60281-5 | FERRITE BEADS |

| #△ REF No. | PART No.                              | PART NAME, DESCRIPTION         |
|------------|---------------------------------------|--------------------------------|
| WR1        | PW30112-LOAF6AH<br>or PW30117-LOAG6AH | PARALLEL WIRE<br>PARALLEL WIRE |
| CN1        | PU59934-17                            | WIRE HOLDER                    |
| CN2        | PU58844-6                             | CAP HOUSING                    |
| CN4        | PU58930-14                            | CAP HOUSING                    |
| CN5        | PU58930-12                            | CAP HOUSING                    |
| CN6        | PU59555-10                            | CAP HOUSING                    |
| CN8        | PU59555-8                             | CAP HOUSING                    |
| CN12       | PU59555-7                             | CAP HOUSING                    |
| CN13       | PU58844-3                             | CAP HOUSING                    |
| CN14       | PU58928-18                            | CAP HOUSING                    |
| CN15       | PU58926-13                            | CAP HOUSING                    |
| CN16       | PU58928-16                            | CAP HOUSING                    |
| CN17       | PU58928-15                            | CAP HOUSING                    |
| CN18       | PU59555-6                             | CAP HOUSING                    |
| CN20       | PU59555-6                             | CAP HOUSING                    |

\*\*\*\*\*

## 7. VIDEO BOARD ASSEMBLY (05)

|      |             |                      |
|------|-------------|----------------------|
| PWBA | PB10154J    | VIDEO BOARD ASSEMBLY |
| CL1  | PU59729-2   | WIRE CLAMP           |
| CL2  | PU55379     | MINI CLAMP           |
| HN1  | PU59018-1-2 | PWB HINGE, X2        |
| SPC1 | PU60010     | SPACER, X4           |
| TP1  | PU57545     | TEST PIN, X38        |
| TP2  | PU58008     | TEST-PIN             |
| CN1  | PU58844-2   | CAP HOUSING          |
| CN2  | PU58844-6   | CAP HOUSING          |
| CN3  | PU58844-3   | CAP HOUSING          |
| CN4  | PU59555-10  | CAP HOUSING          |
| CN5  | PU58844-8   | CAP HOUSING          |
| CN6  | PU58844-4   | CAP HOUSING          |
| CN7  | PU58844-5   | CAP HOUSING          |
| CN8  | PU58844-5   | CAP HOUSING          |
| CN9  | PU58844-6   | CAP HOUSING          |
| CN10 | PU58844-4   | CAP HOUSING          |
| CN12 | PU59555-5   | CAP HOUSING          |
| CN14 | PU58844-2   | CAP HOUSING          |

## - Y SECTION -

|     |           |                     |
|-----|-----------|---------------------|
| IC1 | PB20291A  | Y MODULE BOARD ASSY |
| IC2 | NJM2234D  | IC                  |
| IC3 | M51288SP  | IC                  |
| IC4 | HA118070  | IC                  |
| IC5 | NJM2233AD | IC                  |

| #△ REF No. | PART No.      | PART NAME, DESCRIPTION |
|------------|---------------|------------------------|
| IC6        | PB20290A-02   | JOG MODULE BOARD ASSY  |
| IC7        | M52055P       | IC                     |
| IC8        | NJM2233AD     | IC                     |
| IC9        | PB20285A      | Y MODULE BOARD ASSY    |
| IC10       | PB20298A      | Y MODULE BOARD ASSY    |
| IC11       | PB20286A-02   | YNR MODULE BOARD ASSY  |
| IC12       | VC2063S       | IC                     |
| IC13       | TC74HC04AP    | IC                     |
| or         | MC74HC04AN    | IC                     |
| IC14       | AN6041        | IC                     |
| IC15       | BA7021        | IC                     |
| IC16       | BU4066B       | IC                     |
| Q1         | 2SC1740S(QRS) | TRANSISTOR             |
| Q2         | DTC124ES      | TRANSISTOR             |
| Q3         | DTC124ES      | TRANSISTOR             |
| Q4         | 2SC1740S(QRS) | TRANSISTOR             |
| Q5         | 2SC1740S(QRS) | TRANSISTOR             |
| Q6         | DTC124ES      | TRANSISTOR             |
| Q7         | DTC124ES      | TRANSISTOR             |
| Q8         | 2SA933S       | TRANSISTOR             |
| Q9         | 2SA933S       | TRANSISTOR             |
| Q10        | 2SC1740S(QRS) | TRANSISTOR             |
| Q11        | 2SA933S       | TRANSISTOR             |
| Q12        | 2SC1740S(QRS) | TRANSISTOR             |
| Q13        | 2SC1740S(QRS) | TRANSISTOR             |
| Q14        | 2SA933S       | TRANSISTOR             |
| Q15        | 2SA933S       | TRANSISTOR             |
| Q16        | 2SA933S       | TRANSISTOR             |
| Q17        | DTC124ES      | TRANSISTOR             |
| Q18        | 2SK361(C)     | FE TRANSISTOR          |
| Q19        | 2SA933S       | TRANSISTOR             |
| Q20        | 2SC1740S(QRS) | TRANSISTOR             |
| Q21        | 2SC1740S(QRS) | TRANSISTOR             |
| Q22        | DTC144ES      | TRANSISTOR             |
| Q23        | 2SA933S       | TRANSISTOR             |
| Q24        | 2SA933S       | TRANSISTOR             |
| Q25        | 2SA933S       | TRANSISTOR             |
| Q26        | 2SC1740S(QRS) | TRANSISTOR             |
| Q27        | DTC124ES      | TRANSISTOR             |
| Q28        | DTC124ES      | TRANSISTOR             |
| Q29        | DTA124ES      | TRANSISTOR             |
| Q30        | 2SC1740S(QRS) | TRANSISTOR             |
| Q31        | 2SC1740S(QRS) | TRANSISTOR             |
| Q32        | DTA124ES      | TRANSISTOR             |
| Q33        | 2SA933S       | TRANSISTOR             |
| Q34        | 2SC1740S(RS)  | TRANSISTOR             |
| Q35        | 2SB861Q, R    | TRANSISTOR             |
| Q36        | DTA124ES      | TRANSISTOR             |
| Q37        | DTA124ES      | TRANSISTOR             |
| Q38        | DTC124ES      | TRANSISTOR             |
| Q39        | 2SC3313CTA    | TRANSISTOR             |
| Q40        | 2SC3313CTA    | TRANSISTOR             |
| Q41        | 2SC1740S(QRS) | TRANSISTOR             |
| Q42        | 2SC2647C      | TRANSISTOR             |
| Q43        | 2SC2647C      | TRANSISTOR             |

| #△ | REF No. | PART No.      | PART NAME, DESCRIPTION |
|----|---------|---------------|------------------------|
|    | Q45     | 2SC1740S(QRS) | TRANSISTOR             |
|    | Q46     | 2SA933S       | TRANSISTOR             |
|    | Q47     | 2SC1740S(QRS) | TRANSISTOR             |
|    | Q48     | 2SC1740S(QRS) | TRANSISTOR             |
|    | Q49     | 2SA933S       | TRANSISTOR             |
|    | Q50     | 2SA933S       | TRANSISTOR             |
|    | Q51     | 2SA933S       | TRANSISTOR             |
|    | Q52     | 2SC1740S(QRS) | TRANSISTOR             |
|    | Q53     | DTIC14ES      | TRANSISTOR             |
|    | Q54     | DTIC14ES      | TRANSISTOR             |
|    | Q55     | 2SA933S       | TRANSISTOR             |
|    | D1      | 1SS133        | DIODE                  |
|    |         | or MA165      | DIODE                  |
|    | D2      | 1SS133        | DIODE                  |
|    |         | or MA165      | DIODE                  |
|    | D3      | 1SS133        | DIODE                  |
|    |         | or MA165      | DIODE                  |
|    | D4      | 1SS133        | DIODE                  |
|    |         | or MA165      | DIODE                  |
|    | D5      | 1SS133        | DIODE                  |
|    |         | or MA165      | DIODE                  |
|    | D6      | 1SS133        | DIODE                  |
|    |         | or MA165      | DIODE                  |
|    | D7      | 1SS133        | DIODE                  |
|    |         | or MA165      | DIODE                  |
|    | D8      | 1SS133        | DIODE                  |
|    |         | or MA165      | DIODE                  |
|    | D10     | 1SS133        | DIODE                  |
|    |         | or MA165      | DIODE                  |
|    | D11     | 1SS133        | DIODE                  |
|    |         | or MA165      | DIODE                  |
|    | D12     | 1SS133        | DIODE                  |
|    |         | or MA165      | DIODE                  |
|    | D13     | 1SS133        | DIODE                  |
|    |         | or MA165      | DIODE                  |
|    | D16     | 1SS133        | DIODE                  |
|    |         | or MA165      | DIODE                  |
|    | D17     | 1SS133        | DIODE                  |
|    |         | or MA165      | DIODE                  |
|    | D18     | 1SS133        | DIODE                  |
|    |         | or MA165      | DIODE                  |
|    | D20     | OA90UF        | DIODE                  |
|    | D21     | OA90UF        | DIODE                  |
|    | D22     | 1SS133        | DIODE                  |
|    |         | or MA165      | DIODE                  |
|    | D23     | 1SS133        | DIODE                  |
|    |         | or MA165      | DIODE                  |
|    | D24     | 1SS133        | DIODE                  |
|    |         | or MA165      | DIODE                  |
|    | D26     | 1SS133        | DIODE                  |
|    |         | or MA165      | DIODE                  |
|    | D27     | 1SS133        | DIODE                  |
|    |         | or MA165      | DIODE                  |
|    | D28     | 1SS133        | DIODE                  |
|    |         | or MA165      | DIODE                  |
|    | D29     | 1SS133        | DIODE                  |
|    |         | or MA165      | DIODE                  |

| #△ | REF No. | PART No.    | PART NAME, DESCRIPTION             |
|----|---------|-------------|------------------------------------|
|    | D31     | 1SS133      | DIODE                              |
|    |         | or MA165    | DIODE                              |
|    | D32     | 1SS133      | DIODE                              |
|    |         | or MA165    | DIODE                              |
|    | D34     | RD91ES-T1B2 | ZENER DIODE                        |
|    | R1      | QRD161J-562 | RESISTOR 5.6KΩ, 1/6W               |
|    | R2      | QRD161J-822 | RESISTOR 8.2KΩ, 1/6W               |
|    | R3      | QRD161J-223 | RESISTOR 22KΩ, 1/6W                |
|    | R4      | QRD161J-182 | RESISTOR 1.8KΩ, 1/6W               |
|    | R5      | QRD161J-821 | RESISTOR 820Ω, 1/6W                |
|    | R6      | QRD161J-681 | RESISTOR 680Ω, 1/6W                |
|    | R7      | QRD161J-223 | RESISTOR 22KΩ, 1/6W                |
|    | R8      | QRD161J-273 | RESISTOR 27KΩ, 1/6W                |
|    | R9      | QRD161J-223 | RESISTOR 22KΩ, 1/6W                |
|    | R10     | QRD161J-681 | RESISTOR 680Ω, 1/6W                |
|    | R11     | QRD161J-331 | RESISTOR 330Ω, 1/6W                |
|    | R12     | QRD161J-331 | RESISTOR 330Ω, 1/6W                |
|    | R13     | QRD161J-475 | RESISTOR 4.7MΩ, 1/6W               |
|    | R14     | QRD161J-102 | RESISTOR 1KΩ, 1/6W                 |
|    | R15     | QRD161J-103 | RESISTOR 10KΩ, 1/6W                |
|    | R16     | QRD161J-222 | RESISTOR 2.2KΩ, 1/6W               |
|    | R17     | QRD161J-821 | RESISTOR 820Ω, 1/6W                |
|    | R18     | QRD161J-102 | RESISTOR 1KΩ, 1/6W                 |
|    | R19     | QRD161J-222 | RESISTOR 2.2KΩ, 1/6W               |
|    | R20     | QRD161J-122 | RESISTOR 1.2KΩ, 1/6W               |
|    | R21     | QRD161J-102 | RESISTOR 1KΩ, 1/6W                 |
|    | R22     | QRD161J-681 | RESISTOR 680Ω, 1/6W                |
|    | R23     | QRD161J-102 | RESISTOR 1KΩ, 1/6W                 |
|    | R24     | QRD161J-122 | RESISTOR 1.2KΩ, 1/6W               |
|    | R25     | QRD161J-562 | RESISTOR 5.6KΩ, 1/6W               |
|    | R26     | QRD121J-181 | RESISTOR 180Ω, 1/2W                |
|    | R27     | QVZ3518-102 | V RESISTOR, 0.25H DL VIDEO LEV 1KΩ |
|    | R28     | QRD161J-471 | RESISTOR 470Ω, 1/6W                |
|    | R29     | QRD161J-821 | RESISTOR 820Ω, 1/6W                |
|    | R30     | QRD161J-561 | RESISTOR 560Ω, 1/6W                |
|    | R31     | QRD161J-471 | RESISTOR 470Ω, 1/6W                |
|    | R32     | QRD161J-153 | RESISTOR 15KΩ, 1/6W                |
|    | R33     | QRD161J-561 | RESISTOR 560Ω, 1/6W                |
|    | R34     | QRD161J-182 | RESISTOR 1.8KΩ, 1/6W               |
|    | R35     | QRD161J-102 | RESISTOR 1KΩ, 1/6W                 |
|    | R36     | QRD161J-221 | RESISTOR 220Ω, 1/6W                |
|    | R37     | QRD161J-271 | RESISTOR 270Ω, 1/6W                |
|    | R38     | QRD161J-471 | RESISTOR 470Ω, 1/6W                |
|    | R39     | QRD161J-152 | RESISTOR 1.5KΩ, 1/6W               |
|    | R40     | QRD161J-152 | RESISTOR 1.5KΩ, 1/6W               |
|    | R41     | QRD161J-562 | RESISTOR 5.6KΩ, 1/6W               |
|    | R42     | QVZ3518-103 | V RESISTOR, SHARPNESS PRESET 1KΩ   |
|    | R43     | QRD161J-103 | RESISTOR 10KΩ, 1/6W                |
|    | R44     | QRD161J-331 | RESISTOR 330Ω, 1/6W                |
|    | R45     | QRD161J-331 | RESISTOR 330Ω, 1/6W                |
|    | R46     | QRD161J-331 | RESISTOR 330Ω, 1/6W                |
|    | R47     | QRD161J-152 | RESISTOR 1.5KΩ, 1/6W               |
|    | R48     | QRD161J-391 | RESISTOR 390Ω, 1/6W                |
|    | R49     | QRD161J-152 | RESISTOR 1.5KΩ, 1/6W               |
|    | R50     | QRD161J-102 | RESISTOR 1KΩ, 1/6W                 |

| #Δ   | REF No. | PART No.    | PART NAME, DESCRIPTION             | #Δ     | REF No. | PART No.    | PART NAME, DESCRIPTION         |
|------|---------|-------------|------------------------------------|--------|---------|-------------|--------------------------------|
| R51  |         | QRD161J-153 | RESISTOR 15KΩ, 1/6W                | R111   |         | QRD161J-223 | RESISTOR 22KΩ, 1/6W            |
| R52  |         | QRD161J-683 | RESISTOR 68KΩ, 1/6W                | R112   |         | QRD161J-391 | RESISTOR 390Ω, 1/6W            |
| R53  |         | QRD161J-122 | RESISTOR 1.2KΩ, 1/6W               | R113   |         | QRD161J-391 | RESISTOR 390Ω, 1/6W            |
| R54  |         | QRD161J-152 | RESISTOR 1.5KΩ, 1/6W               | R114   |         | QRD161J-391 | RESISTOR 390Ω, 1/6W            |
| R55  |         | QRD161J-391 | RESISTOR 390Ω, 1/6W                | R115   |         | QRD161J-391 | RESISTOR 390Ω, 1/6W            |
| R57  |         | QVZ3518-151 | V RESISTOR, SUB EMPH IN LEVEL 150Ω | R116   |         | QRD161J-391 | RESISTOR 390Ω, 1/6W            |
| R58  |         | QRD161J-241 | RESISTOR 240Ω, 1/6W                | R117   |         | QRD161J-223 | RESISTOR 22KΩ, 1/6W            |
| R60  |         | QRD161J-273 | RESISTOR 27KΩ, 1/6W                | R118   |         | QVZ3520-223 | V RESISTOR, Y COMB GAIN 22KΩ   |
| R61  |         | QRD161J-223 | RESISTOR 22KΩ, 1/6W                | R119   |         | QVZ3520-472 | V RESISTOR, Y COMB PHASE 4.7KΩ |
| R62  |         | QRD161J-222 | RESISTOR 2.2KΩ, 1/6W               | R120   |         | QRD161J-102 | RESISTOR 1KΩ, 1/6W             |
| R63  |         | QRD161J-102 | RESISTOR 1KΩ, 1/6W                 | R122   |         | QRD161J-102 | RESISTOR 1KΩ, 1/6W             |
| R64  |         | QRD161J-102 | RESISTOR 1KΩ, 1/6W                 | R123   |         | QRD161J-102 | RESISTOR 1KΩ, 1/6W             |
| R65  |         | QRD161J-152 | RESISTOR 1.5KΩ, 1/6W               | R124   |         | QRD161J-102 | RESISTOR 1KΩ, 1/6W             |
| R66  |         | QRD161J-561 | RESISTOR 560Ω, 1/6W                | R125   |         | QRD161J-102 | RESISTOR 1KΩ, 1/6W             |
| R67  |         | QRD161J-821 | RESISTOR 820Ω, 1/6W                | R126   |         | QRD161J-102 | RESISTOR 1KΩ, 1/6W             |
| R68  |         | QRD161J-471 | RESISTOR 470Ω, 1/6W                | R127   |         | QRD161J-473 | RESISTOR 47KΩ, 1/6W            |
| R69  |         | QRD161J-123 | RESISTOR 12KΩ, 1/6W                | R128   |         | QRD161J-562 | RESISTOR 5.6KΩ, 1/6W           |
| R70  |         | QRD161J-473 | RESISTOR 47KΩ, 1/6W                | R129   |         | QRD161J-103 | RESISTOR 10KΩ, 1/6W            |
| R71  |         | QRD161J-122 | RESISTOR 1.2KΩ, 1/6W               | R130   |         | QRD161J-393 | RESISTOR 39KΩ, 1/6W            |
| R72  |         | QRD161J-102 | RESISTOR 1KΩ, 1/6W                 | R131   |         | QRD161J-272 | RESISTOR 2.7KΩ, 1/6W           |
| R73  |         | QRD161J-622 | RESISTOR 8.2KΩ, 1/6W               | R132   |         | QRD161J-104 | RESISTOR 100KΩ, 1/6W           |
| R74  |         | QRD161J-182 | RESISTOR 1.8KΩ, 1/6W               | R133   |         | QRD161J-104 | RESISTOR 100KΩ, 1/6W           |
| R75  |         | QVZ3518-102 | V RESISTOR, EE Y LEVEL 1KΩ         | R135   |         | QRD161J-473 | RESISTOR 47KΩ, 1/6W            |
| R76  |         | QRD161J-272 | RESISTOR 2.7KΩ, 1/6W               | R136   |         | QRD161J-393 | RESISTOR 39KΩ, 1/6W            |
| R77  |         | QRD161J-332 | RESISTOR 3.3KΩ, 1/6W               | R137   |         | QRD161J-153 | RESISTOR 15KΩ, 1/6W            |
| R78  |         | QRD161J-183 | RESISTOR 18KΩ, 1/6W                | R138   |         | QRD161J-561 | RESISTOR 560Ω, 1/6W            |
| R79  |         | QRD161J-222 | RESISTOR 2.2KΩ, 1/6W               | R139   |         | QRD161J-182 | RESISTOR 1.8KΩ, 1/6W           |
| R80  |         | QRD161J-681 | RESISTOR 680Ω, 1/6W                | R140   |         | QRD161J-271 | RESISTOR 270Ω, 1/6W            |
| R81  |         | QRD161J-223 | RESISTOR 22KΩ, 1/6W                | R141   |         | QRD161J-223 | RESISTOR 22KΩ, 1/6W            |
| R82  |         | QRD161J-393 | RESISTOR 39KΩ, 1/6W                | R142   |         | QRD161J-622 | RESISTOR 3.9KΩ, 1/6W           |
| R83  |         | QRD161J-153 | RESISTOR 15KΩ, 1/6W                | R145   |         | QRD161J-562 | RESISTOR 5.6KΩ, 1/6W           |
| R84  |         | QRD161J-154 | RESISTOR 150KΩ, 1/6W               | R146   |         | QRD161J-682 | RESISTOR 6.8KΩ, 1/6W           |
| R85  |         | QRD161J-124 | RESISTOR 120KΩ, 1/6W               | Δ R147 |         | QRD121J-680 | RESISTOR 68Ω, 1/2W             |
| R87  |         | QRD161J-394 | RESISTOR 390KΩ, 1/6W               | R148   |         | QRD161J-271 | RESISTOR 270Ω, 1/6W            |
| R88  |         | QRD161J-475 | RESISTOR 4.7KΩ, 1/6W               | R149   |         | QRD161J-101 | RESISTOR 100Ω, 1/6W            |
| R89  |         | QRD161J-562 | RESISTOR 5.6KΩ, 1/6W               | R150   |         | QRD161J-101 | RESISTOR 100Ω, 1/6W            |
| R91  |         | QVZ3518-473 | V RESISTOR, VHS PB Y LEVEL 47KΩ    | R151   |         | QRD161J-393 | RESISTOR 39KΩ, 1/6W            |
| R92  |         | QVZ3518-473 | V RESISTOR, S-VHS PB Y LEVEL 47KΩ  | R152   |         | QRD161J-622 | RESISTOR 8.2KΩ, 1/6W           |
| R93  |         | QRD161J-223 | RESISTOR 22KΩ, 1/6W                | R153   |         | QRD161J-122 | RESISTOR 1.2KΩ, 1/6W           |
| R94  |         | QRD161J-821 | RESISTOR 820Ω, 1/6W                | R154   |         | QRD161J-271 | RESISTOR 270Ω, 1/6W            |
| R95  |         | QVZ3518-102 | V RESISTOR, VHS REC FM LEVEL 1KΩ   | R155   |         | QRD161J-222 | RESISTOR 2.2KΩ, 1/6W           |
| R96  |         | QRD161J-102 | RESISTOR 1KΩ, 1/6W                 | R156   |         | QRD161J-221 | RESISTOR 220Ω, 1/6W            |
| R97  |         | QRD161J-103 | RESISTOR 10KΩ, 1/6W                | R157   |         | QRD161J-221 | RESISTOR 220Ω, 1/6W            |
| R98  |         | QRD161J-223 | RESISTOR 22KΩ, 1/6W                | R161   |         | QRD161J-222 | RESISTOR 2.2KΩ, 1/6W           |
| R99  |         | QRD161J-681 | RESISTOR 680Ω, 1/6W                | R163   |         | QVZ3518-681 | V RESISTOR, 0.25H DL VIDEO 68Ω |
| R100 |         | QRD161J-223 | RESISTOR 22KΩ, 1/6W                | R164   |         | QRD161J-102 | RESISTOR 1KΩ, 1/6W             |
| R101 |         | QRD161J-153 | RESISTOR 15KΩ, 1/6W                | R165   |         | QRD161J-102 | RESISTOR 1KΩ, 1/6W             |
| R102 |         | QRD161J-561 | RESISTOR 560Ω, 1/6W                | R166   |         | QRD161J-151 | RESISTOR 150Ω, 1/6W            |
| R103 |         | QVZ3518-102 | V RESISTOR, S-VHS REC FM LEVEL 1KΩ | R167   |         | QRD161J-102 | RESISTOR 1KΩ, 1/6W             |
| R104 |         | QRD161J-102 | RESISTOR 1KΩ, 1/6W                 | R168   |         | QRD161J-102 | RESISTOR 1KΩ, 1/6W             |
| R105 |         | QRD161J-331 | RESISTOR 330Ω, 1/6W                | R169   |         | QRD161J-223 | RESISTOR 22KΩ, 1/6W            |
| R106 |         | QRD161J-102 | RESISTOR 1KΩ, 1/6W                 | R170   |         | QRD161J-153 | RESISTOR 15KΩ, 1/6W            |
| R107 |         | QVZ3518-151 | V RESISTOR, Y COMB GAIN ADJ 150Ω   | R171   |         | QRD161J-121 | RESISTOR 120Ω, 1/6W            |
| R108 |         | QVZ3518-473 | V RESISTOR, 4H DELAYED CHROMA 47KΩ | R172   |         | QRD161J-101 | RESISTOR 100Ω, 1/6W            |
| R109 |         | QRD161J-223 | RESISTOR 22KΩ, 1/6W                | R173   |         | QRD161J-472 | RESISTOR 4.7KΩ, 1/6W           |
| R110 |         | QVZ3518-473 | V RESISTOR, 2H DELAYED CHROMA 47KΩ | R174   |         | QRD161J-102 | RESISTOR 1KΩ, 1/6W             |

| #Δ | REF No. | PART No.      | PART NAME, DESCRIPTION   |
|----|---------|---------------|--------------------------|
|    | R175    | QRD161J-331   | RESISTOR 330Ω, 1/6W      |
|    | R176    | QRD161J-392   | RESISTOR 3.9KΩ, 1/6W     |
|    | R177    | ERT-D2FHL332S | THERMISTOR               |
|    | R178    | QRD161J-272   | RESISTOR 2.7KΩ, 1/6W     |
|    | R179    | QRD161J-223   | RESISTOR 22KΩ, 1/6W      |
|    | R180    | QRD161J-122   | RESISTOR 1.2KΩ, 1/6W     |
|    | R181    | QRD161J-562   | RESISTOR 5.6KΩ, 1/6W     |
|    | R182    | QRD161J-101   | RESISTOR 100Ω, 1/6W      |
|    | R183    | QRD161J-101   | RESISTOR 100Ω, 1/6W      |
|    | R184    | QRD161J-272   | RESISTOR 2.7KΩ, 1/6W     |
|    | R185    | QRD161J-471   | RESISTOR 470Ω, 1/6W      |
|    | R186    | QRD161J-381   | RESISTOR 390Ω, 1/6W      |
|    | R187    | QRD161J-621   | RESISTOR 620Ω, 1/6W      |
|    | R188    | QRD161J-392   | RESISTOR 3.9KΩ, 1/6W     |
|    | R189    | QRD161J-181   | RESISTOR 180Ω, 1/6W      |
|    | R190    | QRD161J-821   | RESISTOR 820Ω, 1/6W      |
|    | R191    | QRD161J-222   | RESISTOR 2.2KΩ, 1/6W     |
|    | R192    | ERT-D2FGL102S | THERMISTOR               |
|    | R193    | QRD161J-473   | RESISTOR 47KΩ, 1/6W      |
|    | R194    | QRD161J-473   | RESISTOR 47KΩ, 1/6W      |
|    | R195    | QRD161J-561   | RESISTOR 560Ω, 1/6W      |
|    | R196    | QRD161J-561   | RESISTOR 560Ω, 1/6W      |
|    | R197    | QVZ3520-471   | V RESISTOR, Y COMB 470Ω  |
|    | R198    | QRD161J-103   | RESISTOR 10KΩ, 1/6W      |
|    | R199    | QRD161J-121   | RESISTOR 120Ω, 1/6W      |
|    | R200    | QRD161J-102   | RESISTOR 1KΩ, 1/6W       |
|    | R201    | QRD161J-332   | RESISTOR 3.3KΩ, 1/6W     |
|    | R204    | QRD161J-102   | RESISTOR 1KΩ, 1/6W       |
|    | R205    | QRD161J-102   | RESISTOR 1KΩ, 1/6W       |
| Δ  | R206    | QRD121J-680   | RESISTOR 68Ω, 1/2W       |
|    | R209    | QRD161J-474   | RESISTOR 470KΩ, 1/6W     |
|    | R210    | QRD161J-101   | RESISTOR 100Ω, 1/6W      |
|    | R211    | QRD161J-101   | RESISTOR 100Ω, 1/6W      |
|    | R212    | QRD161J-122   | RESISTOR 1.2KΩ, 1/6W     |
|    | C1      | QCSB1HJ-560   | CAPACITOR 56PF, 50V      |
|    | C2      | QCSB1HJ-101   | CAPACITOR 100PF, 50V     |
|    | C3      | QCSB1HJ-181   | CAPACITOR 180PF, 50V     |
|    | C4      | QETC1EM-475   | E CAPACITOR 4.7μF, 25V   |
|    | C5      | QETC1HM-224   | E CAPACITOR 0.22μF, 50V  |
|    | C6      | QETC0JM-337   | E CAPACITOR 330μF, 6.3V  |
|    | C7      | QCVB1CN-103   | CAPACITOR 0.01μF, 16V    |
|    | C8      | QCSB1HJ-560   | CAPACITOR 56PF, 50V      |
|    | C9      | QETC1HM-105   | E CAPACITOR 1μF, 50V     |
|    | C10     | QCVB1CN-103   | CAPACITOR 0.01μF, 16V    |
|    | C11     | QCSB1HJ-680   | CAPACITOR 68PF, 50V      |
|    | C13     | QCVB1CN-103   | CAPACITOR 0.01μF, 16V    |
|    | C14     | QETC1HM-225   | E CAPACITOR 2.2μF, 50V   |
|    | C15     | QFN41HK-563   | M CAPACITOR 0.056μF, 50V |
|    | C16     | QCSB1HJ-181   | CAPACITOR 180PF, 50V     |
|    | C17     | QCSB1HJ-391   | CAPACITOR 390PF, 50V     |
|    | C18     | QETC1HM-225   | E CAPACITOR 2.2μF, 50V   |
|    | C19     | QETC1CM-106   | E CAPACITOR 10μF, 16V    |
|    | C20     | QETC1EM-335   | E CAPACITOR 3.3μF, 25V   |
|    | C21     | QCVB1CN-103   | CAPACITOR 0.01μF, 16V    |
|    | C22     | QCVB1CN-103   | CAPACITOR 0.01μF, 16V    |

| #Δ | REF No. | PART No.    | PART NAME, DESCRIPTION    |
|----|---------|-------------|---------------------------|
|    | C23     | QETC1CM-106 | E CAPACITOR 10μF, 16V     |
|    | C24     | QCVB1CN-103 | CAPACITOR 0.01μF, 16V     |
|    | C25     | QCVB1CN-103 | CAPACITOR 0.01μF, 16V     |
|    | C26     | QCVB1CN-103 | CAPACITOR 0.01μF, 16V     |
|    | C27     | QCVB1CN-103 | CAPACITOR 0.01μF, 16V     |
|    | C28     | QEK61EM-475 | E CAPACITOR 4.7μF, 25V    |
|    | C29     | QETC1EM-475 | E CAPACITOR 4.7μF, 25V    |
|    | C30     | QCVB1CN-103 | CAPACITOR 0.01μF, 16V     |
|    | C31     | QEK61EM-475 | E CAPACITOR 4.7μF, 25V    |
|    | C32     | QEK61EM-475 | E CAPACITOR 4.7μF, 25V    |
|    | C33     | QER61AM-226 | E CAPACITOR 22μF, 10V     |
|    | C34     | QETC0JM-337 | E CAPACITOR 330μF, 6.3V   |
|    | C35     | QCVB1CN-103 | CAPACITOR 0.01μF, 16V     |
|    | C36     | QEP61EM-475 | NP E CAPACITOR 4.7μF, 25V |
|    | C37     | QER61EM-475 | E CAPACITOR 4.7μF, 25V    |
|    | C38     | QCVB1CN-103 | CAPACITOR 0.01μF, 16V     |
|    | C40     | QEK60JM-476 | E CAPACITOR 47μF, 6.3V    |
|    | C41     | QCVB1CN-103 | CAPACITOR 0.01μF, 16V     |
|    | C42     | QETC1CM-106 | E CAPACITOR 10μF, 16V     |
|    | C43     | QEK61CM-106 | E CAPACITOR 10μF, 16V     |
|    | C44     | QCVB1CN-103 | CAPACITOR 0.01μF, 16V     |
|    | C45     | QCVB1CN-103 | CAPACITOR 0.01μF, 16V     |
|    | C46     | QCVB1CN-103 | CAPACITOR 0.01μF, 16V     |
|    | C47     | QETC1CM-106 | E CAPACITOR 10μF, 16V     |
|    | C48     | QETC1CM-106 | E CAPACITOR 10μF, 16V     |
|    | C49     | QETC1CM-106 | E CAPACITOR 10μF, 16V     |
|    | C50     | QCVB1CN-103 | CAPACITOR 0.01μF, 16V     |
|    | C51     | QCSB1HJ-390 | CAPACITOR 39PF, 50V       |
|    | C52     | QCVB1CN-103 | CAPACITOR 0.01μF, 16V     |
|    | C53     | QETC1CM-476 | E CAPACITOR 47μF, 16V     |
|    | C54     | QETC1CM-106 | E CAPACITOR 10μF, 16V     |
|    | C55     | QEK61CM-106 | E CAPACITOR 10μF, 16V     |
|    | C56     | QEK61CM-106 | E CAPACITOR 10μF, 16V     |
|    | C57     | QEK61CM-106 | E CAPACITOR 10μF, 16V     |
|    | C58     | QEK61CM-106 | E CAPACITOR 10μF, 16V     |
|    | C60     | QEK61CM-476 | E CAPACITOR 47μF, 16V     |
|    | C61     | QCVB1CN-103 | CAPACITOR 0.01μF, 16V     |
|    | C62     | QCSB1HJ-470 | CAPACITOR 47PF, 50V       |
|    | C63     | QCVB1CN-103 | CAPACITOR 0.01μF, 16V     |
|    | C64     | QCSB1HJ-470 | CAPACITOR 47PF, 50V       |
|    | C65     | QEK60JM-476 | E CAPACITOR 47μF, 6.3V    |
|    | C66     | QEK61CM-106 | E CAPACITOR 10μF, 16V     |
|    | C67     | QCVB1CN-103 | CAPACITOR 0.01μF, 16V     |
|    | C68     | QEK61CM-106 | E CAPACITOR 10μF, 16V     |
|    | C69     | QCVB1CN-103 | CAPACITOR 0.01μF, 16V     |
|    | C70     | QEK61CM-476 | E CAPACITOR 47μF, 16V     |
|    | C74     | QCSB1HJ-560 | CAPACITOR 56PF, 50V       |
|    | C76     | QETC0JM-476 | E CAPACITOR 47μF, 6.3V    |
|    | C77     | QETC1EM-335 | E CAPACITOR 3.3μF, 25V    |
|    | C78     | QETC0JM-476 | E CAPACITOR 47μF, 6.3V    |
|    | C79     | QETC1CM-106 | E CAPACITOR 10μF, 16V     |
|    | C80     | QETC1CM-106 | E CAPACITOR 10μF, 16V     |
|    | C81     | QETC0JM-476 | E CAPACITOR 47μF, 6.3V    |
|    | C82     | QETC1EM-475 | E CAPACITOR 4.7μF, 25V    |
|    | C83     | QETC1EM-475 | E CAPACITOR 4.7μF, 25V    |
|    | C84     | QCSB1HJ-121 | CAPACITOR 120PF, 50V      |
|    | C85     | QCSB1HJ-560 | CAPACITOR 56PF, 50V       |

| #    | REF No.     | PART No.       | PART NAME, DESCRIPTION |  | #    | REF No.      | PART No.    | PART NAME, DESCRIPTION |  |
|------|-------------|----------------|------------------------|--|------|--------------|-------------|------------------------|--|
| C86  | QEK61CM-106 | E CAPACITOR    | 10μF, 16V              |  | C144 | QCVB1CN-103  | CAPACITOR   | 0.01μF, 16V            |  |
| C87  | QCSB1HJ-150 | CAPACITOR      | 15PF, 50V              |  | C146 | QCSB1HJ-220  | CAPACITOR   | 22PF, 50V              |  |
| C88  | QEK61HM-225 | E CAPACITOR    | 2.2μF, 50V             |  | C147 | QCSB1HJ-101  | CAPACITOR   | 100PF, 50V             |  |
| C89  | QEK61CM-106 | E CAPACITOR    | 10μF, 16V              |  | C148 | QCVB1CN-103  | CAPACITOR   | 0.01μF, 16V            |  |
| C90  | QEK51CM-476 | E CAPACITOR    | 47μF, 16V              |  | C149 | QCSB1HJ-560  | CAPACITOR   | 56PF, 50V              |  |
|      |             |                |                        |  | C150 | QCSB1HJ-390  | CAPACITOR   | 39PF, 50V              |  |
| C91  | QCVB1CN-103 | CAPACITOR      | 0.01μF, 16V            |  |      |              |             |                        |  |
| C92  | QETC1CM-106 | E CAPACITOR    | 10μF, 16V              |  | C151 | QCVB1CN-103  | CAPACITOR   | 0.01μF, 16V            |  |
| C93  | QCSB1HJ-101 | CAPACITOR      | 100PF, 50V             |  | C152 | QEK61CM-336  | E CAPACITOR | 33μF, 16V              |  |
| C94  | QCSB1HJ-270 | CAPACITOR      | 27PF, 50V              |  | C153 | QCSB1HK-5R6  | CAPACITOR   | 5.6PF, 50V             |  |
| C95  | QCSB1HJ-180 | CAPACITOR      | 18PF, 50V              |  | C154 | QCSB1HJ-390  | CAPACITOR   | 39PF, 50V              |  |
| C96  | QETC1HM-335 | E CAPACITOR    | 3.3μF, 50V             |  | C155 | QCSB1HJ-120  | CAPACITOR   | 12PF, 50V              |  |
| C97  | QCSB1HJ-151 | CAPACITOR      | 150PF, 50V             |  | C156 | QCSB1HJ-220  | CAPACITOR   | 22PF, 50V              |  |
| C98  | QETC1HM-105 | E CAPACITOR    | 1μF, 50V               |  | C157 | QCSB1HJ-181  | CAPACITOR   | 180PF, 50V             |  |
| C99  | QED60JM-127 | E CAPACITOR    | 120μF, 6.3V            |  | C159 | QCVB1CN-103  | CAPACITOR   | 0.01μF, 16V            |  |
| C100 | QCVB1CN-103 | CAPACITOR      | 0.01μF, 16V            |  | C160 | QCSB1HJ-151  | CAPACITOR   | 150PF, 50V             |  |
|      |             |                |                        |  |      |              |             |                        |  |
| C101 | QETC0JM-337 | E CAPACITOR    | 330μF, 6.3V            |  | C162 | QEK61CM-106  | E CAPACITOR | 10μF, 16V              |  |
| C102 | QCSB1HJ-120 | CAPACITOR      | 12PF, 50V              |  | C163 | QEK61CM-106  | E CAPACITOR | 10μF, 16V              |  |
| C103 | QCSB1HJ-121 | CAPACITOR      | 120PF, 50V             |  | C165 | QEK61CM-476  | E CAPACITOR | 47μF, 16V              |  |
| C104 | QCSB1HJ-121 | CAPACITOR      | 120PF, 50V             |  | C166 | QCVB1CN-103  | CAPACITOR   | 0.01μF, 16V            |  |
| C105 | QCVB1CN-103 | CAPACITOR      | 0.01μF, 16V            |  | C167 | QETC1CM-107  | E CAPACITOR | 100μF, 16V             |  |
| C106 | QCVB1CN-103 | CAPACITOR      | 0.01μF, 16V            |  | C168 | QCVB1CN-103  | CAPACITOR   | 0.01μF, 16V            |  |
| C107 | QCVB1CN-103 | CAPACITOR      | 0.01μF, 16V            |  | C169 | QETC1CM-106  | E CAPACITOR | 10μF, 16V              |  |
| C108 | QCVB1CN-103 | CAPACITOR      | 0.01μF, 16V            |  |      |              |             |                        |  |
| C109 | QCSB1HJ-101 | CAPACITOR      | 100PF, 50V             |  | C171 | QCVB1CN-103  | CAPACITOR   | 0.01μF, 16V            |  |
| C110 | QCVB1CN-103 | CAPACITOR      | 0.01μF, 16V            |  | C172 | QCVB1CN-103  | CAPACITOR   | 0.01μF, 16V            |  |
|      |             |                |                        |  | C173 | QCT25CH-470  | CAPACITOR   | 47PF                   |  |
| C111 | QETC0JM-476 | E CAPACITOR    | 47μF, 6.3V             |  | C174 | QCSB1HJ-471  | CAPACITOR   | 470PF, 50V             |  |
| C112 | QCVB1CN-103 | CAPACITOR      | 0.01μF, 16V            |  | C175 | QCC31CJ-563  | CAPACITOR   | 0.056μF, 16V           |  |
| C113 | QCSB1HJ-101 | CAPACITOR      | 100PF, 50V             |  | C176 | QCVB1CN-103  | CAPACITOR   | 0.01μF, 16V            |  |
| C114 | QCVB1CN-103 | CAPACITOR      | 0.01μF, 16V            |  | C179 | QCSB1HJ-470  | CAPACITOR   | 47PF, 50V              |  |
| C115 | QCVB1CN-103 | CAPACITOR      | 0.01μF, 16V            |  | C180 | QCSB1HJ-220  | CAPACITOR   | 22PF, 50V              |  |
| C116 | QCSB1HJ-101 | CAPACITOR      | 100PF, 50V             |  |      |              |             |                        |  |
| C117 | QCVB1CN-103 | CAPACITOR      | 0.01μF, 16V            |  | C183 | QCSB1HJ-390  | CAPACITOR   | 39PF, 50V              |  |
| C118 | QCVB1CN-103 | CAPACITOR      | 0.01μF, 16V            |  | C184 | QCVB1CN-103  | CAPACITOR   | 0.01μF, 16V            |  |
| C119 | QCVB1CN-103 | CAPACITOR      | 0.01μF, 16V            |  | C185 | QCSB1HK-3R9  | CAPACITOR   | 3.9PF, 50V             |  |
| C120 | QCVB1CN-103 | CAPACITOR      | 0.01μF, 16V            |  |      |              |             |                        |  |
|      |             |                |                        |  |      |              |             |                        |  |
| C121 | QEK61CM-106 | E CAPACITOR    | 10μF, 16V              |  | L1   | PU59152-220J | COIL        | 22μH                   |  |
| C122 | QCVB1CN-103 | CAPACITOR      | 0.01μF, 16V            |  | L2   | PU48530-101K | COIL        | 100μH                  |  |
| C123 | QETC1HM-105 | E CAPACITOR    | 1μF, 50V               |  | L3   | PU48530-101K | COIL        | 100μH                  |  |
| C124 | QCVB1CN-103 | CAPACITOR      | 0.01μF, 16V            |  | L4   | PU48530-101K | COIL        | 100μH                  |  |
| C125 | QETC1CM-476 | E CAPACITOR    | 47μF, 16V              |  | L5   | PU48530-101K | COIL        | 100μH                  |  |
| C126 | QEK61AM-476 | E CAPACITOR    | 47μF, 10V              |  | L6   | PU48530-101K | COIL        | 100μH                  |  |
| C127 | QCVB1CN-103 | CAPACITOR      | 0.01μF, 16V            |  | L7   | PU48530-101K | COIL        | 100μH                  |  |
| C130 | QETC0JM-476 | E CAPACITOR    | 47μF, 6.3V             |  | L8   | PU48530-101K | COIL        | 100μH                  |  |
|      |             |                |                        |  | L9   | PU48530-101K | COIL        | 100μH                  |  |
| C131 | QCVB1CN-103 | CAPACITOR      | 0.01μF, 16V            |  | L10  | PU48530-101K | COIL        | 100μH                  |  |
| C132 | QETCIAM-476 | E CAPACITOR    | 47μF, 10V              |  |      |              |             |                        |  |
| C133 | QCVB1CN-103 | CAPACITOR      | 0.01μF, 16V            |  | L11  | PU48530-101K | COIL        | 100μH                  |  |
| C134 | QCVB1CN-103 | CAPACITOR      | 0.01μF, 16V            |  | L12  | PU48530-101K | COIL        | 100μH                  |  |
| C135 | QETC1CM-476 | E CAPACITOR    | 47μF, 16V              |  | L13  | PU59152-220J | COIL        | 22μH                   |  |
| C136 | QCVB1CN-103 | CAPACITOR      | 0.01μF, 16V            |  | L14  | PU48530-101K | COIL        | 100μH                  |  |
| C137 | QETC1CM-476 | E CAPACITOR    | 47μF, 16V              |  | L15  | PU48530-101K | COIL        | 100μH                  |  |
| C138 | QCVB1CN-103 | CAPACITOR      | 0.01μF, 16V            |  | L16  | PU59152-820J | COIL        | 82μH                   |  |
| C139 | QCVB1CN-103 | CAPACITOR      | 0.01μF, 16V            |  | L17  | PU48530-101K | COIL        | 100μH                  |  |
| C140 | QETC0JM-476 | E CAPACITOR    | 47μF, 6.3V             |  | L18  | PU59152-560J | COIL        | 56μH                   |  |
|      |             |                |                        |  | L19  | PU48530-101K | COIL        | 100μH                  |  |
| C141 | QCVB1CN-103 | CAPACITOR      | 0.01μF, 16V            |  | L20  | PU48530-471K | COIL        | 470μH                  |  |
| C142 | QEN61HM-105 | NP E CAPACITOR | 1μF, 50V               |  |      |              |             |                        |  |
| C143 | QETC1HM-104 | E CAPACITOR    | 0.1μF, 50V             |  | L21  | PU59152-150J | COIL        | 15μH                   |  |



| #Δ  | REF No. | PART No.     | PART NAME, DESCRIPTION |       |
|-----|---------|--------------|------------------------|-------|
| L22 |         | PU48530-101K | COIL                   | 100μH |
| L23 |         | PU48530-471K | COIL                   | 470μH |
| L24 |         | PU48530-560J | COIL                   | 56μH  |
| L25 |         | PU59152-221J | COIL                   | 220μH |
| L26 |         | PU59152-560J | COIL                   | 56μH  |
| L27 |         | PU48530-101K | COIL                   | 100μH |
| L28 |         | PU48530-101K | COIL                   | 100μH |
| L29 |         | PU48530-101K | COIL                   | 100μH |
| L30 |         | PU60165-8R2G | COIL                   | 8.2μH |
| L31 |         | PU60165-8R2G | COIL                   | 8.2μH |
| L32 |         | PU48530-101K | COIL                   | 100μH |
| L33 |         | PU59152-180J | COIL                   | 18μH  |
| L35 |         | PU59152-1R0K | COIL                   | 1.0μH |
| L36 |         | PU59152-1R0K | COIL                   | 1.0μH |
| L38 |         | PU59152-6R6J | COIL                   | 5.6μH |
| L39 |         | PU48530-101K | COIL                   | 100μH |
| L40 |         | PU59152-820J | COIL                   | 82μH  |
| L41 |         | PU59152-470J | COIL                   | 47μH  |
| L42 |         | PU59152-221J | COIL                   | 220μH |
| L43 |         | PU48530-101K | COIL                   | 100μH |
| L44 |         | PU59152-151J | COIL                   | 150μH |

|     |         |           |
|-----|---------|-----------|
| EQ1 | PU60099 | EQUALIZER |
| EQ2 | PU60809 | EQUALIZER |
| EQ3 | PU60810 | EQUALIZER |

|      |           |                        |
|------|-----------|------------------------|
| LPF1 | PU60813   | LOW & BAND PASS FILTER |
| LPF2 | PU60737   | LOW PASS FILTER        |
| LPF3 | PU60806-2 | LOW PASS FILTER        |

|      |           |                  |
|------|-----------|------------------|
| BPF2 | PU60921   | BAND PASS FILTER |
| BPF3 | PU60808-2 | BAND PASS FILTER |

|     |         |                 |
|-----|---------|-----------------|
| DL1 | PU60815 | 2H DELAY LINE   |
| DL3 | PU61081 | 1/4H DELAY LINE |

|        |         |                    |
|--------|---------|--------------------|
| Δ X101 | PU60438 | CRYSTAL RESONATOR  |
| T1     | PU60814 | COIL               |
| T2     | PU60814 | COIL, 2H DL CHROMA |

# — COLOR SECTION —

|       |             |                   |
|-------|-------------|-------------------|
| IC301 | PB20287A-03 | COLOR MODULE ASSY |
| IC302 | PB20289A-02 | JOG MODULE ASSY   |
| IC303 | NUM2233AD   | IC                |

|       |           |    |
|-------|-----------|----|
| IC401 | BA7106LS  | IC |
| or    | XRA7106LS | IC |

|      |          |            |
|------|----------|------------|
| Q301 | 2SA933S  | TRANSISTOR |
| Q302 | DTC144WS | TRANSISTOR |
| Q303 | DTA124ES | TRANSISTOR |

| #Δ   | REF No. | PART No.       | PART NAME, DESCRIPTION |
|------|---------|----------------|------------------------|
| Q304 |         | 2SC1740S(QRS)  | TRANSISTOR             |
| Q305 |         | 2SC1740S(QRS)  | TRANSISTOR             |
| Q307 |         | 2SC2021Q, R, S | TRANSISTOR             |
| Q308 |         | 2SA937         | TRANSISTOR             |
| Q309 |         | 2SC1740S(QRS)  | TRANSISTOR             |
| Q310 |         | DTC124ES       | TRANSISTOR             |
| Q311 |         | 2SC1740S(QRS)  | TRANSISTOR             |
| Q312 |         | DTC114ES       | TRANSISTOR             |
| Q313 |         | DTC114ES       | TRANSISTOR             |
| Q314 |         | DTC144WS       | TRANSISTOR             |
| Q315 |         | 2SC1740S(QRS)  | TRANSISTOR             |
| Q316 |         | 2SA933S        | TRANSISTOR             |
| Q317 |         | 2SC1740S(QRS)  | TRANSISTOR             |
| Q318 |         | 2SC1740S(QRS)  | TRANSISTOR             |
| Q319 |         | 2SC1740S(QRS)  | TRANSISTOR             |
| Q320 |         | DTC124ES       | TRANSISTOR             |
| Q323 |         | DTC124ES       | TRANSISTOR             |
| Q324 |         | DTC124ES       | TRANSISTOR             |
| Q326 |         | 2SA933S        | TRANSISTOR             |
| Q327 |         | 2SA933S(QRS)   | TRANSISTOR             |
| Q331 |         | DTC124ES       | TRANSISTOR             |
| Q332 |         | 2SC1740S(QRS)  | TRANSISTOR             |
| Q401 |         | DTA124ES       | TRANSISTOR             |
| Q402 |         | DTA124ES       | TRANSISTOR             |
| Q403 |         | DTC124ES       | TRANSISTOR             |

|      |        |       |
|------|--------|-------|
| D301 | 1SS133 | DIODE |
| or   | MA165  | DIODE |
| D302 | 1SS133 | DIODE |
| or   | MA165  | DIODE |

|      |        |       |
|------|--------|-------|
| D311 | 1SS133 | DIODE |
| or   | MA165  | DIODE |

|      |        |       |
|------|--------|-------|
| D312 | 1SS133 | DIODE |
| or   | MA165  | DIODE |

|      |        |       |
|------|--------|-------|
| D313 | 1SS133 | DIODE |
| or   | MA165  | DIODE |

|      |        |       |
|------|--------|-------|
| D314 | 1SS133 | DIODE |
| or   | MA165  | DIODE |

|      |        |       |
|------|--------|-------|
| D315 | 1SS133 | DIODE |
| or   | MA165  | DIODE |

|      |        |       |
|------|--------|-------|
| D321 | 1SS133 | DIODE |
| or   | MA165  | DIODE |

|      |        |       |
|------|--------|-------|
| D322 | 1SS133 | DIODE |
| or   | MA165  | DIODE |

|      |        |       |
|------|--------|-------|
| D401 | 1SS133 | DIODE |
| or   | MA165  | DIODE |

|      |        |       |
|------|--------|-------|
| D402 | 1SS133 | DIODE |
| or   | MA165  | DIODE |

|      |        |       |
|------|--------|-------|
| D403 | 1SS133 | DIODE |
| or   | MA165  | DIODE |

| #△ REF No. | PART No.    | PART NAME, DESCRIPTION        | #△ REF No. | PART No.    | PART NAME, DESCRIPTION   |
|------------|-------------|-------------------------------|------------|-------------|--------------------------|
| R302       | QRD161J-102 | RESISTOR 1KΩ, 1/8W            | R382       | QRD161J-103 | RESISTOR 10KΩ, 1/6W      |
| R303       | QRD161J-102 | RESISTOR 1KΩ, 1/6W            | R363       | QRD161J-103 | RESISTOR 10KΩ, 1/6W      |
| R304       | QRD161J-102 | RESISTOR 1KΩ, 1/6W            | R364       | QRD161J-223 | RESISTOR 22KΩ, 1/6W      |
| R305       | QRD161J-102 | RESISTOR 1KΩ, 1/6W            | R366       | QRD161J-103 | RESISTOR 10KΩ, 1/6W      |
| R307       | QRD161J-225 | RESISTOR 2.2MΩ, 1/6W          | R367       | QRD161J-473 | RESISTOR 47KΩ, 1/6W      |
| R308       | QRD161J-103 | RESISTOR 10KΩ, 1/6W           | R368       | QRD161J-332 | RESISTOR 33KΩ, 1/6W      |
| R309       | QRD161J-102 | RESISTOR 1KΩ, 1/6W            |            |             |                          |
| R310       | QRD161J-222 | RESISTOR 2.2KΩ, 1/6W          | R371       | QRD161J-182 | RESISTOR 1.8KΩ, 1/6W     |
|            |             |                               | R372       | QRD161J-102 | RESISTOR 1KΩ, 1/6W       |
| R311       | QRD161J-222 | RESISTOR 2.2KΩ, 1/6W          |            |             |                          |
| R312       | QRD161J-561 | RESISTOR 560Ω, 1/6W           | R401       | QRD161J-103 | RESISTOR 10KΩ, 1/6W      |
| R313       | QRD161J-561 | RESISTOR 560Ω, 1/6W           | R402       | QRD161J-914 | RESISTOR 910KΩ, 1/6W     |
| R314       | QRD161J-103 | RESISTOR 10KΩ, 1/6W           | R403       | QRD161J-104 | RESISTOR 100KΩ, 1/6W     |
| R315       | QRD161J-471 | RESISTOR 470Ω, 1/6W           | R404       | QRD161J-333 | RESISTOR 33KΩ, 1/6W      |
| R316       | QRD161J-223 | RESISTOR 22KΩ, 1/6W           | R405       | QRD161J-273 | RESISTOR 27KΩ, 1/6W      |
| R319       | QRD161J-102 | RESISTOR 1KΩ, 1/6W            |            |             |                          |
| R320       | QRD161J-102 | RESISTOR 1KΩ, 1/6W            |            |             |                          |
|            |             |                               |            |             |                          |
| R321       | QRD161J-561 | RESISTOR 560Ω, 1/6W           | C301       | QETCIHM-105 | E CAPACITOR 1μF, 50V     |
| R322       | QRD161J-471 | RESISTOR 470Ω, 1/6W           | C302       | QETCIHM-105 | E CAPACITOR 1μF, 50V     |
| R323       | QRD161J-272 | RESISTOR 2.7KΩ, 1/6W          | C303       | QCC31CJ-223 | CAPACITOR 0.022μF, 16V   |
| R324       | QRD161J-391 | RESISTOR 390Ω, 1/6W           | C304       | QETCOJM-107 | E CAPACITOR 100μF, 6.3V  |
| R325       | QRD161J-223 | RESISTOR 22KΩ, 1/6W           | C305       | QETCIHM-105 | E CAPACITOR 1μF, 50V     |
| R326       | QRD161J-561 | RESISTOR 560Ω, 1/6W           | C307       | QCSBIHJ-330 | CAPACITOR 33PF, 50V      |
| R327       | QRD161J-333 | RESISTOR 33KΩ, 1/6W           | C308       | QCSBIHJ-390 | CAPACITOR 39PF, 50V      |
| R328       | QRD161J-102 | RESISTOR 1KΩ, 1/6W            | C309       | QFN41HJ-473 | M CAPACITOR 0.047μF, 50V |
| R329       | QRD161J-222 | RESISTOR 2.2KΩ, 1/6W          | C310       | QCSBIHJ-560 | CAPACITOR 56PF, 50V      |
| R330       | QRD161J-561 | RESISTOR 560Ω, 1/6W           |            |             |                          |
|            |             |                               |            |             |                          |
| R331       | QRD161J-561 | RESISTOR 560Ω, 1/6W           | C311       | QEK60JM-476 | E CAPACITOR 47μF, 6.3V   |
| R332       | QRD161J-393 | RESISTOR 390Ω, 1/6W           | C312       | QCVBICN-103 | CAPACITOR 0.01μF, 50V    |
| R333       | QRD161J-223 | RESISTOR 22KΩ, 1/6W           | C314       | QCSBIHJ-820 | CAPACITOR 82PF, 50V      |
| R334       | QRD161J-221 | RESISTOR 220Ω, 1/6W           | C315       | QCC31CJ-682 | CAPACITOR 0.0068μF, 16V  |
| R335       | QRD161J-391 | RESISTOR 390Ω, 1/6W           | C316       | QCVBICN-103 | CAPACITOR 0.01μF, 16V    |
| R336       | QRD161J-152 | RESISTOR 1.5KΩ, 1/6W          | C317       | QCVBICN-222 | CAPACITOR 0.0022μF, 16V  |
| R337       | QRD161J-333 | RESISTOR 33KΩ, 1/6W           | C318       | QCSBIHJ-820 | CAPACITOR 82PF, 50V      |
| R338       | QRD161J-333 | RESISTOR 33KΩ, 1/6W           | C320       | QCVBICN-103 | CAPACITOR 0.01μF, 16V    |
| R339       | QRD161J-151 | RESISTOR 150Ω, 1/6W           |            |             |                          |
| R340       | QRD161J-222 | RESISTOR 2.2KΩ, 1/6W          | C321       | QETCIHM-105 | E CAPACITOR 1μF, 50V     |
|            |             |                               | C322       | QETCIHM-104 | E CAPACITOR 0.1μF, 50V   |
| R341       | QRD161J-391 | RESISTOR 390Ω, 1/6W           | C323       | QEK61EM-475 | E CAPACITOR 4.7μF, 25V   |
| R342       | QRD161J-561 | RESISTOR 560Ω, 1/6W           | C324       | QCC31CJ-104 | CAPACITOR 0.1μF, 16V     |
| R343       | QRD161J-393 | RESISTOR 390Ω, 1/6W           | C325       | QETCOJM-337 | E CAPACITOR 330μF, 6.3V  |
| R344       | QRD161J-332 | RESISTOR 33KΩ, 1/6W           | C326       | QCC31CJ-563 | CAPACITOR 0.056μF, 16V   |
| R345       | QRD161J-472 | RESISTOR 47KΩ, 1/6W           | C327       | QETCOJM-107 | E CAPACITOR 100μF, 6.3V  |
| R346       | QRD161J-103 | RESISTOR 10KΩ, 1/6W           | C328       | QETCIEM-335 | E CAPACITOR 3.3μF, 25V   |
| R347       | QRD161J-473 | RESISTOR 47KΩ, 1/6W           | C329       | QETCOJM-337 | E CAPACITOR 330μF, 6.3V  |
| R348       | QRD161J-391 | RESISTOR 390Ω, 1/6W           | C330       | QETBIHM-474 | E CAPACITOR 0.47μF, 50V  |
| R349       | QRD161J-821 | RESISTOR 820Ω, 1/6W           |            |             |                          |
| R350       | QRD161J-471 | RESISTOR 470Ω, 1/6W           | C331       | QETCIHM-474 | E CAPACITOR 0.47μF, 50V  |
|            |             |                               | C332       | QETCIHM-474 | E CAPACITOR 0.47μF, 50V  |
| R351       | QRD161J-102 | RESISTOR 1KΩ, 1/6W            | C333       | QEK61HM-474 | E CAPACITOR 0.47μF, 50V  |
| R352       | QRD161J-102 | RESISTOR 1KΩ, 1/6W            | C334       | QETCIHM-474 | E CAPACITOR 0.47μF, 50V  |
| R353       | QVZ3518-222 | V RESISTOR, LP REC COLOR 22KΩ | C335       | QETCIHM-106 | E CAPACITOR 10μF, 16V    |
| R354       | QRD161J-222 | RESISTOR 2.2KΩ, 1/6W          | C336       | QCVBICN-103 | CAPACITOR 0.01μF, 16V    |
| R355       | QVZ3518-222 | V RESISTOR, SP REC COLOR 22KΩ | C337       | QCSBIHJ-121 | CAPACITOR 120PF, 50V     |
| R357       | QRD161J-333 | RESISTOR 33KΩ, 1/6W           | C338       | QCVBICN-103 | CAPACITOR 0.01μF, 16V    |
| R358       | QRD161J-223 | RESISTOR 22KΩ, 1/6W           | C339       | QCVBICN-103 | CAPACITOR 0.01μF, 16V    |
| R359       | QRD161J-223 | RESISTOR 22KΩ, 1/6W           |            |             |                          |
| R360       | QRD161J-102 | RESISTOR 1KΩ, 1/6W            | C341       | QCVBICN-103 | CAPACITOR 0.01μF, 16V    |
|            |             |                               | C342       | QCSBIHJ-100 | CAPACITOR 10PF, 50V      |
| R361       | QRD161J-102 | RESISTOR 1KΩ, 1/6W            | C343       | QCVBICN-103 | CAPACITOR 0.01μF, 16V    |

| #△ | REF No. | PART No.     | PART NAME, DESCRIPTION |               |
|----|---------|--------------|------------------------|---------------|
|    | C345    | QCVB1CN-103  | CAPACITOR              | 0.01μF, 16V   |
|    | C346    | QCVB1CN-103  | CAPACITOR              | 0.01μF, 16V   |
|    | C347    | QCSB1HJ-390  | CAPACITOR              | 39PF, 50V     |
|    | C348    | QCVB1CN-103  | CAPACITOR              | 0.01μF, 16V   |
|    | C349    | QCVB1CN-103  | CAPACITOR              | 0.01μF, 16V   |
|    | C350    | QCVB1CN-103  | CAPACITOR              | 0.01μF, 16V   |
|    | C351    | QCVB1CN-103  | CAPACITOR              | 0.01μF, 16V   |
|    | C352    | QEK60JM-476  | E CAPACITOR            | 47μF, 8.3V    |
|    | C353    | QCVB1CN-103  | CAPACITOR              | 0.01μF, 16V   |
|    | C355    | QCVB1CN-103  | CAPACITOR              | 0.01μF, 16V   |
|    | C401    | QEK61CM-106  | E CAPACITOR            | 10μF, 16V     |
|    | C402    | QEK61EM-335  | E CAPACITOR            | 3.3μF, 25V    |
|    | C403    | QCSB1HJ-471  | CAPACITOR              | 470PF, 50V    |
|    | C404    | QCVB1CN-103  | CAPACITOR              | 0.01μF, 16V   |
|    | C405    | QCVB1CN-103  | CAPACITOR              | 0.01μF, 16V   |
|    | C406    | QCVB1CN-103  | CAPACITOR              | 0.01μF, 16V   |
|    | C407    | QFN31HJ-471  | M CAPACITOR            | 470PF, 50V    |
|    | C408    | QCSB1HJ-470  | CAPACITOR              | 47PF, 50V     |
|    | C409    | QCXB1CN-472  | CAPACITOR              | 0.0047μF, 16V |
|    | C410    | QCSB1HK-4R7  | CAPACITOR              | 4.7PF, 50V    |
|    | C411    | QCSB1HJ-200  | CAPACITOR              | 20PF, 50V     |
|    | C412    | QEK60JM-107  | E CAPACITOR            | 100μF, 6.3V   |
|    | C413    | QCVB1CN-103  | CAPACITOR              | 0.01μF, 16V   |
|    | L301    | PU48530-101K | COIL                   | 100μH         |
|    | L303    | PU48530-101K | COIL                   | 100μH         |
|    | L304    | PU59152-390J | COIL                   | 39μH          |
|    | L305    | PU48530-222J | COIL                   | 2.2mH         |
|    | L306    | PU59152-221J | COIL                   | 220μH         |
|    | L307    | PU48530-821J | COIL                   | 820μH         |
|    | L308    | PU48530-101K | COIL                   | 100μH         |
|    | L309    | PU59152-100J | COIL                   | 10μH          |
|    | L310    | PU59152-100J | COIL                   | 10μH          |
|    | L311    | PU59153-822J | COIL                   | 8.2mH         |
|    | L312    | PU59153-101K | COIL                   | 100μH         |
|    | L313    | PU59153-101K | COIL                   | 100μH         |
|    | L314    | PU48530-101K | COIL                   | 100μH         |
|    | L316    | PU59152-150J | COIL                   | 15μH          |
|    | L317    | PU48530-101K | COIL                   | 100μH         |
|    | L401    | PU59152-330J | COIL                   | 33μH          |
|    | L402    | PU48530-101K | COIL                   | 100μH         |
|    | EQ301   | PU60811-2    | EQUALIZER              |               |
|    | LFF301  | PU58022      | LOW PASS FILTER        |               |
|    | BPF301  | PU57072      | BAND PASS FILTER       |               |
|    | or      | PU57072-2    | BAND PASS FILTER       |               |
|    | BPF302  | PU60654      | BAND PASS FILTER       |               |
|    | or      | PU60654-2    | BAND PASS FILTER       |               |
|    | CF301   | PU57073      | CERAMIC FILTER         |               |
|    | DL301   | PU58971-3    | 2H DELAY LINE          |               |

| #△ | REF No. | PART No. | PART NAME, DESCRIPTION |
|----|---------|----------|------------------------|
|    | △ X301  | PU60653  | CRYSTAL UNITS          |
|    | T301    | PU49057  | LC BLOCK               |
|    | T401    | PU60655  | COIL, SECAM DET        |

\*\*\*\*\*

## 8. TERMINAL BOARD ASSEMBLY (06)

|       |              |                         |             |
|-------|--------------|-------------------------|-------------|
| PWBA  | PB20416A-01  | TERMINAL BOARD ASSEMBLY |             |
| D2    | 1SS133       | DIODE                   |             |
| or    | MA165        | DIODE                   |             |
| D3    | 1SS133       | DIODE                   |             |
| or    | MA165        | DIODE                   |             |
| R1    | QRD161J-750  | RESISTOR                | 75Ω, 1/6W   |
| R2    | QRD161J-750  | RESISTOR                | 75Ω, 1/6W   |
| R3    | QRD161J-750  | RESISTOR                | 75Ω, 1/6W   |
| R4    | QRD161J-750  | RESISTOR                | 75Ω, 1/6W   |
| R5    | QRD161J-750  | RESISTOR                | 75Ω, 1/6W   |
| R7    | QRD161J-102  | RESISTOR                | 1KΩ, 1/6W   |
| R8    | QRD161J-102  | RESISTOR                | 1KΩ, 1/6W   |
| R9    | QRD161J-102  | RESISTOR                | 1KΩ, 1/6W   |
| R10   | QRD161J-102  | RESISTOR                | 1KΩ, 1/6W   |
| R11   | QVZ3518-105  | V RESISTOR, V LOCK      | 1MΩ         |
| C1    | QCSB1HJ-181  | CAPACITOR               | 180PF, 50V  |
| C2    | QCSB1HJ-181  | CAPACITOR               | 180PF, 50V  |
| C3    | QCSB1HJ-471  | CAPACITOR               | 470PF, 50V  |
| C4    | QCSB1HJ-471  | CAPACITOR               | 470PF, 50V  |
| C5    | QETA1AM-103  | E CAPACITOR             | 1000μF, 10V |
| L1    | PU59152-3R9J | COIL                    | 3.9μH       |
| L2    | PU59152-3R9J | COIL                    | 3.9μH       |
| LC1   | PU59885-102  | N FILTER                |             |
| LC2   | PU59885-102  | N FILTER                |             |
| LC3   | PU59885-102  | N FILTER                |             |
| LC4   | PU59885-102  | N FILTER                |             |
| LC7   | PU59885-102  | N FILTER                |             |
| LC8   | PU59885-102  | N FILTER                |             |
| K1    | PU60281-5    | FERRITE BEADS           |             |
| SCW1  | SDSF2608Z    | SCREW, X3               |             |
| △ TB1 | PQ20677-16   | TERMINAL BOARD          |             |
| CN1   | PU59513-5    | CAP HOUSING             |             |
| CN14  | PU58929-18   | HOUSING                 |             |
| CN15  | PU58929-13   | HOUSING                 |             |

#△ REF No. PART No. PART NAME, DESCRIPTION  
 \*\*\* \*\*

# 9. IF BOARD ASSEMBLY (07)

PWBA PB10047AV IF BOARD ASSEMBLY

IC1 M51365SP IC

|     |                  |             |  |
|-----|------------------|-------------|--|
| Q1  | 2SC3313CTA       | TRANSISTOR  |  |
| Q2  | 2SC3354          | TRANSISTOR  |  |
| Q3  | 2SC1317(RS)      | TRANSISTOR  |  |
| Q4  | 2SC1740(RS)      | TRANSISTOR  |  |
|     | or 2SC536SPA(FG) | TRANSISTOR  |  |
|     | or 2SC3311A(RS)  | TRANSISTOR  |  |
| Q5  | 2SC1740(RS)      | TRANSISTOR  |  |
|     | or 2SC3311A(RS)  | TRANSISTOR  |  |
|     | or 2SC536SPA(FG) | TRANSISTOR  |  |
| Q6  | 2SA933(RS)       | TRANSISTOR  |  |
|     | or 2SA1309AR, S  | TRANSISTOR  |  |
| Q7  | 2SC1740(RS)      | TRANSISTOR  |  |
|     | or 2SC3311A(RS)  | TRANSISTOR  |  |
|     | or 2SC536SPA(FG) | TRANSISTOR  |  |
| Q10 | 2SC3354          | TRANSISTOR  |  |
| Q11 | 2SC1740(RS)      | TRANSISTOR  |  |
|     | or 2SC3199(GJK)  | TRANSISTOR  |  |
|     | or 2SC536SPA(FG) | TRANSISTOR  |  |
|     | or 2SC3311A(RS)  | TRANSISTOR  |  |
| Q12 | DTC144ES         | TRANSISTOR  |  |
|     | or 2SC3399       | TRANSISTOR  |  |
|     | UN4213           | TRANSISTOR  |  |
| Q13 | DTC144ES         | TRANSISTOR  |  |
|     | or 2SC3399       | TRANSISTOR  |  |
|     | UN4213           | TRANSISTOR  |  |
| D1  | MTZ10D           | ZENER DIODE |  |
| D6  | 1SS133           | DIODE       |  |
| D7  | 1SS133           | DIODE       |  |
| D8  | 1SS133           | DIODE       |  |

|     |                |                    |             |
|-----|----------------|--------------------|-------------|
| R4  | NRD187J-332NBU | RESISTOR           | 3.3KΩ, 1/8W |
| R5  | NRD187J-151NBU | RESISTOR           | 150Ω, 1/8W  |
| R6  | NRD187J-182NBU | RESISTOR           | 1.8KΩ, 1/8W |
| R7  | NRD187J-331NBU | RESISTOR           | 330Ω, 1/8W  |
| R8  | NRD187J-681NBU | RESISTOR           | 680Ω, 1/8W  |
| R10 | NRD187J-271NBU | RESISTOR           | 270Ω, 1/8W  |
| R11 | NRD187J-101NBU | RESISTOR           | 100Ω, 1/8W  |
| R15 | NRD187J-271NBU | RESISTOR           | 270Ω, 1/8W  |
| R17 | NRD187J-562NBU | RESISTOR           | 5.6KΩ, 1/8W |
| R18 | NRD187J-332NBU | RESISTOR           | 3.3KΩ, 1/8W |
| R19 | NRD187J-222NBU | RESISTOR           | 2.2KΩ, 1/8W |
| R20 | NRD187J-222NBU | RESISTOR           | 2.2KΩ, 1/8W |
| R21 | QVZ3518-472    | V RESISTOR, RF AGC | 4.7KΩ       |
|     | or QVZ3523-472 | V RESISTOR         | 4.7KΩ       |
| R22 | NRD187J-824NBU | RESISTOR           | 820KΩ, 1/8W |

| #△ REF No. | PART No.       | PART NAME, DESCRIPTION  |               |
|------------|----------------|-------------------------|---------------|
| R24        | NRD187J-821NBU | RESISTOR                | 820Ω, 1/8W    |
| R31        | NRD187J-222NBU | RESISTOR                | 2.2KΩ, 1/8W   |
| R32        | NRD187J-102NBU | RESISTOR                | 1KΩ, 1/8W     |
| R33        | NRD187J-223NBU | RESISTOR                | 22KΩ, 1/8W    |
| R34        | NRD187J-470NBU | RESISTOR                | 47Ω, 1/8W     |
| R35        | NRD187J-561NBU | RESISTOR                | 560Ω, 1/8W    |
| R36        | NRD187J-561NBU | RESISTOR                | 560Ω, 1/8W    |
| R37        | NRD187J-121NBU | RESISTOR                | 120Ω, 1/8W    |
| R38        | NRD187J-182NBU | RESISTOR                | 1.8KΩ, 1/8W   |
| R39        | NRD187J-272NBU | RESISTOR                | 2.7KΩ, 1/8W   |
| R40        | QVZ3518-103    | V RESISTOR, COLOR LEVEL | 10KΩ          |
|            | or QVZ3523-103 | V RESISTOR              | 10KΩ          |
| R41        | NRD187J-222NBU | RESISTOR                | 2.2KΩ, 1/8W   |
| R45        | NRD187J-471NBU | RESISTOR                | 470Ω, 1/8W    |
| R46        | NRD187J-104NBU | RESISTOR                | 100KΩ, 1/8W   |
| R47        | NRD187J-153NBU | RESISTOR                | 15KΩ, 1/8W    |
| R48        | NRD187J-392NBU | RESISTOR                | 3.9KΩ, 1/8W   |
| R49        | NRD187J-103NBU | RESISTOR                | 10KΩ, 1/8W    |
| R50        | NRD187J-471NBU | RESISTOR                | 470Ω, 1/8W    |
| R51        | NRD187J-223NBU | RESISTOR                | 22KΩ, 1/8W    |
| R52        | NRD187J-223NBU | RESISTOR                | 22KΩ, 1/8W    |
| R53        | NRD187J-103NBU | RESISTOR                | 10KΩ, 1/8W    |
| R54        | NRD187J-682NBU | RESISTOR                | 6.8KΩ, 1/8W   |
| R57        | NRD187J-153NBU | RESISTOR                | 15KΩ, 1/8W    |
| R62        | NRD187J-392NBU | RESISTOR                | 3.9KΩ, 1/8W   |
| R63        | NRD187J-470NBU | RESISTOR                | 47Ω, 1/8W     |
| R64        | NRD187J-182NBU | RESISTOR                | 1.8KΩ, 1/8W   |
| R65        | NRD187J-221NBU | RESISTOR                | 220Ω, 1/8W    |
| R71        | NRD187J-681NBU | RESISTOR                | 680Ω, 1/8W    |
| R72        | NRD187J-470NBU | RESISTOR                | 47Ω, 1/8W     |
| R73        | NRD187J-331NBU | RESISTOR                | 330Ω, 1/8W    |
| R82        | NRD187J-680NBU | RESISTOR                | 68Ω, 1/8W     |
| R83        | NRD187J-331NBU | RESISTOR                | 330Ω, 1/8W    |
| R84        | NRD187J-123NBU | RESISTOR                | 12KΩ, 1/8W    |
| R85        | NRD187J-123NBU | RESISTOR                | 12KΩ, 1/8W    |
| R86        | NRD187J-331NBU | RESISTOR                | 330Ω, 1/8W    |
| R101       | NRD187J-182NBU | RESISTOR                | 1.8KΩ, 1/8W   |
| R102       | NRD187J-222NBU | RESISTOR                | 2.2KΩ, 1/8W   |
| R104       | QRD161J-393    | RESISTOR                | 39KΩ, 1/6W    |
| C2         | NCT02CH-5R6NBR | CAPACITOR               | 5.6PF         |
| C3         | QCT25HH-101    | CAPACITOR               | 100PF         |
| C4         | NCT02CH-3R9NBR | CAPACITOR               | 3.9PF         |
| C5         | NCB71HK-102NBR | CAPACITOR               | 0.001μF, 50V  |
| C6         | NCX71CM-222NBR | CAPACITOR               | 0.0022μF, 16V |
| C7         | NCB71HK-102NBR | CAPACITOR               | 0.001μF, 50V  |
| C8         | NCB71HK-102NBR | CAPACITOR               | 0.001μF, 50V  |
| C10        | QETC1CM-336    | E CAPACITOR             | 33μF, 16V     |
| C11        | NCY71CM-103NBR | CAPACITOR               | 0.01μF, 16V   |
| C13        | NCX71CM-222NBR | CAPACITOR               | 0.0022μF, 16V |
| C14        | PU57601-474ME  | E CAPACITOR             | 0.47μF, 16V   |
| C15        | QETC1CM-336    | E CAPACITOR             | 33μF, 16V     |
| C16        | NCX71CM-222NBR | CAPACITOR               | 0.0022μF, 16V |

| #    | REF No. | PART No.       | PART NAME, DESCRIPTION |                     |
|------|---------|----------------|------------------------|---------------------|
| C17  |         | NC71EZ-223NBR  | CAPACITOR              | 0.022 $\mu$ F, 25V  |
| C19  |         | NCY71CM-103NBR | CAPACITOR              | 0.01 $\mu$ F, 16V   |
| C20  |         | NCY71CM-103NBR | CAPACITOR              | 0.01 $\mu$ F, 16V   |
| C21  |         | NCB71HK-101NBR | CAPACITOR              | 100PF, 50V          |
| C24  |         | QETC1HM-105    | E CAPACITOR            | 1 $\mu$ F, 50V      |
| C25  |         | NCX71CM-222NBR | CAPACITOR              | 0.0022 $\mu$ F, 16V |
| C26  |         | QFN31HK-222    | M CAPACITOR            | 0.0022 $\mu$ F, 50V |
| C27  |         | QETC1HM-474    | E CAPACITOR            | 0.47 $\mu$ F, 50V   |
| C29  |         | NCS71HJ-560NBR | CAPACITOR              | 56PF, 50V           |
| C31  |         | QETC1HM-335    | E CAPACITOR            | 3.3 $\mu$ F, 50V    |
| C32  |         | NC71EZ-223NBR  | CAPACITOR              | 0.022 $\mu$ F, 25V  |
| C33  |         | QETC1HM-474    | E CAPACITOR            | 0.47 $\mu$ F, 50V   |
| C41  |         | NCB71HK-102NBR | CAPACITOR              | 0.001 $\mu$ F, 50V  |
| C43  |         | NCX71CM-222NBR | CAPACITOR              | 0.0022 $\mu$ F, 16V |
| C44  |         | NCB71HK-102NBR | CAPACITOR              | 0.001 $\mu$ F, 50V  |
| C45  |         | NCB71HK-102NBR | CAPACITOR              | 0.001 $\mu$ F, 50V  |
| C46  |         | NCB71HK-102NBR | CAPACITOR              | 0.001 $\mu$ F, 50V  |
| C50  |         | QETC1CM-336    | E CAPACITOR            | 33 $\mu$ F, 16V     |
| C56  |         | QETC1CM-336    | E CAPACITOR            | 33 $\mu$ F, 16V     |
| C57  |         | QEN41CM-336    | NP E CAPACITOR         | 33 $\mu$ F, 16V     |
|      | or      | QEN61CM-336    | NP E CAPACITOR         | 33 $\mu$ F, 16V     |
| C58  |         | NCS71HJ-100NBR | CAPACITOR              | 10PF, 50V           |
| C60  |         | NCB71HK-102NBR | CAPACITOR              | 0.001 $\mu$ F, 50V  |
| C63  |         | NCB71HK-102NBR | CAPACITOR              | 0.001 $\mu$ F, 50V  |
| C64  |         | NCB71HK-391NBR | CAPACITOR              | 390PF, 50V          |
| L1   |         | PU60025-1R5    | COIL                   | 1.5 $\mu$ H         |
| L2   |         | PU60025-R82    | COIL                   | 0.82 $\mu$ H        |
| L3   |         | PU60025-1R8    | COIL                   | 1.8 $\mu$ H         |
| L4   |         | PU59152-5R2J   | COIL                   | 8.2 $\mu$ H         |
| L5   |         | PU59152-220J   | COIL                   | 22 $\mu$ H          |
| L6   |         | PU59152-6R8K   | COIL                   | 6.8 $\mu$ H         |
| L7   |         | PU59152-R22K   | COIL                   | 0.22 $\mu$ H        |
| L9   |         | PU59152-6R8K   | COIL                   | 6.8 $\mu$ H         |
| CF1  |         | PU48295-2      | N FILTER               |                     |
| CF3  |         | PU32890-2      | CERAMIC FILTER         |                     |
| CF4  |         | PU48295        | CERAMIC FILTER         |                     |
| CF5  |         | PU32890-4      | CERAMIC FILTER         |                     |
| SAW1 |         | PU60804        | SAW FILTER             |                     |
| SAW2 |         | PU60765        | SAW FILTER             |                     |
| T1   |         | PU60042-2      | COIL                   |                     |
| T2   |         | PU60497        | IF. TRANSFORMER        |                     |
| T4   |         | PU59489        | COIL                   |                     |
| T5   |         | PU60046        | IF. TRANSFORMER        |                     |
| T8   |         | PU60259        | COIL                   |                     |
| JP1  |         | PU59935-16     | TERMINAL               |                     |

| #     | REF No. | PART No. | PART NAME, DESCRIPTION |
|-------|---------|----------|------------------------|
| ***** |         |          |                        |

## 10. TUNER CTL BOARD ASSEMBLY (08)

|        |                    |                          |             |
|--------|--------------------|--------------------------|-------------|
| PWBA   | PB20383A           | TUNER CONTROL BOARD ASSY |             |
| △ RF1  | PU60817-1-1        | RF CONVERTER/MIX BOOSTER |             |
| △ TNR1 | PERF0021           | UHF/VHF TUNER            |             |
| IC1    | UPD75006CU-041     | IC                       |             |
|        | or UPD75P008CU6041 | IC                       |             |
| IC2    | MSM16811RS         | IC                       |             |
| Q1     | DTC144ES           | TRANSISTOR               |             |
| Q2     | DTC144ES           | TRANSISTOR               |             |
| Q3     | 2SB1010(QR)        | TRANSISTOR               |             |
| Q4     | 2SD1856            | TRANSISTOR               |             |
| Q5     | 28C3313CTA         | TRANSISTOR               |             |
| Q6     | 28C3313CTA         | TRANSISTOR               |             |
| Q7     | 28C3313CTA         | TRANSISTOR               |             |
| Q8     | 2SC1740S(S)        | TRANSISTOR               |             |
| Q9     | DTC144ES           | TRANSISTOR               |             |
| Q10    | 2SK381(C)          | FE TRANSISTOR            |             |
| Q11    | 2SK381(C)          | FE TRANSISTOR            |             |
| Q12    | DTC144ES           | TRANSISTOR               |             |
| D1     | E-452-2-T2         | DIODE                    |             |
| D2     | HZT33-02           | ZENER DIODE              |             |
| D3     | 1SS133             | DIODE                    |             |
| D4     | MTZ6.8B            | ZENER DIODE              |             |
| R1     | QRD161J-472        | RESISTOR                 | 4.7KΩ, 1/6W |
| R2     | QRD161J-102        | RESISTOR                 | 1KΩ, 1/6W   |
| R3     | QRD161J-102        | RESISTOR                 | 1KΩ, 1/6W   |
| R4     | QRD161J-222        | RESISTOR                 | 2.2KΩ, 1/6W |
| R5     | QRD161J-222        | RESISTOR                 | 2.2KΩ, 1/6W |
| R6     | QRD161J-222        | RESISTOR                 | 2.2KΩ, 1/6W |
| R7     | QRD161J-222        | RESISTOR                 | 2.2KΩ, 1/6W |
| R8     | QRD161J-102        | RESISTOR                 | 1KΩ, 1/6W   |
| R9     | QRD161J-102        | RESISTOR                 | 1KΩ, 1/6W   |
| R10    | QRD161J-102        | RESISTOR                 | 1KΩ, 1/6W   |
| R11    | QRD161J-102        | RESISTOR                 | 1KΩ, 1/6W   |
| R12    | QRD161J-102        | RESISTOR                 | 1KΩ, 1/6W   |
| R13    | QRD161J-102        | RESISTOR                 | 1KΩ, 1/6W   |
| R14    | QRD161J-105        | RESISTOR                 | 1MΩ, 1/6W   |
| R15    | QRD161J-153        | RESISTOR                 | 15KΩ, 1/6W  |
| R16    | QRD161J-104        | RESISTOR                 | 100KΩ, 1/6W |
| R17    | QRD161J-102        | RESISTOR                 | 1KΩ, 1/6W   |
| R18    | QRD161J-153        | RESISTOR                 | 15KΩ, 1/6W  |
| R19    | QRD161J-222        | RESISTOR                 | 2.2KΩ, 1/6W |
| R20    | QRD161J-331        | RESISTOR                 | 330Ω, 1/6W  |
| R25    | QRD162J-272        | RESISTOR                 | 2.7KΩ, 1/6W |

| #△ | REF No. | PART No.    | PART NAME, DESCRIPTION |             |
|----|---------|-------------|------------------------|-------------|
|    | R26     | QRD161J-151 | RESISTOR               | 150Ω, 1/6W  |
|    | R27     | QRD161J-222 | RESISTOR               | 2.2KΩ, 1/6W |
|    | R28     | QRD161J-472 | RESISTOR               | 4.7KΩ, 1/6W |
|    | R29     | QRD161J-331 | RESISTOR               | 330Ω, 1/6W  |
|    | R30     | QRD161J-472 | RESISTOR               | 4.7KΩ, 1/6W |
|    | R31     | QRD161J-222 | RESISTOR               | 2.2KΩ, 1/6W |
|    | R32     | QRD161J-331 | RESISTOR               | 330Ω, 1/6W  |
|    | R33     | QRD161J-560 | RESISTOR               | 56Ω, 1/6W   |
|    | R34     | QRD161J-123 | RESISTOR               | 12KΩ, 1/6W  |
|    | R35     | QRD161J-364 | RESISTOR               | 360KΩ, 1/6W |
|    | R36     | QRD161J-182 | RESISTOR               | 1.8KΩ, 1/6W |
|    | R37     | QRD161J-682 | RESISTOR               | 6.8KΩ, 1/6W |
|    | R38     | QRD161J-105 | RESISTOR               | 1MΩ, 1/6W   |

RA1 QRB077J-104 RESISTOR ARRAY  
or QRB079J-104 NETWORK RESISTOR

C1 QCVB1CN-103 CAPACITOR 0.01μF, 16V  
C5 QCF11HP-473 CAPACITOR 0.047μF, 50V  
C6 QETC1AM-107 E CAPACITOR 100μF, 10V  
C10 QETC1CM-107 E CAPACITOR 100μF, 16V

C11 QCBBIHJ-471 CAPACITOR 470PF, 50V  
C12 QCBBIHJ-102 CAPACITOR 0.001μF, 50V  
C13 QETC1HM-106 E CAPACITOR 10μF, 50V  
C14 QCBBIHJ-102 CAPACITOR 0.001μF, 50V  
C15 QETC1HM-225 E CAPACITOR 2.2μF, 50V  
C17 QETC1AM-107 E CAPACITOR 100μF, 10V  
C18 QETC1AM-107 E CAPACITOR 100μF, 10V  
C19 QETC1CM-106 E CAPACITOR 10μF, 16V  
C20 QCVB1CN-103 CAPACITOR 0.01μF, 16V

C21 QETC1CM-476 E CAPACITOR 47μF, 16V  
C28 QCBBIHJ-102 CAPACITOR 0.001μF, 50V  
C29 QCBBIHJ-102 CAPACITOR 0.001μF, 50V  
C30 QCBBIHJ-102 CAPACITOR 0.001μF, 50V  
C32 QCBBIHJ-102 CAPACITOR 0.001μF, 50V  
C33 QCXB1CM-222 CAPACITOR 0.0022μF, 16V  
C34 QCBBIHJ-910 CAPACITOR 91PF, 50V

L1 PU59152-R22J COIL 0.22μH  
or PU59152-R22K COIL 0.22μH  
L3 PU59152-100J COIL 10μH  
L4 PU59152-1R0K COIL 1.0μH  
L5 PU59152-1R0K COIL 1.0μH  
L7 PU59152-2R7K COIL 2.7μH  
L9 PU59152-6R8J COIL 6.8μH  
L10 PU59152-5R6J COIL 5.6μH

△ CF1 PU59545 RESONATOR

HD1 PU36378 HOLDER

WR1 PW30401-BB22S COAXIAL CORD  
or PW30401-BB22T COAXIAL CORD

| #△ | REF No. | PART No.  | PART NAME, DESCRIPTION |
|----|---------|-----------|------------------------|
|    | CN1     | PU58844-7 | CAP HOUSING            |
|    | CN2     | PU58844-9 | CAP HOUSING            |
|    | CN4     | PU58844-5 | CAP HOUSING            |
|    | CN5     | PU58844-6 | CAP HOUSING            |
|    | CN6     | PU59374   | JACK                   |

△ CP1 ICP-N10 CIRCUIT PROTECTOR

\*\*\* \*\*

## 11. AUDIO BOARD ASSEMBLY (09)

PWBA PB20292N AUDIO BOARD ASSEMBLY

IC1 AN3380NK IC  
IC2 TA7381AP IC  
IC3 PB20167A-01 FMA MODULE BOARD ASSY

IC101 UPC78N05 IC

Q1 2SC1740S(RS) TRANSISTOR  
Q2 2SC3311(RS) TRANSISTOR  
Q3 DTC114ES TRANSISTOR  
Q4 2SC1740S(RS) TRANSISTOR  
Q5 DTC114ES TRANSISTOR  
Q6 DTC114ES TRANSISTOR  
Q7 DTC114ES TRANSISTOR  
Q8 DTA114ES TRANSISTOR  
Q9 DTA114ES TRANSISTOR  
Q10 2SC1740S(RS) TRANSISTOR

Q11 2SC1740S(RS) TRANSISTOR  
Q12 DTC143TS TRANSISTOR  
Q13 DTC143TS TRANSISTOR  
Q14 2SC1740S(RS) TRANSISTOR  
Q15 2SC1740S(QR) TRANSISTOR  
Q16 2SC3311(RS) TRANSISTOR  
Q17 DTA114ES TRANSISTOR  
Q18 DTC114ES TRANSISTOR  
Q20 DTA114ES TRANSISTOR

Q23 DTA143TS TRANSISTOR

Q101 2SD1764 TRANSISTOR  
Q102 2SA854S(QR) TRANSISTOR  
Q103 2SA854S(QR) TRANSISTOR

D1 1SS133 DIODE

or MA165 DIODE

D3 1SS133 DIODE

or MA165 DIODE

D5 1SS133 DIODE

or MA165 DIODE

D6 1SS133 DIODE

or MA165 DIODE

D7 1SS133 DIODE

| #Δ   | REF No.     | PART No.                 | PART NAME, DESCRIPTION |
|------|-------------|--------------------------|------------------------|
|      |             | or MA165                 | DIODE                  |
| D8   |             | 1SS133                   | DIODE                  |
|      |             | or MA165                 | DIODE                  |
| D9   |             | HZ2BLL                   | ZENER DIODE            |
|      |             | 1SS133                   | DIODE                  |
| D12  |             | or MA165                 | DIODE                  |
|      |             | 1SS133                   | DIODE                  |
| D16  |             | or MA165                 | DIODE                  |
|      |             | 1SS133                   | DIODE                  |
| D17  |             | or MA165                 | DIODE                  |
|      |             | 1SS133                   | DIODE                  |
| D20  |             | HZ2C3                    | ZENER DIODE            |
|      |             | or UZ2.7BSA              | ZENER DIODE            |
|      |             | HZ12A2                   | ZENER DIODE            |
| D101 |             | 1SS133                   | DIODE                  |
| D102 |             | or MA165                 | DIODE                  |
| R3   | QRD161J-102 | RESISTOR                 | 1KΩ, 1/6W              |
| R4   | QRD161J-682 | RESISTOR                 | 6.8KΩ, 1/6W            |
| R5   | QRD161J-271 | RESISTOR                 | 270Ω, 1/6W             |
| R6   | QRD161J-152 | RESISTOR                 | 1.5KΩ, 1/6W            |
| R7   | QRD161J-222 | RESISTOR                 | 2.2KΩ, 1/6W            |
| R8   | QRD161J-100 | RESISTOR                 | 10Ω, 1/6W              |
| R9   | QVZ3518-473 | V RESISTOR, BIAS ADJ     | 47KΩ                   |
| R10  | QRD161J-333 | RESISTOR                 | 33KΩ, 1/6W             |
| R11  | QRD161J-473 | RESISTOR                 | 47KΩ, 1/6W             |
| R12  | QRD161J-101 | RESISTOR                 | 100Ω, 1/6W             |
| R13  | QRD161J-273 | RESISTOR                 | 27KΩ, 1/6W             |
| R14  | QRD161J-3R9 | RESISTOR                 | 3.9Ω, 1/6W             |
| R15  | QRD161J-103 | RESISTOR                 | 10KΩ, 1/6W             |
| R16  | QRD161J-103 | RESISTOR                 | 10KΩ, 1/6W             |
| R17  | QRD161J-102 | RESISTOR                 | 1KΩ, 1/6W              |
| R20  | QRD161J-183 | RESISTOR                 | 18KΩ, 1/6W             |
| R21  | QRD161J-270 | RESISTOR                 | 27Ω, 1/6W              |
| R22  | QRD161J-470 | RESISTOR                 | 47Ω, 1/6W              |
| R23  | QRD161J-303 | RESISTOR                 | 30KΩ, 1/6W             |
| R25  | QRD161J-103 | RESISTOR                 | 10KΩ, 1/6W             |
| R26  | QRD161J-274 | RESISTOR                 | 270KΩ, 1/6W            |
| R27  | QRD161J-471 | RESISTOR                 | 470Ω, 1/6W             |
| R28  | QVZ3518-102 | V RESISTOR, PB ADJ       | 1KΩ                    |
| R29  | QRD161J-102 | RESISTOR                 | 1KΩ, 1/6W              |
| R31  | QRD161J-151 | RESISTOR                 | 150Ω, 1/6W             |
| R32  | QRD161J-102 | RESISTOR                 | 1KΩ, 1/6W              |
| R33  | QRD161J-102 | RESISTOR                 | 1KΩ, 1/6W              |
| R34  | QRD161J-151 | RESISTOR                 | 150Ω, 1/6W             |
| R40  | QVZ3518-222 | V RESISTOR, EE LEVEL (L) | 2.2KΩ                  |
| R41  | QVZ3518-222 | V RESISTOR, EE LEVEL (R) | 2.2KΩ                  |
| R43  | QRD161J-101 | RESISTOR                 | 100Ω, 1/6W             |
| R44  | QRD161J-101 | RESISTOR                 | 100Ω, 1/6W             |
| R45  | QRD161J-392 | RESISTOR                 | 3.9KΩ, 1/6W            |
| R46  | QRD161J-332 | RESISTOR                 | 3.3KΩ, 1/6W            |
| R47  | QRD161J-123 | RESISTOR                 | 12KΩ, 1/6W             |
| R48  | QRD161J-223 | RESISTOR                 | 22KΩ, 1/6W             |
| R49  | QRD161J-274 | RESISTOR                 | 270KΩ, 1/6W            |
| R50  | QRD161J-222 | RESISTOR                 | 2.2KΩ, 1/6W            |

| #Δ   | REF No.     | PART No.               | PART NAME, DESCRIPTION |
|------|-------------|------------------------|------------------------|
| R51  | QRD161J-222 | RESISTOR               | 2.2KΩ, 1/6W            |
| R52  | QRD161J-103 | RESISTOR               | 10KΩ, 1/6W             |
| R53  | QRD161J-333 | RESISTOR               | 33KΩ, 1/6W             |
| R54  | QRD161J-183 | RESISTOR               | 18KΩ, 1/6W             |
| R55  | QRD161J-332 | RESISTOR               | 3.3KΩ, 1/6W            |
| R56  | QRD161J-272 | RESISTOR               | 2.7KΩ, 1/6W            |
| R57  | QRD161J-181 | RESISTOR               | 180Ω, 1/6W             |
| R58  | QRD161J-333 | RESISTOR               | 33KΩ, 1/6W             |
| R59  | QRD161J-333 | RESISTOR               | 33KΩ, 1/6W             |
| R60  | QRD161J-333 | RESISTOR               | 33KΩ, 1/6W             |
| R62  | QRD161J-333 | RESISTOR               | 33KΩ, 1/6W             |
| R63  | QRD161J-102 | RESISTOR               | 1KΩ, 1/6W              |
| R64  | QRD161J-331 | RESISTOR               | 330Ω, 1/6W             |
| R65  | QRD161J-223 | RESISTOR               | 22KΩ, 1/6W             |
| R66  | QRD161J-6R8 | RESISTOR               | 6.8Ω, 1/6W             |
| R67  | QRD161J-333 | RESISTOR               | 33KΩ, 1/6W             |
| R68  | QRD161J-333 | RESISTOR               | 33KΩ, 1/6W             |
| R70  | QRD161J-273 | RESISTOR               | 27KΩ, 1/6W             |
| R72  | QRD161J-392 | RESISTOR               | 3.9KΩ, 1/6W            |
| R73  | QVZ3518-332 | V RESISTOR, IND(L)     | 3.3KΩ                  |
| R74  | QVZ3518-332 | V RESISTOR, IND(R)     | 3.3KΩ                  |
| R76  | QRD161J-151 | RESISTOR               | 150Ω, 1/6W             |
| R80  | QVZ3518-331 | V RESISTOR, FM REC ADJ | 330Ω                   |
| R81  | QRD161J-103 | RESISTOR               | 10KΩ, 1/6W             |
| R82  | QRD161J-153 | RESISTOR               | 15KΩ, 1/6W             |
| R83  | QRD161J-151 | RESISTOR               | 150Ω, 1/6W             |
| R84  | QRD161J-151 | RESISTOR               | 150Ω, 1/6W             |
| R85  | QRD161J-222 | RESISTOR               | 2.2KΩ, 1/6W            |
| R86  | QRD161J-103 | RESISTOR               | 10KΩ, 1/6W             |
| R87  | QRD161J-102 | RESISTOR               | 1KΩ, 1/6W              |
| R88  | QRD161J-102 | RESISTOR               | 1KΩ, 1/6W              |
| R89  | QRD161J-620 | RESISTOR               | 82Ω, 1/6W              |
| R91  | QRD161J-103 | RESISTOR               | 10KΩ, 1/6W             |
| R95  | QRD161J-271 | RESISTOR               | 270Ω, 1/6W             |
| R101 | QRD161J-182 | RESISTOR               | 1.8KΩ, 1/6W            |
| R103 | QRD161J-103 | RESISTOR               | 10KΩ, 1/6W             |
| R104 | QRD161J-222 | RESISTOR               | 2.2KΩ, 1/6W            |
| R105 | QRD161J-103 | RESISTOR               | 10KΩ, 1/6W             |
| R106 | QRD161J-691 | RESISTOR               | 680Ω, 1/6W             |
| R107 | QRD161J-152 | RESISTOR               | 1.5KΩ, 1/6W            |
| R108 | QRD161J-391 | RESISTOR               | 390Ω, 1/6W             |
| R109 | QRD161J-332 | RESISTOR               | 3.3KΩ, 1/6W            |
| R110 | QRD161J-153 | RESISTOR               | 15KΩ, 1/6W             |
| C1   | QETC1CM-106 | E CAPACITOR            | 10μF, 16V              |
| C2   | QETCIAM-476 | E CAPACITOR            | 47μF, 10V              |
| C3   | QEPB1CM-106 | NP E CAPACITOR         | 10μF, 16V              |
| C4   | QETC1CM-106 | E CAPACITOR            | 10μF, 16V              |
| C5   | QETC1CM-226 | E CAPACITOR            | 22μF, 16V              |
| C6   | QETCIAM-336 | E CAPACITOR            | 33μF, 10V              |
| C7   | QETCIAM-476 | E CAPACITOR            | 47μF, 10V              |
| C8   | QCBBIHK-102 | CAPACITOR              | 0.001μF, 50V           |
| C9   | QCBBIHK-101 | CAPACITOR              | 100PF, 50V             |
| C10  | QETCIAM-336 | E CAPACITOR            | 33μF, 10V              |
| C11  | QETCIAM-107 | E CAPACITOR            | 100μF, 10V             |

| #△ | REF No. | PART No.       | PART NAME, DESCRIPTION    |
|----|---------|----------------|---------------------------|
|    | C12     | QETC1CM-226    | E CAPACITOR 22μF, 16V     |
|    | C13     | QETB1CM-106    | E CAPACITOR 10μF, 16V     |
|    | C14     | QEPB1CM-106    | NP E CAPACITOR 10μF, 16V  |
|    | C15     | QETB1AM-476    | E CAPACITOR 47μF, 10V     |
|    | C16     | QETC1CM-106    | E CAPACITOR 10μF, 16V     |
|    | C17     | QCBBIHJ-331    | CAPACITOR 330PF, 50V      |
|    | C18     | or QFV71HJ-223 | TF CAPACITOR 0.022μF, 50V |
|    | C19     | QCC11EJ-222    | M CAPACITOR 0.022μF, 50V  |
|    | C20     | QCC11EJ-102    | CAPACITOR 0.001μF, 25V    |
|    | C21     | QEK61EM-475    | E CAPACITOR 4.7μF, 25V    |
|    | C24     | QCBBIHJ-561    | CAPACITOR 560PF, 50V      |
|    | C25     | QETC1HM-225    | E CAPACITOR 2.2μF, 50V    |
|    | C26     | QETC1AM-336    | E CAPACITOR 33μF, 10V     |
|    | C27     | QETC0JM-476    | E CAPACITOR 47μF, 6.3V    |
|    | C28     | QFN31HJ-104    | M CAPACITOR 0.1μF, 50V    |
|    | or C29  | QFV71HJ-104    | TF CAPACITOR 0.1μF, 50V   |
|    | C30     | QFV71HJ-473    | TF CAPACITOR 0.047μF, 50V |
|    | C31     | QETC1CM-106    | E CAPACITOR 10μF, 16V     |
|    | C32     | QFN31HJ-123    | M CAPACITOR 0.012μF, 50V  |
|    | C33     | QFV71HJ-274    | TF CAPACITOR 0.27μF, 50V  |
|    | C34     | QEB51CM-226    | E CAPACITOR 22μF, 16V     |
|    | C35     | QEB51HM-105    | E CAPACITOR 1μF, 50V      |
|    | C36     | QETB1CM-106    | E CAPACITOR 10μF, 16V     |
|    | C37     | QETC1AM-336    | E CAPACITOR 33μF, 10V     |
|    | C38     | QETC1CM-476    | E CAPACITOR 47μF, 16V     |
|    | C39     | QETC1AM-336    | E CAPACITOR 33μF, 10V     |
|    | C40     | QETC1CM-106    | E CAPACITOR 10μF, 16V     |
|    | C41     | QETC1CM-476    | E CAPACITOR 47μF, 16V     |
|    | C42     | QETC1HM-225    | E CAPACITOR 2.2μF, 50V    |
|    | C43     | QETC1CM-106    | E CAPACITOR 10μF, 16V     |
|    | C44     | QETC1HM-225    | E CAPACITOR 2.2μF, 50V    |
|    | C45     | QEN61HM-225    | NP E CAPACITOR 2.2μF, 50V |
|    | C46     | QEN61HM-225    | NP E CAPACITOR 2.2μF, 50V |
|    | C47     | QETC1HM-225    | E CAPACITOR 2.2μF, 50V    |
|    | C49     | QCF31HP-223    | CAPACITOR 0.022μF, 50V    |
|    | C50     | or QFV71HJ-104 | TF CAPACITOR 0.1μF, 50V   |
|    | or C51  | QFN31HJ-104    | M CAPACITOR 0.1μF, 50V    |
|    | or C52  | QFV81HJ-224    | TF CAPACITOR 0.22μF, 50V  |
|    | C53     | QCF31HP-223    | CAPACITOR 0.022μF, 50V    |
|    | C54     | QEK60JM-107    | E CAPACITOR 100μF, 6.3V   |
|    | C55     | QCVB1CN-103    | CAPACITOR 0.01μF, 16V     |
|    | C56     | QFV81HJ-224    | TF CAPACITOR 0.22μF, 50V  |
|    | C57     | QCSB1HJ-330    | CAPACITOR 33PF, 50V       |
|    | C58     | QCBBIHJ-331    | CAPACITOR 330PF, 50V      |
|    | C59     | QCBBIHJ-102    | CAPACITOR 0.001μF, 50V    |
|    | C60     | QCVB1CN-103    | CAPACITOR 0.01μF, 16V     |
|    | C61     | QCVB1CN-103    | CAPACITOR 0.01μF, 16V     |
|    | C62     | QCVB1CN-103    | CAPACITOR 0.01μF, 16V     |
|    | C63     | QCC11EJ-272    | CAPACITOR 0.0027μF, 25V   |
|    | C66     | QETC1CM-106    | E CAPACITOR 10μF, 16V     |
|    | C67     | QETC1CM-106    | E CAPACITOR 10μF, 16V     |
|    | C68     | QETC1HM-225    | E CAPACITOR 2.2μF, 50V    |
|    | C69     | QETC1HM-225    | E CAPACITOR 2.2μF, 50V    |

| #△ | REF No. | PART No.       | PART NAME, DESCRIPTION               |
|----|---------|----------------|--------------------------------------|
|    | C70     | QCBBIHJ-391    | CAPACITOR 390PF, 50V                 |
|    | C71     | QCBBIHJ-391    | CAPACITOR 390PF, 50V                 |
|    | C72     | QCBBIHK-561    | CAPACITOR 560PF, 50V                 |
|    | C73     | QCBBIHK-561    | CAPACITOR 560PF, 50V                 |
|    | C74     | QCC11EJ-332    | CAPACITOR 0.0033μF, 25V              |
|    | C75     | QCC11EJ-102    | CAPACITOR 0.001μF, 25V               |
|    | C76     | or QFV71HJ-333 | TF CAPACITOR 0.033μF, 50V            |
|    | C77     | QETC1CM-106    | M CAPACITOR 0.033μF, 50V             |
|    | C79     | QCC11EJ-273    | E CAPACITOR 10μF, 16V                |
|    | C101    | QEK61EM-336    | E CAPACITOR 33μF, 25V                |
|    | C102    | QCBBIHK-102    | CAPACITOR 0.001μF, 50V               |
|    | C103    | QEK61HM-105    | E CAPACITOR 1μF, 50V                 |
|    | C104    | QETC1CM-106    | E CAPACITOR 10μF, 16V                |
|    | C105    | QFV81HJ-153    | TF CAPACITOR 0.015μF, 50V            |
|    | C106    | QCBBIHJ-681    | CAPACITOR 680PF, 50V                 |
|    | C107    | QCBBIHJ-391    | CAPACITOR 390PF, 50V                 |
|    | L1      | PU54223-101J   | COIL 100μH                           |
|    | L3      | PU58308-392J   | COIL 3.9mH                           |
|    | L4      | PU54223-221J   | COIL 220μH                           |
|    | L5      | PU54223-101J   | COIL 100μH                           |
|    | BPF1    | PU60610        | BPF                                  |
|    | BPF2    | PU60611        | BPF                                  |
|    | △ T1    | PU60320        | OSC TRANSFORMER                      |
|    | △ T2    | PU60321        | OSC TRANSFORMER                      |
|    | HN1     | PU58018-1-2    | PWB HINGE, X2                        |
|    | △ HS1   | PU60185        | HEAT SINK, FOR Q101                  |
|    | HS2     | PU60261        | HEAT SINK, FOR IC101                 |
|    | SCW1    | DPSP3008Z      | SCREW, FOR Q101                      |
|    | SLD1    | PU59960        | P/R AMP SHIELD1                      |
|    | SLD2    | PU59961        | P/R AMP SHIELD2                      |
|    | SLD3    | PQ43345-1-1    | SHIELD PLATE                         |
|    | TP31    | PU55774        | TEST PIN, X7, (TP31-34, 53, 54, GND) |
|    | CN1     | PU58844-3Y     | CAP HOUSING                          |
|    | CN2     | PU59555-8      | CAP HOUSING                          |
|    | CN3     | PU58844-2      | CAP HOUSING                          |
|    | CN4     | PU58555-5      | CAP HOUSING                          |
|    | CN5     | PU58844-4      | CAP HOUSING                          |
|    | CN6     | PU58844-2      | CAP HOUSING                          |
|    | CN7     | PU58844-4      | CAP HOUSING                          |
|    | CN8     | PU58844-3R     | CAP HOUSING                          |
|    | CN8     | PU58844-3      | CAP HOUSING                          |
|    | CN9     | PU58844-8      | CAP HOUSING                          |
|    | CN10    | PU58844-5      | CAP HOUSING                          |
|    | CN11    | PU58844-3      | CAP HOUSING                          |
|    | CN12    | PU59555-6      | CAP HOUSING                          |
|    | CN14    | PU58844-2Y     | CAP HOUSING                          |
|    | CN16    | PU58844-2      | CAP HOUSING                          |



| # | REF No. | PART No. | PART NAME, DESCRIPTION |
|---|---------|----------|------------------------|
| △ | CP1     | ICP-F20  | CIRCUIT PROTECTOR      |

\*\*\*\*\*

## 12. AUDIO/VIDEO IN OUT BOARD ASSY (10)

|       |             |                          |
|-------|-------------|--------------------------|
| PWBA  | PB20429A-01 | AV IN/OUT BOARD ASSEMBLY |
| SLD1  | PQ43207     | SHIELD COVER             |
| CN1   | PU58844-8   | CAP HOUSING              |
| CN2   | PU58844-3   | CAP HOUSING              |
| CN3   | PU59555-4   | CAP HOUSING              |
| CN4   | PU58844-4   | CAP HOUSING              |
| CN16  | PU58929-16  | HOUSING                  |
| CN17  | PU58929-15  | HOUSING                  |
| CN301 | PU58844-5   | CAP HOUSING              |
| CN302 | PU58844-4   | CAP HOUSING              |
| CN303 | PU58844-6   | CAP HOUSING              |
| CN304 | PU58844-6   | CAP HOUSING              |
| CN305 | PU58844-7   | CAP HOUSING              |
| CN306 | PU58844-6   | CAP HOUSING              |
| CN307 | PU58844-4   | CAP HOUSING              |
| CN308 | PU59555-9   | CAP HOUSING              |
| CN309 | PU58844-6   | CAP HOUSING              |
| CN310 | PU59555-5   | CAP HOUSING              |
| CN311 | PU59555-3   | CAP HOUSING              |

## — AUDIO SECTION —

|     |                    |            |             |
|-----|--------------------|------------|-------------|
| IC1 | TC4052BP           | IC         |             |
|     | or MC14052BCP      | IC         |             |
| IC2 | M5218P             | IC         |             |
| IC3 | M5218P             | IC         |             |
| Q1  | 2SD1450S, T        | TRANSISTOR |             |
| Q2  | 2SC1740S(QRS)      | TRANSISTOR |             |
|     | or 2SC3199(GB)-TJK | TRANSISTOR |             |
| Q3  | 2SC1740S(QRS)      | TRANSISTOR |             |
|     | or 2SC3199(GB)-TJK | TRANSISTOR |             |
| R1  | QRD161J-102        | RESISTOR   | 1KΩ, 1/6W   |
| R2  | QRD161J-102        | RESISTOR   | 1KΩ, 1/6W   |
| R3  | QRD161J-102        | RESISTOR   | 1KΩ, 1/6W   |
| R4  | QRD161J-102        | RESISTOR   | 1KΩ, 1/6W   |
| R5  | QRD161J-102        | RESISTOR   | 1KΩ, 1/6W   |
| R6  | QRD161J-102        | RESISTOR   | 1KΩ, 1/6W   |
| R7  | QRD161J-332        | RESISTOR   | 3.3KΩ, 1/6W |
| R8  | QRD161J-332        | RESISTOR   | 3.3KΩ, 1/6W |
| R9  | QRD161J-224        | RESISTOR   | 220KΩ, 1/6W |

| # | REF No. | PART No.     | PART NAME, DESCRIPTION |             |
|---|---------|--------------|------------------------|-------------|
|   | R10     | QRD161J-103  | RESISTOR               | 10KΩ, 1/6W  |
|   | R11     | QRD161J-103  | RESISTOR               | 10KΩ, 1/6W  |
|   | R12     | QRD161J-222  | RESISTOR               | 2.2KΩ, 1/6W |
|   | R13     | QRD161J-122  | RESISTOR               | 1.2KΩ, 1/6W |
|   | R14     | QRD161J-101  | RESISTOR               | 100Ω, 1/6W  |
|   | R15     | QRD161J-103  | RESISTOR               | 10KΩ, 1/6W  |
|   | R16     | QRD161J-473  | RESISTOR               | 47KΩ, 1/6W  |
|   | R17     | QRD161J-473  | RESISTOR               | 47KΩ, 1/6W  |
|   | R18     | QRD161J-104  | RESISTOR               | 100KΩ, 1/6W |
|   | R19     | QRD161J-0R0  | RESISTOR               | 0Ω, 1/6W    |
|   | R20     | QRD161J-561  | RESISTOR               | 560Ω, 1/6W  |
|   | R21     | QRD161J-222  | RESISTOR               | 2.2KΩ, 1/6W |
|   | R22     | QRD161J-0R0  | RESISTOR               | 0Ω, 1/6W    |
|   | R23     | QRD161J-682  | RESISTOR               | 6.8KΩ, 1/6W |
|   | R24     | QRD161J-302  | RESISTOR               | 3KΩ, 1/6W   |
|   | R25     | QRD161J-302  | RESISTOR               | 3KΩ, 1/6W   |
|   | R26     | QRD161J-0R0  | RESISTOR               | 0Ω, 1/6W    |
|   | R27     | QRD161J-682  | RESISTOR               | 6.8KΩ, 1/6W |
|   | R28     | QRD161J-103  | RESISTOR               | 10KΩ, 1/6W  |
|   | R29     | QRD161J-221  | RESISTOR               | 220Ω, 1/6W  |
|   | R30     | QRD161J-823  | RESISTOR               | 82KΩ, 1/6W  |
|   | R31     | QRD161J-224  | RESISTOR               | 220KΩ, 1/6W |
|   | R32     | QRD161J-103  | RESISTOR               | 10KΩ, 1/6W  |
|   | RA1     | QRB045J-223F | RESISTOR ARRAY         |             |
|   | or      | QRB045J-223C | RESISTOR ARRAY         |             |
|   | RA2     | QRB055J-104F | RESISTOR ARRAY         |             |
|   | or      | QRB055J-104C | RESISTOR ARRAY         |             |
|   | RA3     | QRB065J-104F | RESISTOR ARRAY         |             |
|   | or      | QRB065J-104C | RESISTOR ARRAY         |             |
|   | C1      | QEK61CM-106  | E CAPACITOR            | 10μF, 16V   |
|   | C2      | QEK61CM-106  | E CAPACITOR            | 10μF, 16V   |
|   | C3      | QEP61CM-106  | NP E CAPACITOR         | 10μF, 16V   |
|   | C4      | QEK61CM-106  | E CAPACITOR            | 10μF, 16V   |
|   | C5      | QEK61CM-106  | E CAPACITOR            | 10μF, 16V   |
|   | C6      | QEK61CM-106  | E CAPACITOR            | 10μF, 16V   |
|   | C7      | QEK61CM-106  | E CAPACITOR            | 10μF, 16V   |
|   | C8      | QEK61CM-106  | E CAPACITOR            | 10μF, 16V   |
|   | C9      | QEP61CM-106  | NP E CAPACITOR         | 10μF, 16V   |
|   | C10     | QEK61CM-106  | E CAPACITOR            | 10μF, 16V   |
|   | C11     | QEK61CM-106  | E CAPACITOR            | 10μF, 16V   |
|   | C12     | QEK60JM-107  | E CAPACITOR            | 100μF, 6.3V |
|   | C13     | QEK61CM-476  | E CAPACITOR            | 47μF, 16V   |
|   | C14     | QEK61HM-105  | E CAPACITOR            | 1μF, 50V    |
|   | C15     | QEK61CM-476  | E CAPACITOR            | 47μF, 16V   |
|   | C18     | QEP61HM-335  | E CAPACITOR            | 3.3μF, 50V  |
|   | C20     | QEP61HM-335  | E CAPACITOR            | 3.3μF, 50V  |
|   | C22     | QEK61HM-105  | E CAPACITOR            | 1μF, 50V    |
|   | C23     | QEK61HM-105  | E CAPACITOR            | 1μF, 50V    |
|   | SLD1    | PQ42994      | SHIELD PLATE           |             |
|   | SLD2    | PQ42995      | SHIELD CASE            |             |

#Δ REF No. PART No. PART NAME, DESCRIPTION

— VIDEO SECTION —

|       |              |            |
|-------|--------------|------------|
| IC301 | NJM2234M     | IC         |
| IC302 | NJM2234M     | IC         |
| IC303 | NJM2243M     | IC         |
| IC304 | NJM2234M     | IC         |
| IC305 | MC74HC4066F  | SOP IC     |
| IC306 | MM1031XM     | IC         |
|       |              |            |
| Q301  | DTA124EK     | TRANSISTOR |
| Q302  | 2SA1037K(RS) | TRANSISTOR |
| Q303  | 2SA1037K(RS) | TRANSISTOR |
| Q304  | 2SA1037K(RS) | TRANSISTOR |
| Q305  | 2SA1037K(RS) | TRANSISTOR |
| Q306  | 2SA1037K(RS) | TRANSISTOR |
| Q307  | 2SC2412K(RS) | TRANSISTOR |
| Q308  | 2SC2412K(RS) | TRANSISTOR |
| Q309  | 2SC2412K(RS) | TRANSISTOR |
| Q310  | 2SC2412K(RS) | TRANSISTOR |
|       |              |            |
| Q311  | 2SC2412K(RS) | TRANSISTOR |
| Q312  | 2SC2412K(RS) | TRANSISTOR |
| Q313  | 2SC2412K(RS) | TRANSISTOR |
| Q314  | 2SA1037K(RS) | TRANSISTOR |
| Q316  | 2SC2412K(RS) | TRANSISTOR |
| Q317  | 2SC2412K(RS) | TRANSISTOR |
| Q318  | DT144EK      | TRANSISTOR |
| Q319  | 2SA1037K(RS) | TRANSISTOR |
| Q320  | 2SA1037K(RS) | TRANSISTOR |
|       |              |            |
| Q321  | 2SA1036K(R)  | TRANSISTOR |
|       |              |            |
| D301  | DAN202K      | DIODE      |
| D302  | DAN202K      | DIODE      |
| D303  | DAP202K      | DIODE      |
| D304  | DAN202K      | DIODE      |
| D305  | DAN202K      | DIODE      |
| D306  | DAN202K      | DIODE      |
| D307  | DAN202K      | DIODE      |
| D308  | DAN202K      | DIODE      |
| D309  | DAN202K      | DIODE      |
| D310  | DAN202K      | DIODE      |
|       |              |            |
| D311  | DAP202K      | DIODE      |
| D312  | DAN202K      | DIODE      |
| D313  | DAP202K      | DIODE      |
| D314  | DAN202K      | DIODE      |
| D315  | DAN202K      | DIODE      |
| D316  | DAN202K      | DIODE      |
| D317  | DAN202K      | DIODE      |
| D318  | DAN202K      | DIODE      |
| D319  | DAN202K      | DIODE      |
| D320  | DAP202K      | DIODE      |
|       |              |            |
| D321  | DAP202K      | DIODE      |
| D322  | DAN202K      | DIODE      |
| D323  | DAN202K      | DIODE      |
| D324  | DAN202K      | DIODE      |

#Δ REF No. PART No. PART NAME, DESCRIPTION

|      |               |                       |
|------|---------------|-----------------------|
| D325 | DAN202K       | DIODE                 |
| D326 | DAP202K       | DIODE                 |
| D327 | DAP202K       | DIODE                 |
|      |               |                       |
| R301 | QRSA08J-101YN | RESISTOR 100Ω, 1/10W  |
| R302 | QRSA08J-560YN | RESISTOR 56Ω, 1/10W   |
| R303 | QRSA08J-560YN | RESISTOR 56Ω, 1/10W   |
| R304 | QRSA08J-472YN | RESISTOR 4.7KΩ, 1/10W |
| R305 | QRSA08J-472YN | RESISTOR 4.7KΩ, 1/10W |
| R306 | QRSA08J-102YN | RESISTOR 1KΩ, 1/10W   |
| R307 | QRSA08J-102YN | RESISTOR 1KΩ, 1/10W   |
| R308 | QRD127J-39I   | RESISTOR 390Ω, 1/2W   |
| R309 | QRSA08J-750YN | RESISTOR 75Ω, 1/10W   |
| R310 | QRSA08J-102YN | RESISTOR 1KΩ, 1/10W   |
|      |               |                       |
| R311 | QRD181J-56I   | RESISTOR 560Ω, 1/8W   |
| R312 | QRSA08J-750YN | RESISTOR 75Ω, 1/10W   |
| R313 | QRSA08J-152YN | RESISTOR 1.5KΩ, 1/10W |
| R314 | QRSA08J-472YN | RESISTOR 4.7KΩ, 1/10W |
| R315 | QRSA08J-123YN | RESISTOR 12KΩ, 1/10W  |
| R316 | QRSA08J-332YN | RESISTOR 3.3KΩ, 1/10W |
| R317 | QRSA08J-473YN | RESISTOR 47KΩ, 1/10W  |
| R318 | QRSA08J-103YN | RESISTOR 10KΩ, 1/10W  |
| R320 | QRSA08J-103YN | RESISTOR 10KΩ, 1/10W  |
|      |               |                       |
| R321 | QRSA08J-223YN | RESISTOR 22KΩ, 1/10W  |
| R322 | QRSA08J-223YN | RESISTOR 22KΩ, 1/10W  |
| R323 | QRSA08J-222YN | RESISTOR 2.2KΩ, 1/10W |
| R324 | QRSA08J-222YN | RESISTOR 2.2KΩ, 1/10W |
| R325 | QRSA08J-102YN | RESISTOR 1KΩ, 1/10W   |
| R326 | QRSA08J-102YN | RESISTOR 1KΩ, 1/10W   |
| R327 | QRSA08J-223YN | RESISTOR 22KΩ, 1/10W  |
| R328 | QRSA08J-392YN | RESISTOR 3.9KΩ, 1/10W |
| R329 | QRSA08J-272YN | RESISTOR 2.7KΩ, 1/10W |
| R330 | QRSA08J-331YN | RESISTOR 330Ω, 1/10W  |
|      |               |                       |
| R331 | QRSA08J-101YN | RESISTOR 100Ω, 1/10W  |
| R332 | QRSA08J-272YN | RESISTOR 2.7KΩ, 1/10W |
| R334 | QRSA08J-182YN | RESISTOR 1.8KΩ, 1/10W |
| R335 | QRSA08J-103YN | RESISTOR 10KΩ, 1/10W  |
| R336 | QRSA08J-223YN | RESISTOR 22KΩ, 1/10W  |
| R337 | QRSA08J-272YN | RESISTOR 2.7KΩ, 1/10W |
| R338 | QRSA08J-223YN | RESISTOR 22KΩ, 1/10W  |
| R339 | QRSA08J-223YN | RESISTOR 22KΩ, 1/10W  |
| R340 | QRSA08J-683YN | RESISTOR 68KΩ, 1/10W  |
|      |               |                       |
| R341 | QRSA08J-103YN | RESISTOR 10KΩ, 1/10W  |
| R342 | QRSA08J-223YN | RESISTOR 22KΩ, 1/10W  |
| R343 | QRSA08J-103YN | RESISTOR 10KΩ, 1/10W  |
| R344 | QRSA08J-562YN | RESISTOR 5.6KΩ, 1/10W |
| R345 | QRSA08J-103YN | RESISTOR 10KΩ, 1/10W  |
| R346 | QRSA08J-472YN | RESISTOR 4.7KΩ, 1/10W |
| R347 | QRSA08J-223YN | RESISTOR 22KΩ, 1/10W  |
| R348 | QRSA08J-223YN | RESISTOR 22KΩ, 1/10W  |
| R349 | QRSA08J-472YN | RESISTOR 4.7KΩ, 1/10W |
| R350 | QRSA08J-393YN | RESISTOR 39KΩ, 1/10W  |
|      |               |                       |
| R351 | QRSA08J-472YN | RESISTOR 4.7KΩ, 1/10W |
| R352 | QRSA08J-0R0Y  | RESISTOR 0Ω, 1/10W    |
| R353 | QRSA08J-0R0Y  | RESISTOR 0Ω, 1/10W    |
| R354 | QRSA08J-680YN | RESISTOR 68Ω, 1/10W   |

| #△   | REF No. | PART No.     | PART NAME, DESCRIPTION   |
|------|---------|--------------|--------------------------|
| R355 |         | QRS08J-105YN | RESISTOR 1MΩ, 1/10W      |
| R356 |         | QRS08J-105YN | RESISTOR 1MΩ, 1/10W      |
| R357 |         | QRS08J-223YN | RESISTOR 22KΩ, 1/10W     |
| R358 |         | QRS08J-472YN | RESISTOR 4.7KΩ, 1/10W    |
| R359 |         | QRS08J-223YN | RESISTOR 22KΩ, 1/10W     |
| C301 |         | QEK61CM-106  | E CAPACITOR 10μF, 16V    |
| C302 |         | QCYA1HK-103  | CAPACITOR 0.01μF, 50V    |
| C303 |         | QEK61CM-106  | E CAPACITOR 10μF, 16V    |
| C304 |         | QCSA1HJ-330  | CAPACITOR 33PF, 50V      |
| C305 |         | QEK61CM-106  | E CAPACITOR 10μF, 16V    |
| C306 |         | QCYA1HK-103  | CAPACITOR 0.01μF, 50V    |
| C308 |         | QCYA1HK-103  | CAPACITOR 0.01μF, 50V    |
| C309 |         | QCYA1HK-103  | CAPACITOR 0.01μF, 50V    |
| C310 |         | QEK60JM-476  | E CAPACITOR 47μF, 6.3V   |
| C311 |         | QCSA1HJ-390  | CAPACITOR 39PF, 50V      |
| C312 |         | QEP61CM-106  | NP E CAPACITOR 10μF, 16V |
| C313 |         | QEK61CM-106  | E CAPACITOR 10μF, 16V    |
| C314 |         | QEK61CM-226  | E CAPACITOR 22μF, 16V    |
| C315 |         | QETB1AM-477  | E CAPACITOR 470μF, 10V   |
| C316 |         | QEK61CM-476  | E CAPACITOR 47μF, 16V    |
| C317 |         | QCYA1HK-103  | CAPACITOR 0.01μF, 50V    |
| C318 |         | QEP61CM-106  | NP E CAPACITOR 10μF, 16V |
| C319 |         | QEK61CM-226  | E CAPACITOR 22μF, 16V    |
| C320 |         | QEK61AM-226  | E CAPACITOR 22μF, 10V    |
| C322 |         | QEK60JM-476  | E CAPACITOR 47μF, 6.3V   |
| C323 |         | QEK61CM-476  | E CAPACITOR 47μF, 16V    |
| C324 |         | QCYA1HK-103  | CAPACITOR 0.01μF, 50V    |
| C325 |         | QCYA1HK-103  | CAPACITOR 0.01μF, 50V    |
| C326 |         | QEK61CM-476  | E CAPACITOR 47μF, 16V    |
| C327 |         | QCYA1HK-103  | CAPACITOR 0.01μF, 50V    |
| C328 |         | QCYA1HK-103  | CAPACITOR 0.01μF, 50V    |
| C329 |         | QCYA1HK-103  | CAPACITOR 0.01μF, 50V    |
| C330 |         | QCYA1HK-103  | CAPACITOR 0.01μF, 50V    |
| C331 |         | QCYA1HK-103  | CAPACITOR 0.01μF, 50V    |
| C332 |         | QCYA1HK-103  | CAPACITOR 0.01μF, 50V    |
| C333 |         | QCYA1HK-103  | CAPACITOR 0.01μF, 50V    |
| C335 |         | QCSA1HJ-561  | CAPACITOR 560PF, 50V     |
| C336 |         | QCSA1HJ-101  | CAPACITOR 100PF, 50V     |
| C337 |         | QCSA1HJ-560  | CAPACITOR 56PF, 50V      |
| C339 |         | QCYA1HK-103  | CAPACITOR 0.01μF, 50V    |
| C339 |         | QEK61CM-106  | E CAPACITOR 10μF, 16V    |
| C340 |         | QCYA1HK-103  | CAPACITOR 0.01μF, 50V    |
| C341 |         | QCYA1HK-103  | CAPACITOR 0.01μF, 50V    |
| C342 |         | QCSA1HJ-560  | CAPACITOR 56PF, 50V      |
| C343 |         | QCYA1HK-103  | CAPACITOR 0.01μF, 50V    |
| C344 |         | QCYA1HK-103  | CAPACITOR 0.01μF, 50V    |
| C345 |         | QCYA1HK-103  | CAPACITOR 0.01μF, 50V    |
| C346 |         | QEK61HM-105  | E CAPACITOR 1μF, 50V     |
| C347 |         | QEK61CM-106  | E CAPACITOR 10μF, 16V    |
| C348 |         | QCYA1HK-103  | CAPACITOR 0.01μF, 50V    |
| C349 |         | QEK60JM-476  | E CAPACITOR 47μF, 6.3V   |
| C350 |         | QEK60JM-476  | E CAPACITOR 47μF, 6.3V   |
| C351 |         | QCYA1HK-103  | CAPACITOR 0.01μF, 50V    |
| C352 |         | QETA0JM-477  | E CAPACITOR 470μF, 6.3V  |
| C353 |         | QFN41HJ-104  | M CAPACITOR 0.1μF, 50V   |

| #△    | REF No. | PART No.     | PART NAME, DESCRIPTION |
|-------|---------|--------------|------------------------|
| C354  |         | QCYA1HK-103  | CAPACITOR 0.01μF, 50V  |
| L301  |         | PU59152-100J | COIL 100μH             |
| L302  |         | PU48530-101K | COIL 100μH             |
| L303  |         | PU48530-101K | COIL 100μH             |
| L304  |         | PU48530-101K | COIL 100μH             |
| L305  |         | PU48530-101K | COIL 100μH             |
| L306  |         | PU48530-101K | COIL 100μH             |
| L307  |         | PU48530-101K | COIL 100μH             |
| L309  |         | PU59153-822J | COIL 8.2mH             |
| L310  |         | PU48530-101K | COIL 100μH             |
| L311  |         | PU59152-180J | COIL 18μH              |
| EQ301 |         | PU54638      | EQUALIZER              |
| BP301 |         | PU57072      | BAND PASS FILTER       |

\*\*\*

### 13. AUDIO CONTROL HEAD BOARD (12)

|       |              |             |
|-------|--------------|-------------|
| PWBA1 | PB40029      | AC HEAD PWB |
| CN1   | PU58844-104B | CAP HOUSING |
| CN2   | PU58844-103  | CAP HOUSING |

\*\*\*

### 14. DEMODULATOR BOARD ASSEMBLY (14)

|      |             |                            |
|------|-------------|----------------------------|
| PWBA | PB20242D    | DEMOMULATOR BOARD ASSEMBLY |
| IC1  | TDA3800GS   | IC                         |
| Q1   | DTC114ES    | TRANSISTOR                 |
| or   | UN4211      | TRANSISTOR                 |
| or   | 2SC3402     | TRANSISTOR                 |
| Q2   | 2SD1292(QR) | TRANSISTOR                 |
| or   | 2SC3068     | TRANSISTOR                 |
| Q3   | DTC114ES    | TRANSISTOR                 |
| or   | UN4211      | TRANSISTOR                 |
| or   | 2SC3402     | TRANSISTOR                 |
| Q4   | DTC114ES    | TRANSISTOR                 |
| or   | 2SC3402     | TRANSISTOR                 |
| or   | UN4211      | TRANSISTOR                 |
| Q5   | DTC114ES    | TRANSISTOR                 |
| or   | 2SC3402     | TRANSISTOR                 |
| or   | UN4211      | TRANSISTOR                 |
| Q6   | DTC114ES    | TRANSISTOR                 |
| or   | 2SC3402     | TRANSISTOR                 |
| or   | UN4211      | TRANSISTOR                 |

| #Δ | REF No. | PART No.    | PART NAME, DESCRIPTION          |
|----|---------|-------------|---------------------------------|
|    | Q7      | DTC144ES    | TRANSISTOR                      |
|    | or      | 2SC3399     | TRANSISTOR                      |
|    | or      | UN4213      | TRANSISTOR                      |
|    | Q8      | DTC114ES    | TRANSISTOR                      |
|    | or      | UN4211      | TRANSISTOR                      |
|    | or      | 2SC3402     | TRANSISTOR                      |
|    | Q9      | 2SD1450S,T  | TRANSISTOR                      |
|    | or      | 2SD1292(QR) | TRANSISTOR                      |
|    | Q10     | 2SD1450S,T  | TRANSISTOR                      |
|    | or      | 2SD1292(QR) | TRANSISTOR                      |
|    | D1      | 1SS133      | DIODE                           |
|    | D2      | 1SS133      | DIODE                           |
|    | D3      | 1SS133      | DIODE                           |
|    | D4      | 1SS133      | DIODE                           |
|    | D6      | 1SS133      | DIODE                           |
|    | R1      | QRD161J-103 | RESISTOR 10KΩ, 1/6W             |
|    | R2      | QVZ3518-103 | V RESISTOR, SEPARATION ADJ 10KΩ |
|    | R3      | QRD161J-153 | RESISTOR 15KΩ, 1/6W             |
|    | R4      | QRD161J-331 | RESISTOR 330Ω, 1/6W             |
|    | R5      | QRD161J-821 | RESISTOR 820Ω, 1/6W             |
|    | R6      | QRD161J-102 | RESISTOR 1KΩ, 1/6W              |
|    | R7      | QRD161J-104 | RESISTOR 100KΩ, 1/6W            |
|    | R8      | QRD161J-154 | RESISTOR 150KΩ, 1/6W            |
|    | R9      | QRD161J-271 | RESISTOR 270Ω, 1/6W             |
|    | R10     | QRD161J-273 | RESISTOR 27KΩ, 1/6W             |
|    | R11     | QRD161J-103 | RESISTOR 10KΩ, 1/6W             |
|    | R12     | QRD161J-103 | RESISTOR 10KΩ, 1/6W             |
|    | R13     | QRD161J-103 | RESISTOR 10KΩ, 1/6W             |
|    | R14     | QRD161J-103 | RESISTOR 10KΩ, 1/6W             |
|    | R15     | QRD161J-103 | RESISTOR 10KΩ, 1/6W             |
|    | R16     | QRD161J-103 | RESISTOR 10KΩ, 1/6W             |
|    | R17     | QRD161J-103 | RESISTOR 10KΩ, 1/6W             |
|    | R21     | QVZ3518-332 | V RESISTOR, AUDIO L LEVEL 3.3KΩ |
|    | R22     | QRD161J-222 | RESISTOR 2.2KΩ, 1/6W            |
|    | R23     | QRD161J-103 | RESISTOR 10KΩ, 1/6W             |
|    | R24     | QVZ3518-332 | V RESISTOR, AUDIO R LEVEL 3.3KΩ |
|    | R25     | QRD161J-222 | RESISTOR 2.2KΩ, 1/6W            |
|    | R26     | QRD161J-103 | RESISTOR 10KΩ, 1/6W             |
|    | R27     | QRD161J-821 | RESISTOR 820Ω, 1/6W             |
|    | R28     | QRD161J-821 | RESISTOR 820Ω, 1/6W             |
|    | C1      | QETC1CM-106 | E CAPACITOR 10μF, 16V           |
|    | C2      | QFN31HK-392 | M CAPACITOR 0.0039μF, 50V       |
|    | C3      | QFN31HK-392 | M CAPACITOR 0.0039μF, 50V       |
|    | C4      | QFN31HK-392 | M CAPACITOR 0.0039μF, 50V       |
|    | C5      | QETC1CM-106 | E CAPACITOR 10μF, 16V           |
|    | C6      | QETC1CM-106 | E CAPACITOR 10μF, 16V           |
|    | C7      | QETC1CM-476 | E CAPACITOR 47μF, 16V           |
|    | C8      | QCC31HP-223 | CAPACITOR 0.022μF, 50V          |
|    | C9      | QCC11EK-473 | CAPACITOR 0.047μF, 25V          |
|    | C10     | QFP31HJ-102 | M CAPACITOR 0.001μF, 50V        |
|    | C11     | QETC1CM-477 | E CAPACITOR 470μF, 16V          |
|    | C12     | QCC11EK-473 | CAPACITOR 0.047μF, 25V          |
|    | C13     | QETC1CM-106 | E CAPACITOR 10μF, 16V           |

| #Δ | REF No. | PART No.    | PART NAME, DESCRIPTION   |
|----|---------|-------------|--------------------------|
|    | C14     | QETC1CM-106 | E CAPACITOR 10μF, 16V    |
|    | C15     | QETC1CM-336 | E CAPACITOR 33μF, 16V    |
|    | C16     | QETC1CM-107 | E CAPACITOR 100μF, 16V   |
|    | C17     | QETC1HM-105 | E CAPACITOR 1μF, 50V     |
|    | C18     | QETC1CM-476 | E CAPACITOR 47μF, 16V    |
|    | C19     | QFN31HJ-123 | M CAPACITOR 0.012μF, 50V |
|    | C20     | QETC1CM-106 | E CAPACITOR 10μF, 16V    |
|    | C30     | QFN31HJ-123 | M CAPACITOR 0.012μF, 50V |

BPF1 PU58226 BAND PASS FILTER

CF1 PU52775 CERAMIC FILTER

CF2 PU52775-2 CERAMIC FILTER

T1 PU59489 COIL

T2 PU59490 COIL

T3 PU59243 FH TRAP

T4 PU59243 FH TRAP

CN1 PU58844-6 CAP HOUSING

CN4 PU58844-2 CAP HOUSING

CN5 PU58844-2 CAP HOUSING

\*\*\* \*\*\*\*\*

## 15. TIMER BOARD ASSEMBLY (20)

PWBA PB20250AA TIMER BOARD ASSEMBLY

IC1 UPD75216ACW-A63 IC

or UPD75216ACW-A63 IC

IC2 S-8053HNB IC

IC3 M5278L56 IC

IC301 SDA5642 IC

Q2 2SC331A(RS) TRANSISTOR

or 2SC3199(GB)-TJK TRANSISTOR

Q3 DTC124ES TRANSISTOR

Q4 2SC331A(RS) TRANSISTOR

or 2SC3199(GB)-TJK TRANSISTOR

Q5 DTC124ES TRANSISTOR

Q6 DTC124ES TRANSISTOR

D1 RD9.1ES-T1B2 ZENER DIODE

or HZS9.1EB2TJ ZENER DIODE

D6 1SS133 DIODE

or MA165 DIODE

D7 1SS133 DIODE

or MA165 DIODE

D8 1SS133 DIODE

or MA165 DIODE

D9 1SS133 DIODE

or MA165 DIODE

| #Δ  | REF No.     | PART No. | PART NAME, DESCRIPTION |
|-----|-------------|----------|------------------------|
| D10 | ISS133      | DIODE    |                        |
|     | or MA165    | DIODE    |                        |
| D25 | ISS133      | DIODE    |                        |
| D26 | ISS133      | DIODE    |                        |
| D29 | ISS133      | DIODE    |                        |
| D30 | ISS133      | DIODE    |                        |
| D35 | ISS133      | DIODE    |                        |
| R3  | QRD161J-103 | RESISTOR | 10KΩ, 1/6W             |
| R4  | QRD161J-682 | RESISTOR | 6.8KΩ, 1/6W            |
| R5  | QRD161J-104 | RESISTOR | 100KΩ, 1/6W            |
| R6  | QRD161J-151 | RESISTOR | 150Ω, 1/6W             |
| R7  | QRD161J-102 | RESISTOR | 1KΩ, 1/6W              |
| R8  | QRD161J-104 | RESISTOR | 100KΩ, 1/6W            |
| R9  | QRD161J-472 | RESISTOR | 4.7KΩ, 1/6W            |
| R10 | QRD161J-102 | RESISTOR | 1KΩ, 1/6W              |
| R11 | QRD161J-102 | RESISTOR | 1KΩ, 1/6W              |
| R12 | QRD161J-102 | RESISTOR | 1KΩ, 1/6W              |
| R13 | QRD161J-102 | RESISTOR | 1KΩ, 1/6W              |
| R14 | QRD161J-102 | RESISTOR | 1KΩ, 1/6W              |
| R15 | QRD161J-102 | RESISTOR | 1KΩ, 1/6W              |
| R16 | QRD161J-102 | RESISTOR | 1KΩ, 1/6W              |
| R17 | QRD161J-102 | RESISTOR | 1KΩ, 1/6W              |
| R18 | QRD161J-102 | RESISTOR | 1KΩ, 1/6W              |
| R19 | QRD161J-102 | RESISTOR | 1KΩ, 1/6W              |
| R20 | QRD161J-102 | RESISTOR | 1KΩ, 1/6W              |
| R21 | QRD161J-102 | RESISTOR | 1KΩ, 1/6W              |
| R22 | QRD161J-472 | RESISTOR | 4.7KΩ, 1/6W            |
| R23 | QRD161J-472 | RESISTOR | 4.7KΩ, 1/6W            |
| R24 | QRD161J-472 | RESISTOR | 4.7KΩ, 1/6W            |
| R25 | QRD161J-472 | RESISTOR | 4.7KΩ, 1/6W            |
| R26 | QRD161J-102 | RESISTOR | 1KΩ, 1/6W              |
| R29 | QRD161J-472 | RESISTOR | 4.7KΩ, 1/6W            |
| R30 | QRD161J-472 | RESISTOR | 4.7KΩ, 1/6W            |
| R31 | QRD161J-472 | RESISTOR | 4.7KΩ, 1/6W            |
| R32 | QRD161J-472 | RESISTOR | 4.7KΩ, 1/6W            |
| R33 | QRD161J-472 | RESISTOR | 4.7KΩ, 1/6W            |
| R34 | QRD161J-472 | RESISTOR | 4.7KΩ, 1/6W            |
| R35 | QRD161J-472 | RESISTOR | 4.7KΩ, 1/6W            |
| R36 | QRD161J-472 | RESISTOR | 4.7KΩ, 1/6W            |
| R37 | QRD161J-472 | RESISTOR | 4.7KΩ, 1/6W            |
| R38 | QRD161J-472 | RESISTOR | 4.7KΩ, 1/6W            |
| R39 | QRD161J-472 | RESISTOR | 4.7KΩ, 1/6W            |
| R40 | QRD161J-472 | RESISTOR | 4.7KΩ, 1/6W            |
| R41 | QRD161J-472 | RESISTOR | 4.7KΩ, 1/6W            |
| R42 | QRD161J-472 | RESISTOR | 4.7KΩ, 1/6W            |
| R43 | QRD161J-333 | RESISTOR | 33KΩ, 1/6W             |
| R44 | QRD161J-472 | RESISTOR | 4.7KΩ, 1/6W            |
| R45 | QRD161J-472 | RESISTOR | 4.7KΩ, 1/6W            |
| R46 | QRD161J-102 | RESISTOR | 1KΩ, 1/6W              |
| R47 | QRD161J-333 | RESISTOR | 33KΩ, 1/6W             |
| R49 | QRD161J-272 | RESISTOR | 2.7KΩ, 1/6W            |
| R50 | QRD161J-271 | RESISTOR | 270Ω, 1/6W             |
| R51 | QRD161J-271 | RESISTOR | 270Ω, 1/6W             |

| #Δ   | REF No.         | PART No.               | PART NAME, DESCRIPTION |
|------|-----------------|------------------------|------------------------|
| R301 | QRD161J-824     | RESISTOR               | 820KΩ, 1/6W            |
| R302 | QRD161J-101     | RESISTOR               | 100Ω, 1/6W             |
| R303 | QRD161J-562     | RESISTOR               | 5.6KΩ, 1/6W            |
| R304 | QRD161J-104     | RESISTOR               | 100KΩ, 1/6W            |
| R305 | QRD161J-103     | RESISTOR               | 10KΩ, 1/6W             |
| R306 | QRD161J-103     | RESISTOR               | 10KΩ, 1/6W             |
| R307 | QRD161J-105     | RESISTOR               | 1MΩ, 1/6W              |
| R308 | QRD161J-824     | RESISTOR               | 820KΩ, 1/6W            |
| R309 | QRD161J-104     | RESISTOR               | 100KΩ, 1/6W            |
| R310 | QRD161J-202     | RESISTOR               | 2KΩ, 1/6W              |
| RA1  | QRB067J-224     | RESISTOR ARRAY         |                        |
|      | or QRB069J-224  | RESISTOR ARRAY         |                        |
|      | or QRB069J-224C | RESISTOR ARRAY         |                        |
| RA2  | QRB067J-104     | NETWORK RESISTOR       |                        |
|      | or QRB069J-104  | NETWORK RESISTOR       |                        |
|      | or QRB069J-104C | RESISTOR ARRAY         |                        |
| RA3  | QRB047J-333     | RESISTOR ARRAY         |                        |
|      | or QRB049J-333  | RESISTOR ARRAY         |                        |
|      | or QRB049J-333C | RESISTOR ARRAY         |                        |
| RA4  | QRB037J-104     | NETWORK RESISTOR       |                        |
|      | or QRB039J-104C | RESISTOR ARRAY         |                        |
|      | or QRB039J-104  | NETWORK RESISTOR       |                        |
| C1   | QETC1EM-107     | E CAPACITOR            | 100μF, 25V             |
| C3   | QCB81HJ-102     | CAPACITOR              | 0.001μF, 50V           |
| C4   | PU60676-473     | E CAPACITOR            | 0.047μF                |
|      | or QEA40HZ-473  | E CAPACITOR (DOUBLE)   | 0.047μF, 55V           |
| C5   | QETC1CM-336     | E CAPACITOR            | 33μF, 16V              |
| C6   | QETC0JM-336     | E CAPACITOR            | 33μF, 6.3V             |
| C7   | QCVB1CN-103     | CAPACITOR              | 0.01μF, 16V            |
| C8   | QETC1CM-106     | E CAPACITOR            | 10μF, 16V              |
| C9   | QCVB1CN-103     | CAPACITOR              | 0.01μF, 16V            |
| C10  | QAT3123-200     | TRIMMER CAPACITOR, VXO |                        |
| C11  | QCT30CH-120     | CAPACITOR              | 12PF                   |
| C301 | QFN31HJ-103     | M CAPACITOR            | 0.01μF, 50V            |
| C302 | QFN31HJ-333     | M CAPACITOR            | 0.033μF, 50V           |
| C303 | QFN31HJ-103     | M CAPACITOR            | 0.01μF, 50V            |
| C304 | QETC1HM-104     | E CAPACITOR            | 0.1μF, 50V             |
| C305 | QCB81HJ-151     | CAPACITOR              | 150PF, 50V             |
| L1   | PU48530-101K    | COIL                   | 100μH                  |
| Δ X1 | PU60226-2       | CRYSTAL RESONATOR      |                        |
| TP1  | PU58008         | TEST PIN, GND          |                        |
| TP2  | PU58008         | TEST PIN               |                        |
| TP3  | PU58008         | TEST PIN, TEST         |                        |
| CN1  | PU59555-8       | CAP HOUSING            |                        |
| CN2  | PU58844-9       | CAP HOUSING            |                        |
| CN3  | PU58844-6       | CAP HOUSING            |                        |
| CN4  | PU58555-12      | CAP HOUSING            |                        |
| CN5  | PU58555-3       | CAP HOUSING            |                        |
| CN6  | PU58844-2       | CAP HOUSING            |                        |

| # | REF No. | PART No.  | PART NAME, DESCRIPTION |
|---|---------|-----------|------------------------|
|   | CN11    | PU58844-2 | CAP HOUSING            |
|   | CN12    | PU58844-2 | CAP HOUSING            |
|   | CN301   | PU58844-6 | CAP HOUSING            |
|   | △ CP1   | ICP-F10   | CIRCUIT PROTECTOR      |

\*\*\*\*\*

## 16. OPERATION BOARD ASSEMBLY (22)

### PWBA PB20253A-01 OPERATION BOARD ASSEMBLY

|      |             |          |             |
|------|-------------|----------|-------------|
| R201 | QRD161J-222 | RESISTOR | 2.2KΩ, 1/6W |
| R202 | QRD161J-222 | RESISTOR | 2.2KΩ, 1/6W |
| R203 | QRD161J-332 | RESISTOR | 3.3KΩ, 1/6W |
| R204 | QRD161J-472 | RESISTOR | 4.7KΩ, 1/6W |
| R205 | QRD161J-103 | RESISTOR | 10KΩ, 1/6W  |
| R206 | QRD161J-223 | RESISTOR | 22KΩ, 1/6W  |
| R208 | QRD161J-222 | RESISTOR | 2.2KΩ, 1/6W |
| R209 | QRD161J-332 | RESISTOR | 3.3KΩ, 1/6W |
| R210 | QRD161J-472 | RESISTOR | 4.7KΩ, 1/6W |

|      |             |          |             |
|------|-------------|----------|-------------|
| R211 | QRD161J-103 | RESISTOR | 10KΩ, 1/6W  |
| R212 | QRD161J-223 | RESISTOR | 22KΩ, 1/6W  |
| R215 | QRD161J-332 | RESISTOR | 3.3KΩ, 1/6W |
| R216 | QRD161J-472 | RESISTOR | 4.7KΩ, 1/6W |

|     |         |                        |
|-----|---------|------------------------|
| S1  | PU57550 | TACT SWITCH, 1         |
| or  | PU53598 | TACT SWITCH            |
| S2  | PU57550 | TACT SWITCH, 2         |
| or  | PU53598 | TACT SWITCH            |
| S3  | PU57550 | TACT SWITCH, 3         |
| or  | PU53598 | TACT SWITCH            |
| S4  | PU57550 | TACT SWITCH, 4         |
| or  | PU53598 | TACT SWITCH            |
| S5  | PU57550 | TACT SWITCH, 5         |
| or  | PU53598 | TACT SWITCH            |
| S6  | PU57550 | TACT SWITCH, 6         |
| or  | PU53598 | TACT SWITCH            |
| S7  | PU57550 | TACT SWITCH, 7         |
| or  | PU53598 | TACT SWITCH            |
| S8  | PU57550 | TACT SWITCH, 8/DAILY   |
| or  | PU53598 | TACT SWITCH            |
| S9  | PU57550 | TACT SWITCH, 9/REPEAT  |
| or  | PU53598 | TACT SWITCH            |
| S10 | PU57550 | TACT SWITCH, 0/AUX     |
| or  | PU53598 | TACT SWITCH            |
| S11 | PU57550 | TACT SWITCH, GOTO      |
| or  | PU53598 | TACT SWITCH            |
| S12 | PU57550 | TACT SWITCH, C. MEMORY |
| or  | PU53598 | TACT SWITCH            |
| S13 | PU57550 | TACT SWITCH, C. PRESET |
| or  | PU53598 | TACT SWITCH            |
| S14 | PU57550 | TACT SWITCH, DISP      |
| or  | PU53598 | TACT SWITCH            |
| S15 | PU57550 | TACT SWITCH, REC/OTR   |

| #    | REF No. | PART No.    | PART NAME, DESCRIPTION   |
|------|---------|-------------|--------------------------|
|      |         | or PU53598  | TACT SWITCH              |
| S16  |         | PU57550     | TACT SWITCH, TIMER       |
|      |         | or PU53598  | TACT SWITCH              |
| S17  |         | PU57550     | TACT SWITCH, CH+ /NEXT   |
|      |         | or PU53598  | TACT SWITCH              |
| S18  |         | PU57550     | TACT SWITCH, CH+ /BACK   |
|      |         | or PU53598  | TACT SWITCH              |
| S19  |         | PU57550     | TACT SWITCH, SEARCH      |
|      |         | or PU53598  | TACT SWITCH              |
| S20  |         | PU57550     | TACT SWITCH, VPS/CH      |
|      |         | or PU53598  | TACT SWITCH              |
| S21  |         | PU57550     | TACT SWITCH, CANCEL/SKIP |
|      |         | or PU53598  | TACT SWITCH              |
| S22  |         | PU57550     | TACT SWITCH, STORE       |
|      |         | or PU53598  | TACT SWITCH              |
| S23  |         | PU57550     | TACT SWITCH, FINE+       |
|      |         | or PU53598  | TACT SWITCH              |
| S24  |         | PU57550     | TACT SWITCH, FINE+       |
|      |         | or PU53598  | TACT SWITCH              |
| S25  |         | PU57550     | TACT SWITCH, C. ADJ      |
|      |         | or PU53598  | TACT SWITCH              |
| S26  |         | PU57550     | TACT SWITCH, PROG        |
|      |         | or PU53598  | TACT SWITCH              |
| S27  |         | PU57550     | TACT SWITCH, SP/LP       |
|      |         | or PU53598  | TACT SWITCH              |
| S29  |         | PU57550     | TACT SWITCH, SIMUL       |
|      |         | or PU53598  | TACT SWITCH              |
| S201 |         | PU57550     | TACT SWITCH, STOP        |
|      |         | or PU53598  | TACT SWITCH              |
| S202 |         | PU57550     | TACT SWITCH, PAUSE/STILL |
|      |         | or PU53598  | TACT SWITCH              |
| S203 |         | PU57550     | TACT SWITCH, PLAY        |
|      |         | or PU53598  | TACT SWITCH              |
| S204 |         | PU57550     | TACT SWITCH, REW         |
|      |         | or PU53598  | TACT SWITCH              |
| S205 |         | PU57550     | TACT SWITCH, FF          |
|      |         | or PU53598  | TACT SWITCH              |
| S206 |         | PU57550     | TACT SWITCH, SEARCH(+)   |
|      |         | or PU53598  | TACT SWITCH              |
| S207 |         | PU57550     | TACT SWITCH, SEARCH(+)   |
|      |         | or PU53598  | TACT SWITCH              |
| S209 |         | PU57550     | TACT SWITCH, INSERT      |
|      |         | or PU53598  | TACT SWITCH              |
| S210 |         | PU57550     | TACT SWITCH, S-VHS       |
|      |         | or PU53598  | TACT SWITCH              |
| S211 |         | PU57550     | TACT SWITCH, ERASE       |
|      |         | or PU53598  | TACT SWITCH              |
| S212 |         | PU57550     | TACT SWITCH, MARK        |
|      |         | or PU53598  | TACT SWITCH              |
| S213 |         | PU57550     | TACT SWITCH, A.MON       |
|      |         | or PU53598  | TACT SWITCH              |
| S214 |         | PU57550     | TACT SWITCH, MIX         |
|      |         | or PU53598  | TACT SWITCH              |
| S217 |         | PU57550     | TACT SWITCH, A.DUB       |
|      |         | or PU53598  | TACT SWITCH              |
| S219 |         | PU57550     | TACT SWITCH, EJECT       |
|      |         | or PU53598  | TACT SWITCH              |
| CN1  |         | PU80566-116 | FPC CONNECTOR            |

#△ REF No. PART No. PART NAME, DESCRIPTION  
\*\*\*\*\*

# 17. SW/JACK BOARD ASSEMBLY (26)(36)

PWBA PB10153F SW/JACK BOARD ASSEMBLY

## — SW BOARD ASSEMBLY (26) —

|       |                       |                                   |             |
|-------|-----------------------|-----------------------------------|-------------|
| PWBA1 | PB10153F1             | SWITCH BOARD ASSEMBLY             |             |
| D201  | SLH-34VT3F            | LE DIODE, POWER                   |             |
| R200  | QRD161J-102           | RESISTOR                          | 1KΩ, 1/6W   |
| R201  | QRD161J-331           | RESISTOR                          | 330Ω, 1/6W  |
| R213  | QRD161J-222           | RESISTOR                          | 2.2KΩ, 1/6W |
| R401  | QRD161J-823           | RESISTOR                          | 82KΩ, 1/6W  |
| R402  | QRD161J-333           | RESISTOR                          | 33KΩ, 1/6W  |
| R403  | QRD161J-333           | RESISTOR                          | 33KΩ, 1/6W  |
| S215  | PU57550<br>or PU53598 | TACT SWITCH, POWER<br>TACT SWITCH |             |
| S401  | PU58488-1-1           | SLIDE SWITCH, INPUT SEL           |             |
| S405  | PU58486-1-1           | SLIDE SWITCH, EDIT                |             |
| S407  | PU58488-1-1           | SLIDE SWITCH, LEVEL IND           |             |
| S408  | PU58486-1-1           | SLIDE SWITCH, TV SOUND SEL        |             |
| S409  | PU58486-1-1           | SLIDE SWITCH, ALC                 |             |
| S410  | PU58486-1-1           | SLIDE SWITCH, AC ONLINE           |             |
| S418  | PU58487-1-1           | SLIDE SWITCH, MONITOR SEL         |             |
| HD1   | PQM30038-3            | LED HOLDER                        |             |

## — JACK BOARD ASSEMBLY (36) —

|       |              |                        |            |
|-------|--------------|------------------------|------------|
| PWBA2 | PB10153A2-04 | JACK BOARD ASSEMBLY    |            |
| R231  | QRD161J-103  | RESISTOR               | 10KΩ, 1/6W |
| R404  | PU60565      | V RESISTOR, H.P. LEVEL |            |
| LC1   | PU59885-223  | N FILTER               |            |
| LC2   | PU59885-223  | N FILTER               |            |
| J401  | PU58356-2    | JACK (HEADPHONE)       |            |
| J402  | PU58356-2    | MIC JACK               |            |

#△ REF No. PART No. PART NAME, DESCRIPTION  
\*\*\*\*\*

# 18. DISPLAY/STEP BOARD ASSY (27)(37)

PWBA PB10343A DIS/STEP BOARD ASSEMBLY

## — DISPALY BOARD ASSEMBLY (27) —

PWBA1 PB10343A1 DISPLAY BOARD ASSEMBLY

|       |              |                      |             |
|-------|--------------|----------------------|-------------|
| IC101 | MSC7112-01SS | IC                   |             |
| IC102 | MSC1146BRS   | IC                   |             |
| IC103 | SBX1492-01   | INFRARED RAYS UNIT   |             |
| Q101  | 2SK658       | FE TRANSISTOR        |             |
| Q102  | DTC124ES     | TRANSISTOR           |             |
| Q103  | DTC124ES     | TRANSISTOR           |             |
| Q104  | DTC124ES     | TRANSISTOR           |             |
| D101  | SLR-55VC3F   | LE DIODE, MARK       |             |
| D102  | SLR-55VC3F   | LE DIODE, ERASE      |             |
| D103  | MTZ5.1B      | ZENER DIODE          |             |
| D104  | SLR-55VC3F   | LE DIODE, STEREO     |             |
| D105  | SLR-55MC3F   | LE DIODE, BILINGUAL  |             |
| D107  | SLR-55MC3F   | LE DIODE, S-CASSETTE |             |
| D109  | SLR-34MC3F   | LE DIODE, S-VHS      |             |
| D110  | SLR-34MC3F   | LE DIODE, S-VHS      |             |
| D111  | SLR-34MC3F   | LE DIODE, S-VHS      |             |
| D112  | SLR-55MC3F   | LE DIODE, AT         |             |
| D113  | SLR-34MC3F   | LE DIODE, MAC        |             |
| D114  | SLR-34MC3F   | LE DIODE, MAC        |             |
| D115  | SLR-34MC3F   | LE DIODE, MAC        |             |
| D116  | SLR-55VC3F   | LE DIODE, RADIO      |             |
| R101  | QRD161J-102  | RESISTOR             | 1KΩ, 1/6W   |
| R102  | QRD161J-102  | RESISTOR             | 1KΩ, 1/6W   |
| R103  | QRD161J-102  | RESISTOR             | 1KΩ, 1/6W   |
| R104  | QRD161J-273  | RESISTOR             | 27KΩ, 1/6W  |
| R105  | QRD161J-221  | RESISTOR             | 220Ω, 1/6W  |
| R106  | QRD161J-221  | RESISTOR             | 220Ω, 1/6W  |
| R107  | QRD161J-102  | RESISTOR             | 1KΩ, 1/6W   |
| R108  | QRD161J-103  | RESISTOR             | 10KΩ, 1/6W  |
| R109  | QRD161J-103  | RESISTOR             | 10KΩ, 1/6W  |
| R110  | QRD161J-103  | RESISTOR             | 10KΩ, 1/6W  |
| R111  | QRD161J-153  | RESISTOR             | 15KΩ, 1/6W  |
| R112  | QRD161J-104  | RESISTOR             | 100KΩ, 1/6W |
| R113  | QRD161J-103  | RESISTOR             | 10KΩ, 1/6W  |
| R114  | QRD161J-101  | RESISTOR             | 100Ω, 1/6W  |
| R115  | QRD161J-101  | RESISTOR             | 100Ω, 1/6W  |
| R116  | QRD161J-103  | RESISTOR             | 10KΩ, 1/6W  |
| R117  | QRD161J-101  | RESISTOR             | 100Ω, 1/6W  |
| R118  | QRD161J-101  | RESISTOR             | 100Ω, 1/6W  |

| #△ REF No. | PART No.     | PART NAME, DESCRIPTION        |              |
|------------|--------------|-------------------------------|--------------|
| R119       | QRD161J-104  | RESISTOR                      | 100KΩ, 1/8W  |
| R120       | QRD161J-471  | RESISTOR                      | 470Ω, 1/8W   |
| R121       | QRD161J-102  | RESISTOR                      | 1KΩ, 1/8W    |
| R122       | QRD161J-102  | RESISTOR                      | 1KΩ, 1/8W    |
| R123       | QRD161J-561  | RESISTOR                      | 560Ω, 1/8W   |
| R124       | QRD161J-102  | RESISTOR                      | 1KΩ, 1/8W    |
| R125       | PU59375      | SLIDE VR, REC LEVEL           |              |
| R126       | QRD161J-102  | RESISTOR                      | 1KΩ, 1/8W    |
| R127       | QRD161J-561  | RESISTOR                      | 560Ω, 1/8W   |
| R128       | QRD161J-102  | RESISTOR                      | 1KΩ, 1/8W    |
| R207       | QRD161J-222  | RESISTOR                      | 2.2KΩ, 1/8W  |
| R214       | QRD161J-222  | RESISTOR                      | 2.2KΩ, 1/8W  |
| R215       | QRD161J-472  | RESISTOR                      | 4.7KΩ, 1/8W  |
| R216       | QRD161J-472  | RESISTOR                      | 4.7KΩ, 1/8W  |
| R217       | QRD161J-472  | RESISTOR                      | 4.7KΩ, 1/8W  |
| R402       | PU60257      | V RESISTOR, PICTURE SHARPNESS |              |
| C101       | QCB81HJ-101  | CAPACITOR                     | 100PF, 50V   |
| C102       | QER61HM-104  | E CAPACITOR                   | 0.1μF, 50V   |
| C103       | QER60JM-336  | E CAPACITOR                   | 33μF, 6.3V   |
| C104       | QCVB1CM-103  | CAPACITOR                     | 0.01μF, 16V  |
| C105       | QERF1VM-106  | E CAPACITOR                   | 10μF, 35V    |
| C106       | QEN41EM-226  | E CAPACITOR                   | 22μF, 25V    |
| C107       | QEN41EM-226  | E CAPACITOR                   | 22μF, 25V    |
| C108       | QERF1CM-106  | E CAPACITOR                   | 10μF, 16V    |
| C109       | QF41HJ-223   | M CAPACITOR                   | 0.022μF, 50V |
| C110       | QF41HJ-333   | M CAPACITOR                   | 0.033μF, 50V |
| C111       | QCVB1CM-103  | CAPACITOR                     | 0.01μF, 16V  |
| C112       | QCVB1CM-103  | CAPACITOR                     | 0.01μF, 16V  |
| C113       | QERF1VM-226  | E CAPACITOR                   | 22μF, 35V    |
| C114       | QERF0JM-107  | E CAPACITOR                   | 100μF, 6.3V  |
| C115       | QCSB1HJ-330  | CAPACITOR                     | 33PF, 50V    |
| C116       | QCSB1HJ-330  | CAPACITOR                     | 33PF, 50V    |
| C117       | QCVB1CM-103  | CAPACITOR                     | 0.01μF, 16V  |
| S208       | PU80392-Z    | TACT SWITCH, TRACKING(+)      |              |
| S216       | PU80392-Z    | TACT SWITCH, TRACKING(+)      |              |
| FDP1       | PU60660-2    | FLUORESCENT DISPLAY PANEL     |              |
| HD1        | PQ42602      | LED SHADE                     |              |
| HD2        | PQ42602      | LED SHADE                     |              |
| HD3        | PQM30038-1-2 | LED HOLDER                    |              |
| HD4        | PQ31309      | FDP HOLDER (L)                |              |
| HD5        | PQ31310      | FDP HOLDER (R)                |              |
| SLD1       | PU59919      | RASTER METAL                  |              |
| CN102      | PU59513-7    | CAP HOUSING                   |              |
| CN105      | PU59513-9    | CAP HOUSING                   |              |
| CN107      | PU59555-7    | CAP HOUSING                   |              |
| CN108      | PU59555-4    | CAP HOUSING                   |              |
| CN109      | PU59513-2    | CAP HOUSING                   |              |

| #△ REF No.                   | PART No.    | PART NAME, DESCRIPTION |
|------------------------------|-------------|------------------------|
| CN112                        | PU59513-3   | CAP HOUSING            |
| — STEP BOARD ASSEMBLY (37) — |             |                        |
| PWBA2                        | PB10343A2   | STEP BOARD ASSEMBLY    |
| CL1                          | PU59311-4   | WIRE CLAMP             |
| CN1                          | PU59555-12  | CAP HOUSING            |
| CN2                          | PU59555-4   | CAP HOUSING            |
| CN3                          | PU60566-116 | FPC CONNECTOR          |

\*\*\* \*\*

# 19. SERVO SUB BOARD ASSEMBLY (39)

|      |             |                          |              |
|------|-------------|--------------------------|--------------|
| PWBA | PB30095A-02 | SERVO SUB BOARD ASSEMBLY |              |
| IC1  | BU3791      | IC                       |              |
| Q1   | DTC144ES    | TRANSISTOR               |              |
| or   | UN4213      | TRANSISTOR               |              |
| or   | 2SC3399     | TRANSISTOR               |              |
| Q2   | DTC124ES    | TRANSISTOR               |              |
| Q3   | DTC144WS    | TRANSISTOR               |              |
| D1   | 1SS133      | DIODE                    |              |
| or   | MA165       | DIODE                    |              |
| R1   | QRD161J-103 | RESISTOR                 | 10KΩ, 1/8W   |
| R2   | QRD161J-104 | RESISTOR                 | 100KΩ, 1/8W  |
| R3   | QRD161J-104 | RESISTOR                 | 100KΩ, 1/8W  |
| R4   | QRD161J-104 | RESISTOR                 | 100KΩ, 1/8W  |
| R5   | QRD161J-104 | RESISTOR                 | 100KΩ, 1/8W  |
| R6   | QRD161J-822 | RESISTOR                 | 8.2KΩ, 1/8W  |
| R7   | QRD161J-104 | RESISTOR                 | 100KΩ, 1/8W  |
| R8   | QRD161J-103 | RESISTOR                 | 10KΩ, 1/8W   |
| R9   | QRD161J-563 | RESISTOR                 | 56KΩ, 1/8W   |
| R10  | QRD161J-472 | RESISTOR                 | 4.7KΩ, 1/8W  |
| C1   | QCB81HJ-102 | CAPACITOR                | 0.001μF, 50V |
| C2   | QCC11CK-104 | CAPACITOR                | 0.1μF, 16V   |
| C3   | QCB81HJ-102 | CAPACITOR                | 0.001μF, 50V |
| C4   | QCB81HJ-121 | CAPACITOR                | 120PF, 50V   |
| C5   | QEK61AM-336 | E CAPACITOR              | 33μF, 10V    |
| C6   | QFN31HJ-103 | M CAPACITOR              | 0.01μF, 50V  |
| CN1  | PU59555-7   | CAP HOUSING              |              |
| CN2  | PU59844-7   | CAP HOUSING              |              |
| CN5  | PU59844-2   | CAP HOUSING              |              |



| # | REF No. | PART No. | PART NAME, DESCRIPTION |
|---|---------|----------|------------------------|
|---|---------|----------|------------------------|

## 20. PRE/REC BOARD ASSEMBLY (43)

PWBA PB10194A-01 PRE/REC BOARD ASSEMBLY

|     |         |    |
|-----|---------|----|
| IC1 | TA8609P | IC |
| IC2 | TA8733F | IC |
| IC3 | AN6392  | IC |

|     |          |            |
|-----|----------|------------|
| Q1  | 2SC2412K | TRANSISTOR |
| Q2  | 2SC2412K | TRANSISTOR |
| Q3  | 2SC2412K | TRANSISTOR |
| Q4  | 2SC2412K | TRANSISTOR |
| Q6  | 2SC2412K | TRANSISTOR |
| Q7  | 2SC2412K | TRANSISTOR |
| Q8  | 2SA1037K | TRANSISTOR |
| Q9  | 2SA1037K | TRANSISTOR |
| Q10 | DTC144EK | TRANSISTOR |

|     |             |            |
|-----|-------------|------------|
| Q11 | DTC144EK    | TRANSISTOR |
| Q12 | DTC124EK    | TRANSISTOR |
| Q13 | 2SA1036K(R) | TRANSISTOR |
| Q14 | 2SA1036K(R) | TRANSISTOR |
| Q15 | DTC124EK    | TRANSISTOR |
| Q16 | DTC144WK    | TRANSISTOR |

|      |          |            |
|------|----------|------------|
| Q101 | DTA124EK | TRANSISTOR |
| Q102 | DTA124EK | TRANSISTOR |
| Q103 | DTC144WK | TRANSISTOR |
| Q104 | 2SA1037K | TRANSISTOR |
| Q105 | 2SC2412K | TRANSISTOR |
| Q106 | 2SC2412K | TRANSISTOR |
| Q107 | 2SA1037K | TRANSISTOR |
| Q108 | 2SC2412K | TRANSISTOR |
| Q109 | 2SA1037K | TRANSISTOR |
| Q110 | DTC124EK | TRANSISTOR |

|      |          |            |
|------|----------|------------|
| Q111 | 2SC2412K | TRANSISTOR |
| Q112 | 2SC2412K | TRANSISTOR |
| Q113 | 2SC2412K | TRANSISTOR |
| Q114 | 2SC2412K | TRANSISTOR |
| Q115 | 2SC2412K | TRANSISTOR |
| Q116 | 2SC2412K | TRANSISTOR |
| Q117 | 2SC2412K | TRANSISTOR |
| Q118 | 2SA1037K | TRANSISTOR |
| Q119 | 2SC2412K | TRANSISTOR |

|    |         |       |
|----|---------|-------|
| D1 | DAN202K | DIODE |
| D2 | DAN202K | DIODE |
| D3 | DAN202K | DIODE |
| D5 | DAN202K | DIODE |
| D6 | 1S133   | DIODE |

|      |         |       |
|------|---------|-------|
| D101 | DAN202K | DIODE |
| D102 | DAN202K | DIODE |
| D103 | DAP202K | DIODE |
| D104 | MA157   | DIODE |

| # | REF No. | PART No. | PART NAME, DESCRIPTION |
|---|---------|----------|------------------------|
|---|---------|----------|------------------------|

D105 MA157 DIODE

|     |               |          |              |
|-----|---------------|----------|--------------|
| R1  | QRSA08J-100YN | RESISTOR | 10Ω, 1/10W   |
| R2  | QRSA08J-272YN | RESISTOR | 2.7KΩ, 1/10W |
| R3  | QRSA08J-100YN | RESISTOR | 10Ω, 1/10W   |
| R4  | QRSA08J-272YN | RESISTOR | 2.7KΩ, 1/10W |
| R5  | QRSA08J-103YN | RESISTOR | 10KΩ, 1/10W  |
| R6  | QRSA08J-100YN | RESISTOR | 10Ω, 1/10W   |
| R7  | QRSA08J-100YN | RESISTOR | 10Ω, 1/10W   |
| R8  | QRSA08J-272YN | RESISTOR | 2.7KΩ, 1/10W |
| R9  | QRSA08J-272YN | RESISTOR | 2.7KΩ, 1/10W |
| R10 | QRSA08J-103YN | RESISTOR | 10KΩ, 1/10W  |

|     |               |                       |              |
|-----|---------------|-----------------------|--------------|
| R11 | QVZ3531-152   | V RESISTOR, SP CH-1 Q | 1.5KΩ        |
| R12 | QVZ3531-152   | V RESISTOR, LP CH-2 Q | 1.5KΩ        |
| R13 | QVZ3531-152   | V RESISTOR, LP CH-1 Q | 1.5KΩ        |
| R14 | QRSA08J-103YN | RESISTOR              | 10KΩ, 1/10W  |
| R15 | QVZ3531-152   | V RESISTOR, SP CH-2 Q | 1.5KΩ        |
| R19 | QRSA08J-122YN | RESISTOR              | 1.2KΩ, 1/10W |
| R20 | QRSA08J-221YN | RESISTOR              | 220Ω, 1/10W  |

|     |               |          |              |
|-----|---------------|----------|--------------|
| R21 | QRSA08J-102YN | RESISTOR | 1KΩ, 1/10W   |
| R22 | QRSA08J-122YN | RESISTOR | 1.2KΩ, 1/10W |
| R23 | QRSA08J-221YN | RESISTOR | 220Ω, 1/10W  |
| R24 | QRSA08J-102YN | RESISTOR | 1KΩ, 1/10W   |
| R25 | QRSA08J-122YN | RESISTOR | 1.2KΩ, 1/10W |
| R26 | QRSA08J-122YN | RESISTOR | 1.2KΩ, 1/10W |
| R27 | QRSA08J-103YN | RESISTOR | 10KΩ, 1/10W  |
| R28 | QRSA08J-103YN | RESISTOR | 10KΩ, 1/10W  |
| R29 | QRSA08J-393YN | RESISTOR | 39KΩ, 1/10W  |
| R30 | QRSA08J-393YN | RESISTOR | 39KΩ, 1/10W  |

|     |               |          |              |
|-----|---------------|----------|--------------|
| R31 | QRD161J-391   | RESISTOR | 390Ω, 1/6W   |
| R32 | QRSA08J-471YN | RESISTOR | 470Ω, 1/10W  |
| R33 | QRSA08J-391YN | RESISTOR | 390Ω, 1/10W  |
| R34 | QRSA08J-623YN | RESISTOR | 62KΩ, 1/10W  |
| R35 | QRSA08J-821YN | RESISTOR | 820Ω, 1/10W  |
| R36 | QRSA08J-680YN | RESISTOR | 68Ω, 1/10W   |
| R37 | QRSA08J-820YN | RESISTOR | 82Ω, 1/10W   |
| R38 | QRSA08J-102YN | RESISTOR | 1KΩ, 1/10W   |
| R39 | QRSA08J-472YN | RESISTOR | 4.7KΩ, 1/10W |
| R40 | QRSA08J-222YN | RESISTOR | 2.2KΩ, 1/10W |

|     |               |          |              |
|-----|---------------|----------|--------------|
| R41 | QRSA08J-332YN | RESISTOR | 3.3KΩ, 1/10W |
| R42 | QRSA08J-393YN | RESISTOR | 39KΩ, 1/10W  |
| R43 | QRD161J-222   | RESISTOR | 2.2KΩ, 1/6W  |
| R44 | QRSA08J-393YN | RESISTOR | 39KΩ, 1/10W  |
| R45 | QRSA08J-222YN | RESISTOR | 2.2KΩ, 1/10W |
| R46 | QRSA08J-103YN | RESISTOR | 10KΩ, 1/10W  |
| R47 | QRSA08J-103YN | RESISTOR | 10KΩ, 1/10W  |

|     |               |                     |             |
|-----|---------------|---------------------|-------------|
| R48 | PU52108-150   | POSITIVE THERMISTOR |             |
| R49 | QRD161J-333   | RESISTOR            | 33KΩ, 1/8W  |
| R50 | QRSA08J-101YN | RESISTOR            | 100Ω, 1/10W |

|     |               |          |             |
|-----|---------------|----------|-------------|
| R51 | QRSA08J-103YN | RESISTOR | 10KΩ, 1/10W |
| R52 | QRSA08J-823YN | RESISTOR | 82KΩ, 1/10W |
| R53 | QRSA08J-102YN | RESISTOR | 1KΩ, 1/10W  |
| R54 | QRSA08J-821YN | RESISTOR | 820Ω, 1/10W |
| R55 | QRSA08J-102YN | RESISTOR | 1KΩ, 1/10W  |
| R56 | QRSA08J-102YN | RESISTOR | 1KΩ, 1/10W  |

| #    | REF No.      | PART No.                          | PART NAME, DESCRIPTION |
|------|--------------|-----------------------------------|------------------------|
| R101 | QSA08J-223YN | RESISTOR                          | 22K $\Omega$ , 1/10W   |
| R102 | QSA08J-273YN | RESISTOR                          | 27K $\Omega$ , 1/10W   |
| R103 | QSA08J-102YN | RESISTOR                          | 1K $\Omega$ , 1/10W    |
| R104 | QSA08J-102YN | RESISTOR                          | 1K $\Omega$ , 1/10W    |
| R105 | QSA08J-471YN | RESISTOR                          | 470 $\Omega$ , 1/10W   |
| R106 | PUS7457-152  | V RESISTOR, FREQ RES (S-MODE, LP) |                        |
| R107 | QSA08J-103YN | RESISTOR                          | 10K $\Omega$ , 1/10W   |
| R108 | PUS7457-222  | V RESISTOR, FREQ RES (S-MODE, SP) |                        |
| R109 | QSA08J-561YN | RESISTOR                          | 560 $\Omega$ , 1/10W   |
| R110 | QSA08J-152YN | RESISTOR                          | 1.5K $\Omega$ , 1/10W  |
| R111 | QSA08J-561YN | RESISTOR                          | 560 $\Omega$ , 1/10W   |
| R112 | QSA08J-472YN | RESISTOR                          | 4.7K $\Omega$ , 1/10W  |
| R113 | QSA08J-561YN | RESISTOR                          | 560 $\Omega$ , 1/10W   |
| R114 | QSA08J-152YN | RESISTOR                          | 1.5K $\Omega$ , 1/10W  |
| R117 | QSA08J-102YN | RESISTOR                          | 1K $\Omega$ , 1/10W    |
| R118 | QSA08J-102YN | RESISTOR                          | 1K $\Omega$ , 1/10W    |
| R119 | QSA08J-122YN | RESISTOR                          | 1.2K $\Omega$ , 1/10W  |
| R120 | QSA08J-102YN | RESISTOR                          | 1K $\Omega$ , 1/10W    |
| R121 | QSA08J-102YN | RESISTOR                          | 1K $\Omega$ , 1/10W    |
| R122 | QSA08J-471YN | RESISTOR                          | 470 $\Omega$ , 1/10W   |
| R123 | QSA08J-561YN | RESISTOR                          | 560 $\Omega$ , 1/10W   |
| R124 | QSA08J-122YN | RESISTOR                          | 1.2K $\Omega$ , 1/10W  |
| R125 | QSA08J-102YN | RESISTOR                          | 1K $\Omega$ , 1/10W    |
| R126 | QSA08J-122YN | RESISTOR                          | 1.2K $\Omega$ , 1/10W  |
| R127 | QSA08J-222YN | RESISTOR                          | 2.2K $\Omega$ , 1/10W  |
| R128 | QSA08J-681YN | RESISTOR                          | 680 $\Omega$ , 1/10W   |
| R129 | QSA08J-101YN | RESISTOR                          | 100 $\Omega$ , 1/10W   |
| R130 | PUS7457-682  | V RESISTOR, FREQ RES (N-MODE, SP) |                        |
| R131 | PUS7457-332  | V RESISTOR, FREQ RES (N-MODE, LP) |                        |
| R134 | QSA08J-102YN | RESISTOR                          | 1K $\Omega$ , 1/10W    |
| R135 | QSA08J-103YN | RESISTOR                          | 10K $\Omega$ , 1/10W   |
| R136 | QSA08J-223YN | RESISTOR                          | 22K $\Omega$ , 1/10W   |
| R137 | QSA08J-471YN | RESISTOR                          | 470 $\Omega$ , 1/10W   |
| R138 | QSA08J-102YN | RESISTOR                          | 1K $\Omega$ , 1/10W    |
| R139 | QSA08J-102YN | RESISTOR                          | 1K $\Omega$ , 1/10W    |
| R140 | QSA08J-392YN | RESISTOR                          | 3.9K $\Omega$ , 1/10W  |
| R141 | QSA08J-102YN | RESISTOR                          | 1K $\Omega$ , 1/10W    |
| R142 | QSA08J-682YN | RESISTOR                          | 6.8K $\Omega$ , 1/10W  |
| R143 | QSA08J-361YN | RESISTOR                          | 360 $\Omega$ , 1/10W   |
| R144 | QSA08J-561YN | RESISTOR                          | 560 $\Omega$ , 1/10W   |
| R145 | QSA08J-152YN | RESISTOR                          | 1.5K $\Omega$ , 1/10W  |
| R146 | QSA08J-332YN | RESISTOR                          | 3.3K $\Omega$ , 1/10W  |
| R147 | QSA08J-472YN | RESISTOR                          | 4.7K $\Omega$ , 1/10W  |
| R148 | QSA08J-184YN | RESISTOR                          | 180K $\Omega$ , 1/10W  |
| R149 | QSA08J-682YN | RESISTOR                          | 6.8K $\Omega$ , 1/10W  |
| R150 | QSA08J-184YN | RESISTOR                          | 180K $\Omega$ , 1/10W  |
| R151 | QSA08J-223YN | RESISTOR                          | 22K $\Omega$ , 1/10W   |
| R152 | QSA08J-102YN | RESISTOR                          | 1K $\Omega$ , 1/10W    |
| R154 | QSA08J-821YN | RESISTOR                          | 820 $\Omega$ , 1/10W   |
| C1   | QCF1HZ-103   | CAPACITOR                         | 0.01 $\mu$ F, 50V      |
| C2   | PUB0733-200  | TRIMMER CAPACITOR, LP CH2 FO      | 20PF                   |
| C3   | QCF1HZ-103   | CAPACITOR                         | 0.01 $\mu$ F, 50V      |
| C4   | PUB0733-200  | TRIMMER CAPACITOR, LP CH1 FO      | 20PF                   |
| C5   | PUB0733-200  | TRIMMER CAPACITOR, SP CH2 FO      | 20PF                   |
| C6   | QCF1HZ-103   | CAPACITOR                         | 0.01 $\mu$ F, 50V      |

| #    | REF No.     | PART No.                     | PART NAME, DESCRIPTION |
|------|-------------|------------------------------|------------------------|
| C7   | PUB0733-100 | TRIMMER CAPACITOR, SP CH1 FO | 10PF                   |
| C8   | QCF1HZ-103  | CAPACITOR                    | 0.01 $\mu$ F, 50V      |
| C9   | QER51HM-106 | E CAPACITOR                  | 1 $\mu$ F, 50V         |
| C10  | QER51HM-106 | E CAPACITOR                  | 1 $\mu$ F, 50V         |
| C11  | QER51HM-106 | E CAPACITOR                  | 1 $\mu$ F, 50V         |
| C12  | QER51HM-106 | E CAPACITOR                  | 1 $\mu$ F, 50V         |
| C13  | QER50JM-476 | E CAPACITOR                  | 47 $\mu$ F, 6.3V       |
| C14  | QCF1HZ-103  | CAPACITOR                    | 0.01 $\mu$ F, 50V      |
| C15  | QCF1HZ-103  | CAPACITOR                    | 0.01 $\mu$ F, 50V      |
| C16  | QCF1HZ-103  | CAPACITOR                    | 0.01 $\mu$ F, 50V      |
| C17  | QCF1HZ-103  | CAPACITOR                    | 0.01 $\mu$ F, 50V      |
| C18  | QCSA1HJ-580 | CAPACITOR                    | 58PF, 50V              |
| C19  | QCSA1HJ-151 | CAPACITOR                    | 15PF, 50V              |
| C20  | QCSA1HJ-271 | CAPACITOR                    | 27PF, 50V              |
| C21  | QER50JM-476 | E CAPACITOR                  | 47 $\mu$ F, 6.3V       |
| C22  | QCF1HZ-103  | CAPACITOR                    | 0.01 $\mu$ F, 50V      |
| C23  | QCSA1HJ-331 | CAPACITOR                    | 33PF, 50V              |
| C24  | QCSA1HJ-121 | CAPACITOR                    | 12PF, 50V              |
| C25  | QCF1HZ-103  | CAPACITOR                    | 0.01 $\mu$ F, 50V      |
| C26  | QER51HM-104 | E CAPACITOR                  | 0.1 $\mu$ F, 50V       |
| C27  | QCF1HZ-103  | CAPACITOR                    | 0.01 $\mu$ F, 50V      |
| C28  | QER51HM-106 | E CAPACITOR                  | 1 $\mu$ F, 50V         |
| C29  | QER51HM-106 | E CAPACITOR                  | 1 $\mu$ F, 50V         |
| C30  | QCF1HZ-103  | CAPACITOR                    | 0.01 $\mu$ F, 50V      |
| C31  | QCF1HZ-103  | CAPACITOR                    | 0.01 $\mu$ F, 50V      |
| C32  | QER51CM-476 | E CAPACITOR                  | 47 $\mu$ F, 16V        |
| C33  | QCF1HZ-103  | CAPACITOR                    | 0.01 $\mu$ F, 50V      |
| C34  | QFN41HJ-273 | M CAPACITOR                  | 0.027 $\mu$ F, 50V     |
| C35  | QFN31HJ-103 | M CAPACITOR                  | 0.01 $\mu$ F, 50V      |
| C36  | QER51HM-106 | E CAPACITOR                  | 1 $\mu$ F, 50V         |
| C37  | QCSA1HJ-470 | CAPACITOR                    | 47PF, 50V              |
| C38  | QCF1HZ-103  | CAPACITOR                    | 0.01 $\mu$ F, 50V      |
| C39  | QCF1HZ-103  | CAPACITOR                    | 0.01 $\mu$ F, 50V      |
| C40  | QCSA1HJ-7R0 | CAPACITOR                    | 7PF, 50V               |
| C41  | QETC1CM-106 | E CAPACITOR                  | 10 $\mu$ F, 16V        |
| C42  | QCF1HZ-103  | CAPACITOR                    | 0.01 $\mu$ F, 50V      |
| C43  | QCF1HZ-103  | CAPACITOR                    | 0.01 $\mu$ F, 50V      |
| C44  | QCSA1HJ-121 | CAPACITOR                    | 12PF, 50V              |
| C45  | QCSA1HJ-101 | CAPACITOR                    | 10PF, 50V              |
| C46  | QCF1HZ-103  | CAPACITOR                    | 0.01 $\mu$ F, 50V      |
| C47  | QCF1HZ-103  | CAPACITOR                    | 0.01 $\mu$ F, 50V      |
| C48  | QCF1HZ-103  | CAPACITOR                    | 0.01 $\mu$ F, 50V      |
| C49  | QCF1HZ-103  | CAPACITOR                    | 0.01 $\mu$ F, 50V      |
| C50  | QCVB1CN-103 | CAPACITOR                    | 0.01 $\mu$ F, 16V      |
| C51  | QCF1HZ-103  | CAPACITOR                    | 0.01 $\mu$ F, 50V      |
| C52  | QCF1HZ-103  | CAPACITOR                    | 0.01 $\mu$ F, 50V      |
| C53  | QCF1HZ-103  | CAPACITOR                    | 0.01 $\mu$ F, 50V      |
| C102 | QCSA1HJ-180 | CAPACITOR                    | 18PF, 50V              |
| C103 | QCF1HZ-103  | CAPACITOR                    | 0.01 $\mu$ F, 50V      |
| C104 | QCSA1HJ-390 | CAPACITOR                    | 39PF, 50V              |
| C106 | QCSA1HJ-180 | CAPACITOR                    | 18PF, 50V              |
| C107 | QCSA1HJ-390 | CAPACITOR                    | 39PF, 50V              |
| C108 | QCSA1HJ-120 | CAPACITOR                    | 12PF, 50V              |
| C109 | QCSA1HJ-100 | CAPACITOR                    | 10PF, 50V              |
| C110 | QER50JM-476 | E CAPACITOR                  | 47 $\mu$ F, 6.3V       |

| # | REF No. | PART No.     | PART NAME, DESCRIPTION |
|---|---------|--------------|------------------------|
|   | C111    | QCFA1HZ-103  | CAPACITOR 0.01μF, 50V  |
|   | C112    | QCFA1HZ-103  | CAPACITOR 0.01μF, 50V  |
|   | C113    | QCSA1HJ-360  | CAPACITOR 36PF, 50V    |
|   | C114    | QCSA1HJ-220  | CAPACITOR 22PF, 50V    |
|   | C115    | QCSA1HJ-180  | CAPACITOR 18PF, 50V    |
|   | C117    | QCFA1HZ-103  | CAPACITOR 0.01μF, 50V  |
|   | C118    | QCSA1HJ-470  | CAPACITOR 47PF, 50V    |
|   | C120    | QCFA1HZ-103  | CAPACITOR 0.01μF, 50V  |
|   | C121    | QCFA1HZ-103  | CAPACITOR 0.01μF, 50V  |
|   | C122    | QCFA1HZ-103  | CAPACITOR 0.01μF, 50V  |
|   | C123    | QCFA1HZ-103  | CAPACITOR 0.01μF, 50V  |
|   | C124    | QCSA1HJ-681  | CAPACITOR 680PF, 50V   |
|   | C125    | QCFA1HZ-103  | CAPACITOR 0.01μF, 50V  |
|   | C126    | QER61HM-105  | E CAPACITOR 1μF, 50V   |
|   | C127    | QER61EM-475  | E CAPACITOR 4.7μF, 25V |
|   | C128    | QCFA1HZ-103  | CAPACITOR 0.01μF, 50V  |
|   | C129    | QERS0JM-476  | E CAPACITOR 47μF, 6.3V |
|   | C130    | QCFA1EZ-104  | CAPACITOR 0.1μF, 25V   |
|   | C131    | QCSA1HJ-221  | CAPACITOR 220PF, 50V   |
|   | C132    | QCSA1HJ-120  | CAPACITOR 12PF, 50V    |
|   | C133    | QCSA1HJ-770  | CAPACITOR 7PF, 50V     |
|   | C134    | QCSA1HJ-680  | CAPACITOR 68PF, 50V    |
|   | C138    | QCSB1HJ-100  | CAPACITOR 10PF, 50V    |
|   | L1      | PU48530-101K | COIL 100μH             |
|   | L2      | PU59152-161J | COIL 180μH             |
|   | L3      | PU48530-101K | COIL 100μH             |
|   | L4      | PU59152-820J | COIL 82μH              |
|   | L5      | PU59152-101J | COIL 100μH             |
|   | L6      | PU48530-101K | COIL 100μH             |
|   | L7      | PU59152-4R7K | COIL 4.7μH             |
|   | L8      | PU59152-270J | COIL 27μH              |
|   | L9      | PU59152-330J | COIL 33μH              |
|   | L10     | PU59152-330J | COIL 33μH              |
|   | L11     | PU59152-2R2K | COIL 2.2μH             |
|   | L12     | PU59152-100J | COIL 10μH              |
|   | L13     | PU59152-150J | COIL 15μH              |
|   | L101    | PU59152-560J | COIL 56μH              |
|   | L102    | PU59152-150J | COIL 15μH              |
|   | L103    | PU59152-390J | COIL 39μH              |
|   | L104    | PU59152-221J | COIL 220μH             |
|   | L105    | PU59152-100J | COIL 10μH              |
|   | L106    | PU48530-101K | COIL 100μH             |
|   | L107    | PU59152-820J | COIL 82μH              |
|   | L108    | PU59152-330J | COIL 33μH              |
|   | L109    | PU59152-820J | COIL 82μH              |
|   | L110    | PU59152-220J | COIL 22μH              |
|   | L111    | PU59152-220J | COIL 22μH              |
|   | L113    | PU48530-101K | COIL 100μH             |
|   | L114    | PU59152-8R2J | COIL 8.2μH             |
|   | L115    | PU59152-121J | COIL 120μH             |
|   | BKT1    | PQ42955      | BOARD BRACKET          |
|   | ETH1    | PQ40433-2    | EARTH LUG              |

| # | REF No. | PART No.        | PART NAME, DESCRIPTION            |
|---|---------|-----------------|-----------------------------------|
|   | SCW1    | DPSP2606Z       | SCREW, X2, FOR PRE/REC BOARD      |
|   | SCW2    | DPSP2606Z       | SCREW, FOR BRACKET                |
|   | SLD1    | PU36485         | SHIELD PLATE                      |
|   | SLD2    | PU36486         | SHIELD CASE                       |
|   | SPC1    | WBS2600Z        | T.L. WASHER                       |
|   | SPC2    | PU59210-001     | W. LOKING SPACER, X5              |
|   | WR1     | PW30109-50AAZZ7 | PARALLEL WIRE                     |
|   | WR2     | PW30109-50AAZZ7 | PARALLEL WIRE                     |
|   | TP1     | PU56008         | TEST PIN, X8, (TP1, 3-7, GND1, 2) |
|   | CN1     | PU56256-10      | CAP HOUSING                       |
|   | CN2     | PU58844-5       | CAP HOUSING                       |
|   | CN3     | PU58844-3R      | CAP HOUSING                       |
|   | CN4     | PU58844-2       | CAP HOUSING                       |
|   | CN5     | PU58844-4       | CAP HOUSING                       |
|   | CN6     | PU58844-5       | CAP HOUSING                       |
|   | CN7     | PU58844-3       | CAP HOUSING                       |

\*\*\*\*\*

## 21. FLYING ERASE BOARD ASSEMBLY (46)

| PWBA | PB30092A     | FLYING ERASE BOARD ASSEMBLY |
|------|--------------|-----------------------------|
| Q1   | 2SA933S      | TRANSISTOR                  |
| Q2   | 2SC1741S(QR) | TRANSISTOR                  |
| Q3   | 2SA933S(Q)   | TRANSISTOR                  |
| Q4   | 2SD639R      | TRANSISTOR                  |
| Q5   | 2SD639R      | TRANSISTOR                  |
| D1   | UZB.2BSC     | ZENER DIODE                 |
| D2   | 1S9133       | DIODE                       |
| R1   | QRD161J-473  | RESISTOR 47KΩ, 1/6W         |
| R2   | QRD161J-472  | RESISTOR 4.7KΩ, 1/6W        |
| R3   | QRD161J-222  | RESISTOR 2.2KΩ, 1/6W        |
| R4   | QRD161J-473  | RESISTOR 47KΩ, 1/6W         |
| R5   | QRD161J-183  | RESISTOR 18KΩ, 1/6W         |
| R6   | QRD161J-104  | RESISTOR 100KΩ, 1/6W        |
| R7   | QRD161J-121  | RESISTOR 120Ω, 1/6W         |
| R8   | QRD161J-104  | RESISTOR 100KΩ, 1/6W        |
| R9   | QRD161J-121  | RESISTOR 120Ω, 1/6W         |
| R10  | QRD161J-101  | RESISTOR 100Ω, 1/6W         |
| C1   | QCVB1CN-103  | CAPACITOR 0.01μF, 16V       |
| C2   | QCC31EJ-123  | CAPACITOR 0.012μF, 25V      |
| C3   | QCSB1HJ-560  | CAPACITOR 56PF, 50V         |
| C4   | QCSB1HJ-820  | CAPACITOR 82PF, 50V         |
| C5   | QCVB1CN-103  | CAPACITOR 0.01μF, 16V       |
| C6   | QCSB1HJ-820  | CAPACITOR 82PF, 50V         |
| C8   | QCT251J-161  | CAPACITOR 160PF             |

| #△ | REF No. | PART No.     | PART NAME, DESCRIPTION |       |
|----|---------|--------------|------------------------|-------|
|    | C9      | QCT05UJ-330  | CAPACITOR              | 33PF  |
|    | L1      | PU48530-560J | COIL                   | 56μH  |
|    | L2      | PU48530-3R3K | COIL                   | 3.3μH |
|    | L3      | PU48530-3R3K | COIL                   | 3.3μH |
|    | L4      | PU59152-101J | COIL                   | 100μH |
|    | T1      | PU56175      | S.TRANS                |       |
|    | SLD1    | PU60779      | SHIELD CASE            |       |
|    | SLD2    | PU60781      | SHIELD COVER           |       |
|    | SLD3    | PU60780      | SHIELD PLATE           |       |
|    | CN1     | PU58844-3    | CAP HOUSING            |       |
|    | CN2     | PU58844-2R   | CAP HOUSING            |       |
|    | CN3     | PU58844-2    | CAP HOUSING            |       |

\*\*\* \*\*\*\*\*

## 22. SERVO BOARD ASSEMBLY (48)

PWBA PB10152A-01 SERVO BOARD ASSEMBLY

IC1 HD49722NT IC  
IC2 BU2767S IC

Q1 DTC124ES TRANSISTOR  
or UN4212 TRANSISTOR  
or 2SC3400 TRANSISTOR  
Q2 DTA124ES TRANSISTOR  
or UN4112 TRANSISTOR  
or 2SA1346 TRANSISTOR  
Q3 DTA124ES TRANSISTOR  
or UN4112 TRANSISTOR  
or 2SA1346 TRANSISTOR  
Q4 DTA124ES TRANSISTOR  
or UN4112 TRANSISTOR  
or 2SA1346 TRANSISTOR  
Q5 DTA124ES TRANSISTOR  
or 2SA1346 TRANSISTOR  
or UN4112 TRANSISTOR  
Q6 DTC144ES TRANSISTOR  
or UN4213 TRANSISTOR  
or 2SC3399 TRANSISTOR  
Q7 DTA124ES TRANSISTOR  
or 2SA1346 TRANSISTOR  
or UN4112 TRANSISTOR

D1 1SS133 DIODE  
or MA165 DIODE  
D2 1SS133 DIODE  
or MA165 DIODE  
D3 1SS133 DIODE  
or MA165 DIODE  
D4 1SS133 DIODE

| #△ | REF No. | PART No. | PART NAME, DESCRIPTION |  |
|----|---------|----------|------------------------|--|
|    |         | or MA165 | DIODE                  |  |
|    | D5      | 1SS133   | DIODE                  |  |
|    |         | or MA165 | DIODE                  |  |
|    | D6      | 1SS133   | DIODE                  |  |
|    |         | or MA165 | DIODE                  |  |
|    | D7      | 1SS133   | DIODE                  |  |
|    |         | or MA165 | DIODE                  |  |
|    | D8      | 1SS133   | DIODE                  |  |
|    |         | or MA165 | DIODE                  |  |
|    | D9      | 1SS133   | DIODE                  |  |
|    | D10     | 1SS133   | DIODE                  |  |
|    |         | 1SS133   | DIODE                  |  |
|    | D11     | 1SS133   | DIODE                  |  |
|    |         | or MA165 | DIODE                  |  |
|    | D12     | 1SS133   | DIODE                  |  |
|    |         | or MA165 | DIODE                  |  |
|    | D13     | 1SS133   | DIODE                  |  |
|    |         | or MA165 | DIODE                  |  |
|    | D14     | 1SS133   | DIODE                  |  |
|    |         | or MA165 | DIODE                  |  |
|    | D15     | 1SS133   | DIODE                  |  |
|    |         | or MA165 | DIODE                  |  |
|    | D16     | 1SS133   | DIODE                  |  |
|    |         | or MA165 | DIODE                  |  |
|    | D17     | 1SS133   | DIODE                  |  |
|    |         | or MA165 | DIODE                  |  |
|    | D18     | 1SS133   | DIODE                  |  |
|    |         | or MA165 | DIODE                  |  |
|    | D20     | 1SS133   | DIODE                  |  |
|    |         | or MA165 | DIODE                  |  |

R1 QRSA08J-682YN RESISTOR 6.8KΩ, 1/10W  
R2 QRSA08J-102YN RESISTOR 1KΩ, 1/10W  
R3 QRSA08J-155YN RESISTOR 1.5MΩ, 1/10W  
R4 QRSA08J-102YN RESISTOR 1KΩ, 1/10W  
R5 QRSA08J-103YN RESISTOR 10KΩ, 1/10W  
R6 QRSA08J-105YN RESISTOR 1MΩ, 1/10W  
R7 QRSA08J-102YN RESISTOR 1KΩ, 1/10W  
R8 QRSA08J-102YN RESISTOR 1KΩ, 1/10W  
R9 QRSA08J-102YN RESISTOR 1KΩ, 1/10W  
R10 QRSA08J-222YN RESISTOR 2.2KΩ, 1/10W

R11 QRSA08J-273YN RESISTOR 27KΩ, 1/10W  
R12 QRSA08J-475YN RESISTOR 4.7MΩ, 1/10W  
R13 QRSA08J-333YN RESISTOR 33KΩ, 1/10W  
R14 QRSA08J-392YN RESISTOR 3.9KΩ, 1/10W  
R15 QRSA08J-153YN RESISTOR 15KΩ, 1/10W  
R16 QRSA08J-182YN RESISTOR 1.8KΩ, 1/10W  
R17 QRSA08J-105YN RESISTOR 1MΩ, 1/10W  
R18 QRSA08J-273YN RESISTOR 27KΩ, 1/10W  
R19 QRSA08J-395YN RESISTOR 3.9MΩ, 1/10W  
R20 QRSA08J-105YN RESISTOR 1MΩ, 1/10W

R21 QRSA08J-273YN RESISTOR 27KΩ, 1/10W  
R22 QRSA08J-274YN RESISTOR 270KΩ, 1/10W  
R23 QRSA08J-393YN RESISTOR 39KΩ, 1/10W  
R24 QRSA08J-475YN RESISTOR 4.7MΩ, 1/10W  
R25 QRSA08J-334YN RESISTOR 330KΩ, 1/10W  
R26 QRD161J-222 RESISTOR 2.2KΩ, 1/6W  
R27 QRSA08J-154YN RESISTOR 150KΩ, 1/10W  
R28 QRSA08J-154YN RESISTOR 150KΩ, 1/10W

| #   | REF No.       | PART No.                 | PART NAME, DESCRIPTION |
|-----|---------------|--------------------------|------------------------|
| R30 | QRD161J-102   | RESISTOR                 | 1K $\Omega$ , 1/6W     |
| R31 | QRD161J-104   | RESISTOR                 | 100K $\Omega$ , 1/6W   |
| R32 | QVZ3521-684   | V RESISTOR, SW POINT     | 680K $\Omega$          |
| R33 | QRD161J-104   | RESISTOR                 | 100K $\Omega$ , 1/6W   |
| R34 | QRSA08J-222YN | RESISTOR                 | 2.2K $\Omega$ , 1/10W  |
| R35 | QRSA08J-823YN | RESISTOR                 | 82K $\Omega$ , 1/10W   |
| R36 | QVZ3521-474   | V RESISTOR, LP X2 NOR TK | 470K $\Omega$          |
| R37 | QRSA08J-103YN | RESISTOR                 | 10K $\Omega$ , 1/10W   |
| R38 | QVZ3524-474   | V RESISTOR, SP X2 NOR TK | 470K $\Omega$          |
| R39 | QRD161J-102   | RESISTOR                 | 1K $\Omega$ , 1/6W     |
| R40 | QRD161J-223   | RESISTOR                 | 22K $\Omega$ , 1/6W    |
| R41 | QRD161J-334   | RESISTOR                 | 330K $\Omega$ , 1/6W   |
| R42 | QRSA08J-103YN | RESISTOR                 | 10K $\Omega$ , 1/10W   |
| R43 | QRSA08J-123YN | RESISTOR                 | 12K $\Omega$ , 1/10W   |
| R44 | QRSA08J-822YN | RESISTOR                 | 8.2K $\Omega$ , 1/10W  |
| R45 | QRSA08J-223YN | RESISTOR                 | 22K $\Omega$ , 1/10W   |
| R47 | QRSA08J-123YN | RESISTOR                 | 12K $\Omega$ , 1/10W   |
| R48 | QRSA08J-392YN | RESISTOR                 | 3.9K $\Omega$ , 1/10W  |
| R49 | QRSA08J-123YN | RESISTOR                 | 12K $\Omega$ , 1/10W   |
| R51 | QRSA08J-822YN | RESISTOR                 | 8.2K $\Omega$ , 1/10W  |
| R52 | QRSA08J-104YN | RESISTOR                 | 100K $\Omega$ , 1/10W  |
| R53 | QRSA08J-684YN | RESISTOR                 | 680K $\Omega$ , 1/10W  |
| R55 | QVZ3521-224   | V RESISTOR, SP SLOW      | 220K $\Omega$          |
| R56 | QRD161J-473   | RESISTOR                 | 47K $\Omega$ , 1/6W    |
| R57 | QRSA08J-154YN | RESISTOR                 | 150K $\Omega$ , 1/10W  |
| R58 | QRSA08J-274YN | RESISTOR                 | 270K $\Omega$ , 1/10W  |
| R59 | QVZ3521-104   | V RESISTOR, LP SLOW      | 100K $\Omega$          |
| R61 | QRSA08J-684YN | RESISTOR                 | 680K $\Omega$ , 1/10W  |
| R63 | QRSA08J-104YN | RESISTOR                 | 100K $\Omega$ , 1/10W  |
| C1  | QCC11CK-102   | CAPACITOR                | 0.001 $\mu$ F, 16V     |
| C2  | QEK61AM-226   | E CAPACITOR              | 22 $\mu$ F, 10V        |
| C3  | QEK61AM-226   | E CAPACITOR              | 22 $\mu$ F, 10V        |
| C4  | QCSB1HJ-150   | CAPACITOR                | 15PF, 50V              |
| C5  | QCC11CK-473   | CAPACITOR                | 0.047 $\mu$ F, 16V     |
| C6  | QCSB1HJ-102   | CAPACITOR                | 0.001 $\mu$ F, 50V     |
| C7  | QEK61HM-105   | E CAPACITOR              | 1 $\mu$ F, 50V         |
| C8  | QCSB1HJ-102   | CAPACITOR                | 0.001 $\mu$ F, 50V     |
| C9  | QCC11CK-153   | CAPACITOR                | 0.015 $\mu$ F, 16V     |
| C10 | QCSB1HJ-561   | CAPACITOR                | 560PF, 50V             |
| C11 | QCC11CK-102   | CAPACITOR                | 0.001 $\mu$ F, 16V     |
| C12 | QEK61HM-105   | E CAPACITOR              | 1 $\mu$ F, 50V         |
| C13 | QEK61AM-226   | E CAPACITOR              | 22 $\mu$ F, 10V        |
| C14 | QCSB1HJ-101   | CAPACITOR                | 100PF, 50V             |
| C15 | QCC11CK-102   | CAPACITOR                | 0.001 $\mu$ F, 16V     |
| C16 | QFV71HJ-274   | TF CAPACITOR             | 0.27 $\mu$ F, 50V      |
| C17 | QFV71HJ-564   | TF CAPACITOR             | 0.56 $\mu$ F, 50V      |
| C18 | QFV71HJ-153   | TF CAPACITOR             | 0.015 $\mu$ F, 50V     |
| C19 | QEK61EM-475   | E CAPACITOR              | 4.7 $\mu$ F, 25V       |
| C20 | QEK61EM-475   | E CAPACITOR              | 4.7 $\mu$ F, 25V       |
| C21 | QEK61CM-106   | E CAPACITOR              | 10 $\mu$ F, 16V        |
| C22 | QEK61CM-106   | E CAPACITOR              | 10 $\mu$ F, 16V        |
| C23 | QFV71HJ-334   | TF CAPACITOR             | 0.33 $\mu$ F, 50V      |
| C24 | QFV71HJ-333   | TF CAPACITOR             | 0.033 $\mu$ F, 50V     |
| C25 | QCSB1HJ-471   | CAPACITOR                | 470PF, 50V             |

| #   | REF No.     | PART No.                 | PART NAME, DESCRIPTION   |
|-----|-------------|--------------------------|--------------------------|
| C26 | QFL31HJ-682 | M CAPACITOR              | 0.0068 $\mu$ F, 50V      |
| C27 | QFL31HJ-102 | M CAPACITOR              | 0.001 $\mu$ F, 50V       |
| C28 | QFV71HJ-124 | TF CAPACITOR             | 0.12 $\mu$ F, 50V        |
| C29 | QCF31HP-223 | CAPACITOR                | 0.022 $\mu$ F, 50V       |
| C30 | QCSB1HJ-101 | CAPACITOR                | 100PF, 50V               |
| C31 | QCSB1HJ-101 | CAPACITOR                | 100PF, 50V               |
| C32 | QCC11CK-102 | CAPACITOR                | 0.001 $\mu$ F, 16V       |
| C33 | QFV71HJ-224 | TF CAPACITOR             | 0.22 $\mu$ F, 50V        |
| C34 | QEK61AM-226 | E CAPACITOR              | 22 $\mu$ F, 10V          |
| C35 | QFV71HJ-393 | TF CAPACITOR             | 0.039 $\mu$ F, 50V       |
| C36 | QFV71HJ-274 | TF CAPACITOR             | 0.27 $\mu$ F, 50V        |
| C37 | QFV71HJ-124 | TF CAPACITOR             | 0.12 $\mu$ F, 50V        |
| C38 | QFV71HJ-393 | TF CAPACITOR             | 0.039 $\mu$ F, 50V       |
| C39 | QCSB1HJ-102 | CAPACITOR                | 0.001 $\mu$ F, 50V       |
| C40 | QCSB1HJ-561 | CAPACITOR                | 560PF, 50V               |
| C41 | QFV71HJ-474 | TF CAPACITOR             | 0.47 $\mu$ F, 50V        |
| C42 | QCSB1HJ-102 | CAPACITOR                | 0.001 $\mu$ F, 50V       |
| TH1 | or          | NTH5D223KA<br>NTH5D223LA | THERMISTOR<br>THERMISTOR |
| TP1 | PU45908-3   | TEST PIN, X2, (TP1, GND) |                          |
| CN1 | PU58844-4   | CAP HOUSING              |                          |
| CN4 | PU58931-14  | HOUSING                  |                          |
| CN5 | PU58931-12  | HOUSING                  |                          |
| CN6 | PU58844-8   | CAP HOUSING              |                          |

\*\*\*\*\*

## 23. DECK TERMINAL BOARD ASSEMBLY {51}{53}

PWBA PB20013D-02 DECK TERMINAL BOARD ASSY

### — DECK TERMINAL BOARD ASSEMBLY {51} —

PWBA1 PB20013C1 DECK TERMINAL BOARD ASSY

R1 QRD161J-151 RESISTOR 150 $\Omega$ , 1/8W  
R3 QRD161J-331 RESISTOR 330 $\Omega$ , 1/8W

PS1 PU60271 PHOTO INTERRUPTER

CN1 PEMC0722-017 WIRE TRAP

### — REC SAFETY BOARD ASSEMBLY {53} —

PWBA3 PB20013A3 REC SAFETY BOARD ASSY

S1 PU58844-1-3 REC SAFETY SWITCH

#△ REF No. PART No. PART NAME, DESCRIPTION

\*\*\*\*\*

## 24. RELAY BOARD ASSEMBLY (52)

|       |                    |                  |            |
|-------|--------------------|------------------|------------|
| PWBA2 | PB20013C2-02       | RELAY BOARD ASSY |            |
| G1    | QCC11EJ-104        | CAPACITOR        | 0.1μF, 25V |
| LC1   | PU59736-471        | N FILTER         |            |
| LC2   | PU59736-471        | N FILTER         |            |
| K1    | PU60281-5          | FERRITE BEADS    |            |
| WR2   | PW30113-GOABZ62    | PARALLEL WIRE    |            |
|       | or PW30118-GOABZ62 | PARALLEL WIRE    |            |

\*\*\*\*\*

## 25. END SENSOR BOARD ASSEMBLY (54)

|       |             |                       |  |
|-------|-------------|-----------------------|--|
| PWBA4 | PB20013A4   | END SENSOR BOARD ASSY |  |
| G1    | PN268R-NC   | PHOTO TRANSISTOR      |  |
| HD1   | PQ31047-1-4 | E.S. HOLDER           |  |
| CN1   | PU59945-102 | WIRE SOCKET           |  |

\*\*\*\*\*

## 26. CASSETTE HOUSING BOARD (56)

|      |             |                        |            |
|------|-------------|------------------------|------------|
| PWB1 | PB30043     | CASSETTE HOUSING BOARD |            |
|      | or PB30097  | CASSETTE HOUSING BOARD |            |
| Q1   | PN268R-NC   | PHOTO TRANSISTOR       |            |
| R1   | QRD162J-471 | RESISTOR               | 470Ω, 1/6W |
| PHS1 | PU58879     | PHOTO INTERRUPTER      |            |
| CN1  | PU58844-106 | CAP HOUSING            |            |

\*\*\*\*\*

## 27. UPPER DRUM BOARD (62) (63)

|      |         |                        |  |
|------|---------|------------------------|--|
| PWB1 | PDM3161 | BOARD (UPPER DRUM), X2 |  |
|------|---------|------------------------|--|

#△ REF No. PART No. PART NAME, DESCRIPTION

\*\*\*\*\*

## 28. AUTO TRACKING BOARD ASSEMBLY (83)

|      |                   |                              |             |
|------|-------------------|------------------------------|-------------|
| PWBA | PB20399A          | AUTO TRACKING BOARD ASSEMBLY |             |
| IC1  | BU4066B           | IC                           |             |
|      | or MC14066BCP     | IC                           |             |
| IC2  | LM324N            | IC                           |             |
|      | or BA10324        | IC                           |             |
| Q1   | 2SC1740S(RS)      | TRANSISTOR                   |             |
|      | or 2SC3199(G)-TJK | TRANSISTOR                   |             |
|      | or 2SC3311A(RS)   | TRANSISTOR                   |             |
|      | or 2SC536SPA(FG)  | TRANSISTOR                   |             |
| Q2   | 2SC1740S(RS)      | TRANSISTOR                   |             |
|      | or 2SC536SPA(FG)  | TRANSISTOR                   |             |
|      | or 2SC3199(G)-TJK | TRANSISTOR                   |             |
|      | or 2SC3311A(RS)   | TRANSISTOR                   |             |
| Q3   | 2SC1740S(RS)      | TRANSISTOR                   |             |
|      | or 2SC536SPA(FG)  | TRANSISTOR                   |             |
|      | or 2SC3199(G)-TJK | TRANSISTOR                   |             |
|      | or 2SC3311A(RS)   | TRANSISTOR                   |             |
| Q4   | DTA124ES          | TRANSISTOR                   |             |
| C5   | 2SA1267(G)-TJK    | TRANSISTOR                   |             |
|      | or 2SA1309(RS)    | TRANSISTOR                   |             |
|      | or 2SA933S(RS)    | TRANSISTOR                   |             |
| Q6   | 2SC1740S(RS)      | TRANSISTOR                   |             |
|      | or 2SC536SPA(FG)  | TRANSISTOR                   |             |
|      | or 2SC3311A(RS)   | TRANSISTOR                   |             |
|      | or 2SC3199(G)-TJK | TRANSISTOR                   |             |
| Q7   | DTG144WS          | TRANSISTOR                   |             |
| Q9   | 2SC1740S(RS)      | TRANSISTOR                   |             |
|      | or 2SC3199(G)-TJK | TRANSISTOR                   |             |
|      | or 2SC536SPA(FG)  | TRANSISTOR                   |             |
|      | or 2SC3311A(RS)   | TRANSISTOR                   |             |
| Q10  | 2SC1740S(RS)      | TRANSISTOR                   |             |
|      | or 2SC536SPA(FG)  | TRANSISTOR                   |             |
|      | or 2SC3199(G)-TJK | TRANSISTOR                   |             |
|      | or 2SC3311A(RS)   | TRANSISTOR                   |             |
| D1   | OA90              | DIODE                        |             |
| D2   | OA90              | DIODE                        |             |
| D3   | RD9.1ES-T1B3      | ZENER DIODE                  |             |
|      | or UZ9.1BSC       | ZENER DIODE                  |             |
| D4   | 1SS133            | DIODE                        |             |
|      | or MA165          | DIODE                        |             |
| D5   | 1SS133            | DIODE                        |             |
|      | or MA165          | DIODE                        |             |
| D6   | 1SS133            | DIODE                        |             |
|      | or MA165          | DIODE                        |             |
| R1   | QRD161J-104       | RESISTOR                     | 100KΩ, 1/6W |
| R2   | QRD161J-104       | RESISTOR                     | 100KΩ, 1/6W |
| R3   | QRD161J-102       | RESISTOR                     | 1KΩ, 1/6W   |
| R4   | QRD161J-102       | RESISTOR                     | 1KΩ, 1/6W   |
| R5   | QRD161J-683       | RESISTOR                     | 68KΩ, 1/6W  |

| #△ REF No. | PART No.     | PART NAME, DESCRIPTION   |              |
|------------|--------------|--------------------------|--------------|
| R6         | QRD161J-103  | RESISTOR                 | 10KΩ, 1/6W   |
| R7         | QRD161J-222  | RESISTOR                 | 2.2KΩ, 1/6W  |
| R8         | QRD161J-221  | RESISTOR                 | 220Ω, 1/6W   |
| R9         | QRD161J-104  | RESISTOR                 | 100KΩ, 1/6W  |
| R10        | QRD161J-332  | RESISTOR                 | 3.3KΩ, 1/6W  |
| R11        | QRD161J-103  | RESISTOR                 | 10KΩ, 1/6W   |
| R12        | QRD161J-105  | RESISTOR                 | 1MΩ, 1/6W    |
| R13        | QRD161J-105  | RESISTOR                 | 1MΩ, 1/6W    |
| R14        | QRD161J-105  | RESISTOR                 | 1MΩ, 1/6W    |
| R15        | QRD161J-105  | RESISTOR                 | 1MΩ, 1/6W    |
| R18        | QRD161J-103  | RESISTOR                 | 10KΩ, 1/6W   |
| R19        | QRD161J-394  | RESISTOR                 | 390KΩ, 1/6W  |
| R20        | QRD161J-824  | RESISTOR                 | 820KΩ, 1/6W  |
| R23        | QRD161J-822  | RESISTOR                 | 8.2KΩ, 1/6W  |
| R24        | QRD161J-123  | RESISTOR                 | 12KΩ, 1/6W   |
| R25        | QRD161J-103  | RESISTOR                 | 10KΩ, 1/6W   |
| R26        | QRD161J-103  | RESISTOR                 | 10KΩ, 1/6W   |
| R29        | QRD161J-333  | RESISTOR                 | 33KΩ, 1/6W   |
| R30        | QRD161J-153  | RESISTOR                 | 15KΩ, 1/6W   |
| R31        | QRD161J-152  | RESISTOR                 | 1.5KΩ, 1/6W  |
| R32        | QRD161J-821  | RESISTOR                 | 820Ω, 1/6W   |
| R33        | QRD161J-272  | RESISTOR                 | 2.7KΩ, 1/6W  |
| R34        | QRD161J-102  | RESISTOR                 | 1KΩ, 1/6W    |
| R35        | QRD161J-102  | RESISTOR                 | 1KΩ, 1/6W    |
| C1         | QCVB1CM-103  | CAPACITOR                | 0.01μF, 16V  |
| C2         | QCVB1HJ-271  | CAPACITOR                | 270PF, 50V   |
| C4         | QCVB1CM-103  | CAPACITOR                | 0.01μF, 16V  |
| C5         | QCVB1CM-103  | CAPACITOR                | 0.01μF, 16V  |
| C7         | QCVB1CM-103  | CAPACITOR                | 0.01μF, 16V  |
| C8         | QCVB1CM-103  | CAPACITOR                | 0.01μF, 16V  |
| C9         | QCVB1CM-103  | CAPACITOR                | 0.01μF, 16V  |
| C10        | QEK61CM-106  | E CAPACITOR              | 10μF, 16V    |
| C11        | QEK61CM-106  | E CAPACITOR              | 10μF, 16V    |
| C12        | QCVB1CM-103  | CAPACITOR                | 0.01μF, 16V  |
| C13        | QFV71HJ-473  | TF CAPACITOR             | 0.047μF, 50V |
| C14        | QCVB1CM-103  | CAPACITOR                | 0.01μF, 16V  |
| C15        | QCVB1HJ-331  | CAPACITOR                | 330PF, 50V   |
| C16        | QCVB1HJ-821  | CAPACITOR                | 820PF, 50V   |
| L2         | PU59152-270J | COIL                     | 27μH         |
| SPC1       | PU59210-001  | W. LOKING SPACER, X2     |              |
| TP1        | PU45908-3    | TEST PIN, X2, (TP1, GND) |              |
| CN1        | PU58844-102  | CAP HOUSING              |              |
| CN2        | PU58844-102R | CAP HOUSING              |              |
| CN3        | PU59555-106  | CAP HOUSING              |              |

| #△ REF No. | PART No. | PART NAME, DESCRIPTION |
|------------|----------|------------------------|
| *****      |          |                        |

## 29. DECODE/VPT BOARD ASSEMBLY (87)

|      |                   |                           |
|------|-------------------|---------------------------|
| PWBA | PB10341A-01       | DECODE/VPT BOARD ASSEMBLY |
| IC1  | M52008SP          | IC                        |
| IC2  | NJM2233BM         | IC                        |
| IC3  | TC4S66F           | IC                        |
| IC4  | TC4S66F           | IC                        |
| IC5  | LM358PS           | IC                        |
| IC6  | TC4S66F           | IC                        |
| IC7  | NJM2233BM         | IC                        |
| IC8  | TL026CPS          | IC                        |
| IC9  | LM324NS           | SOP IC                    |
| IC10 | TC4S66F           | IC                        |
| IC11 | TC4S66F           | IC                        |
| IC12 | XN4601            | TRANSISTOR                |
| IC13 | HA1921BNT         | IC                        |
| IC14 | LM358PS           | IC                        |
| IC15 | MC74HC4066F       | SOP IC                    |
| IC16 | MB40878PQ-G       | IC                        |
| IC17 | MC74HC4053F       | IC                        |
| IC18 | V7040             | IC                        |
| IC19 | NJM2246M          | IC                        |
| IC20 | NJM2245M          | IC                        |
| IC21 | NJM2234M          | IC                        |
| IC22 | NJM2235M          | IC                        |
| IC23 | NJM2235M          | IC                        |
| IC24 | NJM2235M          | IC                        |
| IC25 | TC7S00F           | IC                        |
| IC26 | TC7S00F           | IC                        |
| IC27 | TC7S04F           | IC                        |
| IC28 | TC4S69F           | IC                        |
| IC29 | TC4S69F           | IC                        |
| IC30 | MC74HC74F         | IC                        |
| IC31 | BA7806F           | IC                        |
| IC32 | TC7S04F           | IC                        |
| IC33 | TC7S04F           | IC                        |
| IC34 | TC7SU04F          | IC                        |
| IC35 | TDA2501           | IC                        |
| IC36 | MC74HCU04F        | IC                        |
| IC37 | CAT93C46P         | IC                        |
| IC38 | MCU2632           | IC                        |
| IC39 | UPD75008CU-050    | IC                        |
|      | or UPD75P008CU050 | IC                        |
| IC40 | DMA2270           | IC                        |
| IC41 | UPD41464CF-12     | IC                        |
| IC42 | AMU2481           | IC                        |
| IC43 | JCP0010           | IC                        |
| IC44 | UPD42101G-3       | IC                        |
| IC45 | AFL87F15000E1     | IC                        |
| IC47 | AFL87F15000E1     | IC                        |
| IC48 | AFL87F15000E1     | IC                        |
| IC49 | LM358PS           | IC                        |
| IC50 | TC7S08F           | IC                        |

| #A | REF No. | PART No.       | PART NAME, DESCRIPTION |
|----|---------|----------------|------------------------|
|    | IC51    | NJM2243M       | IC                     |
|    | IC52    | MC74HC02AF     | IC                     |
|    | IC53    | NJM2235M       | IC                     |
|    | IC54    | MC14053BF      | SOP IC                 |
|    | or      | TC74HC04AF     | IC                     |
|    | IC56    | NJM78L08UA     | IC                     |
|    | IC59    | LM393PS        | IC                     |
|    | IC60    | TC7S08F        | IC                     |
|    | IC61    | TC7S08F        | IC                     |
|    | IC62    | TC4866F        | IC                     |
|    | IC63    | LM358PS        | IC                     |
|    | IC64    | LM393PS        | IC                     |
|    | IC65    | TC7S32F        | IC                     |
|    | IC501   | UPD78213GJ-5BJ | IC                     |
|    | IC502   | HM6264ALFP     | IC                     |
|    | IC503   | HM6264ALFP     | IC                     |
|    | or      | MSM5165FP      | IC                     |
|    | IC504   | SDA5243        | IC                     |
|    | IC505   | SDA5231        | IC                     |
|    | IC506   | MC74HC74F      | IC                     |
|    | or      | TC74HC74AF     | IC                     |
|    | IC508   | IC-PST529DMT-X | IC                     |
|    | IC509   | S-8052ANY-NH-X | IC                     |
|    | or      | TC74HC573AF    | IC                     |
|    | IC511   | UPD23C512C-206 | IC                     |
|    | or      | UPD27C512C-206 | IC                     |
|    | IC512   | MC74HC10F      | IC                     |
|    | or      | TC74HC10AF     | IC                     |
|    | IC513   | TC7S32F        | IC                     |
|    | Q1      | 2SC3932(ST)    | TRANSISTOR             |
|    | Q2      | 2SA1532(C)     | TRANSISTOR             |
|    | Q3      | 2SC3932(ST)    | TRANSISTOR             |
|    | Q4      | 2SC3931(CD)    | TRANSISTOR             |
|    | Q5      | 2SA1576(QR)    | TRANSISTOR             |
|    | Q6      | 2SA1576(QR)    | TRANSISTOR             |
|    | Q7      | 2SC4081(QR)    | TRANSISTOR             |
|    | Q11     | 2SA1576(QR)    | TRANSISTOR             |
|    | Q12     | 2SC4081(QR)    | TRANSISTOR             |
|    | Q13     | 2SC4081(QR)    | TRANSISTOR             |
|    | Q15     | 2SC4081(QR)    | TRANSISTOR             |
|    | Q17     | 2SC4081(QR)    | TRANSISTOR             |
|    | Q18     | 2SC4081(QR)    | TRANSISTOR             |
|    | Q19     | 2SC4081(QR)    | TRANSISTOR             |
|    | Q20     | 2SC4081(QR)    | TRANSISTOR             |
|    | Q21     | 2SA1576(QR)    | TRANSISTOR             |
|    | Q22     | 2SA1576(QR)    | TRANSISTOR             |
|    | Q23     | 2SC4081(QR)    | TRANSISTOR             |
|    | Q24     | 2SA1576(QR)    | TRANSISTOR             |
|    | Q25     | 2SA1576(QR)    | TRANSISTOR             |
|    | Q26     | 2SC4081(QR)    | TRANSISTOR             |
|    | Q27     | 2SA1576(QR)    | TRANSISTOR             |
|    | Q28     | 2SA1576(QR)    | TRANSISTOR             |
|    | Q29     | 2SC4081(QR)    | TRANSISTOR             |
|    | Q30     | 2SA1576(QR)    | TRANSISTOR             |

| #A | REF No. | PART No.    | PART NAME, DESCRIPTION |
|----|---------|-------------|------------------------|
|    | Q31     | 2SA1576(QR) | TRANSISTOR             |
|    | Q32     | 2SA1576(QR) | TRANSISTOR             |
|    | Q33     | 2SA1576(QR) | TRANSISTOR             |
|    | Q34     | 2SA1576(QR) | TRANSISTOR             |
|    | Q35     | 2SK210(QR)  | TRANSISTOR             |
|    | Q36     | DTC124EU    | TRANSISTOR             |
|    | Q37     | DTA124EU    | TRANSISTOR             |
|    | Q38     | DTC124EU    | TRANSISTOR             |
|    | Q40     | 2SC4081(QR) | TRANSISTOR             |
|    | Q41     | 2SC4081(QR) | TRANSISTOR             |
|    | Q42     | 2SA1576(QR) | TRANSISTOR             |
|    | Q43     | 2SA1576(QR) | TRANSISTOR             |
|    | Q44     | 2SC4081(QR) | TRANSISTOR             |
|    | Q45     | 2SC4081(QR) | TRANSISTOR             |
|    | Q46     | 2SD1766(QR) | TRANSISTOR             |
|    | Q47     | 2SC4081(QR) | TRANSISTOR             |
|    | Q48     | 2SC4081(QR) | TRANSISTOR             |
|    | Q51     | 2SD1766(QR) | TRANSISTOR             |
|    | Q52     | 2SD1812(PQ) | TRANSISTOR             |
|    | Q53     | 2SB1425(EU) | TRANSISTOR             |
|    | Q54     | DTC114EU    | TRANSISTOR             |
|    | Q55     | DTC114EU    | TRANSISTOR             |
|    | Q57     | 2SD1812(PQ) | TRANSISTOR             |
|    | Q58     | 2SC4081(QR) | TRANSISTOR             |
|    | Q59     | 2SK621      | FE TRANSISTOR          |
|    | Q60     | 2SC4081(QR) | TRANSISTOR             |
|    | Q61     | 2SK621      | FE TRANSISTOR          |
|    | Q62     | DTA124EU    | TRANSISTOR             |
|    | Q63     | DTC114EU    | TRANSISTOR             |
|    | Q64     | DTC114EU    | TRANSISTOR             |
|    | Q65     | DTC124EU    | TRANSISTOR             |
|    | Q66     | 2SC4081(QR) | TRANSISTOR             |
|    | Q67     | 2SC4081(QR) | TRANSISTOR             |
|    | Q68     | 2SC4081(QR) | TRANSISTOR             |
|    | Q69     | DTC124EU    | TRANSISTOR             |
|    | Q70     | 2SK621      | FE TRANSISTOR          |
|    | Q71     | DTC114EU    | TRANSISTOR             |
|    | Q72     | 2SC4081(QR) | TRANSISTOR             |
|    | Q73     | 2SA1576(QR) | TRANSISTOR             |
|    | Q74     | 2SC4081(QR) | TRANSISTOR             |
|    | Q75     | 2SC4081(QR) | TRANSISTOR             |
|    | Q76     | 2SC4081(QR) | TRANSISTOR             |
|    | Q77     | 2SA1576(QR) | TRANSISTOR             |
|    | Q502    | 2SK621      | FE TRANSISTOR          |
|    | Q503    | 2SA1576(QR) | TRANSISTOR             |
|    | Q505    | 2SK621      | FE TRANSISTOR          |
|    | Q506    | 2SB1010(QR) | TRANSISTOR             |
|    | Q507    | 2SD1292(QR) | TRANSISTOR             |
|    | D1      | DA204U      | DIODE                  |
|    | D2      | DAP202U     | DIODE                  |
|    | D3      | DA204U      | DIODE                  |
|    | D4      | DA204U      | DIODE                  |
|    | D5      | DA204U      | DIODE                  |
|    | D6      | 1SS99       | DIODE                  |
|    | D7      | 1SS99       | DIODE                  |



| #Δ   | REF No. | PART No.      | PART NAME, DESCRIPTION |  |
|------|---------|---------------|------------------------|--|
| D8   |         | DA204U        | DIODE                  |  |
| D9   |         | DA204U        | DIODE                  |  |
| D10  |         | DAN202U       | DIODE                  |  |
| D11  |         | DAN202U       | DIODE                  |  |
| D12  |         | DAP202U       | DIODE                  |  |
| D14  |         | DAP202U       | DIODE                  |  |
| D15  |         | MTZ10B        | ZENER DIODE            |  |
| D16  |         | DAN202U       | DIODE                  |  |
| D17  |         | DAN202U       | DIODE                  |  |
| D18  |         | DAN202U       | DIODE                  |  |
| D19  |         | DAN202U       | DIODE                  |  |
| D20  |         | DAN202U       | DIODE                  |  |
| D21  |         | DAN202U       | DIODE                  |  |
| D22  |         | MTZ5.6B       | ZENER DIODE            |  |
| D23  |         | DAP202U       | DIODE                  |  |
| D24  |         | DAP202U       | DIODE                  |  |
| D25  |         | DAN202U       | DIODE                  |  |
| D26  |         | DAN202U       | DIODE                  |  |
| D27  |         | DAN202U       | DIODE                  |  |
| D28  |         | DAN202U       | DIODE                  |  |
| D29  |         | DAP202U       | DIODE                  |  |
| D30  |         | DAN202U       | DIODE                  |  |
| D31  |         | DAN202U       | DIODE                  |  |
| D32  |         | 11E2          | DIODE                  |  |
| D501 |         | DAP202U       | DIODE                  |  |
| D502 |         | DAP202U       | DIODE                  |  |
| D503 |         | DAP202U       | DIODE                  |  |
| D505 |         | DAN202U       | DIODE                  |  |
| D506 |         | DAP202U       | DIODE                  |  |
| D508 |         | RB400D        | DIODE                  |  |
| D509 |         | DAP202U       | DIODE                  |  |
| D510 |         | DA204U        | DIODE                  |  |
| R1   |         | QRSA08J-750YN | RESISTOR 75Ω, 1/10W    |  |
| R2   |         | QRSA08J-331YN | RESISTOR 330Ω, 1/10W   |  |
| R3   |         | QRSA08J-682YN | RESISTOR 6.8KΩ, 1/10W  |  |
| R4   |         | QRSA08J-122YN | RESISTOR 1.2KΩ, 1/10W  |  |
| R5   |         | QRS188J-681YN | RESISTOR 680Ω, 1/8W    |  |
| R6   |         | QRSA08J-101YN | RESISTOR 100Ω, 1/10W   |  |
| R7   |         | QRSA08J-220YN | RESISTOR 22Ω, 1/10W    |  |
| R8   |         | QRSA08J-271YN | RESISTOR 270Ω, 1/10W   |  |
| R9   |         | QRSA08J-472YN | RESISTOR 4.7KΩ, 1/10W  |  |
| R10  |         | QRSA08J-272YN | RESISTOR 2.7KΩ, 1/10W  |  |
| R11  |         | QRSA08J-221YN | RESISTOR 220Ω, 1/10W   |  |
| R12  |         | QRSA08J-102YN | RESISTOR 1KΩ, 1/10W    |  |
| R13  |         | QRS188J-471YN | RESISTOR 470Ω, 1/8W    |  |
| R14  |         | QRSA08J-101YN | RESISTOR 100Ω, 1/10W   |  |
| R15  |         | QRSA08J-220YN | RESISTOR 22Ω, 1/10W    |  |
| R16  |         | QRSA08J-152YN | RESISTOR 1.5KΩ, 1/10W  |  |
| R17  |         | QRSA08J-392YN | RESISTOR 3.9KΩ, 1/10W  |  |
| R18  |         | QVZ3521-472   | V RESISTOR 4.7KΩ       |  |
| R19  |         | QRSA08J-182YN | RESISTOR 1.8KΩ, 1/10W  |  |
| R20  |         | QRSA08J-924YN | RESISTOR 820KΩ, 1/10W  |  |
| R21  |         | QRSA08J-470YN | RESISTOR 47Ω, 1/10W    |  |
| R22  |         | QRSA08J-561YN | RESISTOR 560Ω, 1/10W   |  |

| #Δ  | REF No. | PART No.      | PART NAME, DESCRIPTION        |  |
|-----|---------|---------------|-------------------------------|--|
| R23 |         | QRSA08J-103YN | RESISTOR 10KΩ, 1/10W          |  |
| R24 |         | QRSA08J-561YN | RESISTOR 560Ω, 1/10W          |  |
| R25 |         | QRSA08J-152YN | RESISTOR 1.5KΩ, 1/10W         |  |
| R26 |         | QRSA08J-101YN | RESISTOR 100Ω, 1/10W          |  |
| R27 |         | QRSA08J-182YN | RESISTOR 1.8KΩ, 1/10W         |  |
| R28 |         | QRSA08J-102YN | RESISTOR 1KΩ, 1/10W           |  |
| R29 |         | QRSA08J-473YN | RESISTOR 47KΩ, 1/10W          |  |
| R30 |         | QRSA08J-333YN | RESISTOR 33KΩ, 1/10W          |  |
| R31 |         | QRSA08J-103YN | RESISTOR 10KΩ, 1/10W          |  |
| R32 |         | NVP1304-472N  | V RESISTOR 4.7KΩ              |  |
| R33 |         | QRSA08J-272YN | RESISTOR 2.7KΩ, 1/10W         |  |
| R34 |         | QRSA08J-103YN | RESISTOR 10KΩ, 1/10W          |  |
| R35 |         | QRSA08J-224YN | RESISTOR 220KΩ, 1/10W         |  |
| R36 |         | QRSA08J-682YN | RESISTOR 6.8KΩ, 1/10W         |  |
| R37 |         | QRSA08J-103YN | RESISTOR 10KΩ, 1/10W          |  |
| R38 |         | QRSA08J-333YN | RESISTOR 33KΩ, 1/10W          |  |
| R39 |         | QRSA08J-103YN | RESISTOR 10KΩ, 1/10W          |  |
| R40 |         | QRSA08J-682YN | RESISTOR 6.8KΩ, 1/10W         |  |
| R41 |         | QRSA08J-471YN | RESISTOR 470Ω, 1/10W          |  |
| R42 |         | QRSA08J-561YN | RESISTOR 560Ω, 1/10W          |  |
| R43 |         | QRSA08J-182YN | RESISTOR 1.8KΩ, 1/10W         |  |
| R45 |         | QRSA08J-222YN | RESISTOR 2.2KΩ, 1/10W         |  |
| R46 |         | QRSA08J-473YN | RESISTOR 47KΩ, 1/10W          |  |
| R47 |         | QRSA08J-102YN | RESISTOR 1KΩ, 1/10W           |  |
| R48 |         | QRSA08J-182YN | RESISTOR 1.8KΩ, 1/10W         |  |
| R49 |         | QRSA08J-222YN | RESISTOR 2.2KΩ, 1/10W         |  |
| R50 |         | QRSA08J-222YN | RESISTOR 2.2KΩ, 1/10W         |  |
| R51 |         | QRSA08J-102YN | RESISTOR 1KΩ, 1/10W           |  |
| R52 |         | QRSA08J-102YN | RESISTOR 1KΩ, 1/10W           |  |
| R53 |         | QRSA08J-222YN | RESISTOR 2.2KΩ, 1/10W         |  |
| R54 |         | QRSA08J-223YN | RESISTOR 22KΩ, 1/10W          |  |
| R55 |         | NVP1304-472N  | V RESISTOR BASEBAND AGC 4.7KΩ |  |
| R56 |         | QRSA08J-222YN | RESISTOR 2.2KΩ, 1/10W         |  |
| R57 |         | QRSA08J-103YN | RESISTOR 10KΩ, 1/10W          |  |
| R58 |         | QRSA08J-104YN | RESISTOR 100KΩ, 1/10W         |  |
| R59 |         | QRSA08J-124YN | RESISTOR 120KΩ, 1/10W         |  |
| R60 |         | QRSA08J-331YN | RESISTOR 330Ω, 1/10W          |  |
| R61 |         | QRSA08J-102YN | RESISTOR 1KΩ, 1/10W           |  |
| R62 |         | QRSA08J-333YN | RESISTOR 33KΩ, 1/10W          |  |
| R63 |         | QRSA08J-334YN | RESISTOR 330KΩ, 1/10W         |  |
| R64 |         | QRSA08J-105YN | RESISTOR 1MΩ, 1/10W           |  |
| R65 |         | QRSA08J-224YN | RESISTOR 220KΩ, 1/10W         |  |
| R66 |         | QRSA08J-123YN | RESISTOR 12KΩ, 1/10W          |  |
| R67 |         | QRSA08J-103YN | RESISTOR 10KΩ, 1/10W          |  |
| R68 |         | QRSA08J-103YN | RESISTOR 10KΩ, 1/10W          |  |
| R69 |         | QRSA08J-103YN | RESISTOR 10KΩ, 1/10W          |  |
| R70 |         | QRSA08J-103YN | RESISTOR 10KΩ, 1/10W          |  |
| R73 |         | QVZ3521-102   | V RESISTOR 1KΩ                |  |
| R80 |         | QRSA08J-103YN | RESISTOR 10KΩ, 1/10W          |  |
| R81 |         | QRSA08J-821YN | RESISTOR 820Ω, 1/10W          |  |
| R82 |         | QRSA08J-332YN | RESISTOR 3.3KΩ, 1/10W         |  |
| R83 |         | QRSA08J-223YN | RESISTOR 22KΩ, 1/10W          |  |
| R84 |         | QRSA08J-821YN | RESISTOR 820Ω, 1/10W          |  |
| R85 |         | QRSA08J-102YN | RESISTOR 1KΩ, 1/10W           |  |
| R86 |         | QRSA08J-821YN | RESISTOR 820Ω, 1/10W          |  |
| R87 |         | QRSA08J-821YN | RESISTOR 820Ω, 1/10W          |  |

| #A   | REF No.      | PART No. | PART NAME, DESCRIPTION |  | #A   | REF No.      | PART No.                    | PART NAME, DESCRIPTION |  |
|------|--------------|----------|------------------------|--|------|--------------|-----------------------------|------------------------|--|
| R88  | QSA08J-821YN | RESISTOR | 820Ω, 1/10W            |  | R153 | QSA08J-103YN | RESISTOR                    | 10KΩ, 1/10W            |  |
| R89  | QSA08J-821YN | RESISTOR | 820Ω, 1/10W            |  | R154 | QSA08J-122YN | RESISTOR                    | 1.2KΩ, 1/10W           |  |
| R90  | QSA08J-821YN | RESISTOR | 820Ω, 1/10W            |  | R155 | QSA08J-681YN | RESISTOR                    | 680Ω, 1/10W            |  |
| R91  | QSA08J-821YN | RESISTOR | 820Ω, 1/10W            |  | R156 | QSA08J-392YN | RESISTOR                    | 3.9KΩ, 1/10W           |  |
| R92  | QSA08J-821YN | RESISTOR | 820Ω, 1/10W            |  | R157 | QSA08J-332YN | RESISTOR                    | 3.3KΩ, 1/10W           |  |
| R93  | QSA08J-821YN | RESISTOR | 820Ω, 1/10W            |  | R158 | QSA08J-103YN | RESISTOR                    | 10KΩ, 1/10W            |  |
| R94  | QSA08J-821YN | RESISTOR | 820Ω, 1/10W            |  | R159 | QSA08J-151YN | RESISTOR                    | 150Ω, 1/10W            |  |
| R95  | QSA08J-821YN | RESISTOR | 820Ω, 1/10W            |  | R160 | QSA08J-222YN | RESISTOR                    | 2.2KΩ, 1/10W           |  |
| R96  | QSA08J-821YN | RESISTOR | 820Ω, 1/10W            |  | R161 | QSA08J-561YN | RESISTOR                    | 560Ω, 1/10W            |  |
| R97  | QSA08J-821YN | RESISTOR | 820Ω, 1/10W            |  | R162 | QSA08J-561YN | RESISTOR                    | 560Ω, 1/10W            |  |
| R98  | QSA08J-821YN | RESISTOR | 820Ω, 1/10W            |  | R163 | QSA08J-183YN | RESISTOR                    | 18KΩ, 1/10W            |  |
| R99  | QSA08J-821YN | RESISTOR | 820Ω, 1/10W            |  | R164 | NVP1304-153N | V RESISTOR, BURST LEVEL (1) | 15KΩ                   |  |
| R100 | QSA08J-821YN | RESISTOR | 820Ω, 1/10W            |  | R165 | QSA08J-103YN | RESISTOR                    | 10KΩ, 1/10W            |  |
| R101 | QSA08J-102YN | RESISTOR | 1KΩ, 1/10W             |  | R166 | NVP1304-153N | V RESISTOR, BURST LEVEL (2) | 15KΩ                   |  |
| R102 | QSA08J-102YN | RESISTOR | 1KΩ, 1/10W             |  | R167 | QSA08J-122YN | RESISTOR                    | 1.2KΩ, 1/10W           |  |
| R103 | QSA08J-102YN | RESISTOR | 1KΩ, 1/10W             |  | R168 | QSA08J-102YN | RESISTOR                    | 1KΩ, 1/10W             |  |
| R105 | QSA08J-821YN | RESISTOR | 820Ω, 1/10W            |  | R170 | QSA08J-152YN | RESISTOR                    | 1.5KΩ, 1/10W           |  |
| R111 | QSA08J-471YN | RESISTOR | 470Ω, 1/10W            |  | R171 | QSA08J-103YN | RESISTOR                    | 10KΩ, 1/10W            |  |
| R112 | QSA08J-821YN | RESISTOR | 820Ω, 1/10W            |  | R172 | QSA08J-151YN | RESISTOR                    | 150Ω, 1/10W            |  |
| R114 | QSA08J-821YN | RESISTOR | 820Ω, 1/10W            |  | R173 | QSA08J-271YN | RESISTOR                    | 270Ω, 1/10W            |  |
| R115 | QSA08J-182YN | RESISTOR | 1.8KΩ, 1/10W           |  | R174 | QSA08J-103YN | RESISTOR                    | 10KΩ, 1/10W            |  |
| R116 | QSA08J-153YN | RESISTOR | 15KΩ, 1/10W            |  | R175 | QSA08J-103YN | RESISTOR                    | 10KΩ, 1/10W            |  |
| R117 | QSA08J-102YN | RESISTOR | 1KΩ, 1/10W             |  | R176 | QSA08J-821YN | RESISTOR                    | 820Ω, 1/10W            |  |
| R119 | QSA08J-821YN | RESISTOR | 820Ω, 1/10W            |  | R177 | QSA08J-750YN | RESISTOR                    | 75Ω, 1/10W             |  |
| R120 | QSA08J-821YN | RESISTOR | 820Ω, 1/10W            |  | R178 | QSA08J-750YN | RESISTOR                    | 75Ω, 1/10W             |  |
| R121 | QSA08J-821YN | RESISTOR | 820Ω, 1/10W            |  | R179 | QSA08J-222YN | RESISTOR                    | 2.2KΩ, 1/10W           |  |
| R122 | QSA08J-152YN | RESISTOR | 1.5KΩ, 1/10W           |  | R180 | QSA08J-562YN | RESISTOR                    | 5.6KΩ, 1/10W           |  |
| R123 | QSA08J-471YN | RESISTOR | 470Ω, 1/10W            |  | R181 | QSA08J-152YN | RESISTOR                    | 1.5KΩ, 1/10W           |  |
| R124 | QSA08J-102YN | RESISTOR | 1KΩ, 1/10W             |  | R182 | QSA08J-100YN | RESISTOR                    | 10Ω, 1/10W             |  |
| R125 | QSA08J-471YN | RESISTOR | 470Ω, 1/10W            |  | R183 | QSA08J-122YN | RESISTOR                    | 1.2KΩ, 1/10W           |  |
| R126 | QSA08J-152YN | RESISTOR | 1.5KΩ, 1/10W           |  | R184 | QSA08J-222YN | RESISTOR                    | 2.2KΩ, 1/10W           |  |
| R128 | QSA08J-182YN | RESISTOR | 1.8KΩ, 1/10W           |  | R185 | QSA08J-333YN | RESISTOR                    | 33KΩ, 1/10W            |  |
| R129 | QSA08J-153YN | RESISTOR | 15KΩ, 1/10W            |  | R186 | QSA08J-821YN | RESISTOR                    | 820Ω, 1/10W            |  |
| R130 | QSA08J-822YN | RESISTOR | 8.2KΩ, 1/10W           |  | R187 | QSA08J-821YN | RESISTOR                    | 820Ω, 1/10W            |  |
| R131 | QSA08J-152YN | RESISTOR | 1.5KΩ, 1/10W           |  | R188 | QSA08J-821YN | RESISTOR                    | 820Ω, 1/10W            |  |
| R132 | QSA08J-222YN | RESISTOR | 2.2KΩ, 1/10W           |  | R189 | QSA08J-102YN | RESISTOR                    | 1KΩ, 1/10W             |  |
| R133 | QSA08J-682   | RESISTOR | 6.8KΩ, 1/10W           |  | R190 | QSA08J-102YN | RESISTOR                    | 1KΩ, 1/10W             |  |
| R134 | QSA08J-823YN | RESISTOR | 82KΩ, 1/10W            |  | R191 | QSA08J-821YN | RESISTOR                    | 820Ω, 1/8W             |  |
| R135 | QSA08J-103YN | RESISTOR | 10KΩ, 1/10W            |  | R192 | QSA08J-470YN | RESISTOR                    | 47Ω, 1/10W             |  |
| R136 | QSA08J-122YN | RESISTOR | 1.2KΩ, 1/10W           |  | R193 | QSA08J-470YN | RESISTOR                    | 47Ω, 1/10W             |  |
| R137 | QSA08J-821YN | RESISTOR | 820Ω, 1/10W            |  | R196 | QSA08J-103YN | RESISTOR                    | 10KΩ, 1/10W            |  |
| R138 | QSA08J-222YN | RESISTOR | 2.2KΩ, 1/10W           |  | R198 | QSA08J-333YN | RESISTOR                    | 33KΩ, 1/10W            |  |
| R139 | QSA08J-272YN | RESISTOR | 2.7KΩ, 1/10W           |  | R199 | QSA08J-102YN | RESISTOR                    | 1KΩ, 1/10W             |  |
| R140 | QSA08J-103YN | RESISTOR | 10KΩ, 1/10W            |  | R200 | QSA08J-105YN | RESISTOR                    | 1MΩ, 1/10W             |  |
| R141 | QSA08J-151YN | RESISTOR | 150Ω, 1/10W            |  | R201 | QSA08J-821YN | RESISTOR                    | 820Ω, 1/10W            |  |
| R142 | QSA08J-222YN | RESISTOR | 2.2KΩ, 1/10W           |  | R202 | QSA08J-105YN | RESISTOR                    | 1MΩ, 1/10W             |  |
| R143 | QSA08J-823YN | RESISTOR | 82KΩ, 1/10W            |  | R203 | QSA08J-100YN | RESISTOR                    | 10Ω, 1/10W             |  |
| R144 | QSA08J-103YN | RESISTOR | 10KΩ, 1/10W            |  | R204 | QSA08J-223YN | RESISTOR                    | 22KΩ, 1/10W            |  |
| R145 | QSA08J-122YN | RESISTOR | 1.2KΩ, 1/10W           |  | R205 | QSA08J-331YN | RESISTOR                    | 330Ω, 1/10W            |  |
| R146 | QSA08J-561YN | RESISTOR | 560Ω, 1/10W            |  | R206 | QSA08J-332YN | RESISTOR                    | 3.3KΩ, 1/10W           |  |
| R148 | QSA08J-222YN | RESISTOR | 2.2KΩ, 1/10W           |  | R207 | QSA08J-223YN | RESISTOR                    | 22KΩ, 1/10W            |  |
| R149 | QSA08J-103YN | RESISTOR | 10KΩ, 1/10W            |  | R208 | QSA08J-273YN | RESISTOR                    | 27KΩ, 1/10W            |  |
| R150 | QSA08J-151YN | RESISTOR | 150Ω, 1/10W            |  | R209 | QSA08J-472YN | RESISTOR                    | 4.7KΩ, 1/10W           |  |
| R151 | QSA08J-222YN | RESISTOR | 2.2KΩ, 1/10W           |  | R210 | QSA08J-272YN | RESISTOR                    | 2.7KΩ, 1/10W           |  |
| R152 | QSA08J-823YN | RESISTOR | 82KΩ, 1/10W            |  | R211 | QSA08J-103YN | RESISTOR                    | 10KΩ, 1/10W            |  |
|      |              |          |                        |  | R212 | QSA08J-473YN | RESISTOR                    | 47KΩ, 1/10W            |  |

| #A   | REF No. | PART No.      | PART NAME, DESCRIPTION       |
|------|---------|---------------|------------------------------|
| R213 |         | QRSA08J-473YN | RESISTOR 47KQ, 1/10W         |
| R214 |         | QRSA08J-472YN | RESISTOR 4.7KQ, 1/10W        |
| R215 |         | QRSA08J-472YN | RESISTOR 4.7KQ, 1/10W        |
| R216 |         | QRSA08J-472YN | RESISTOR 4.7KQ, 1/10W        |
| R223 |         | QRSA08J-752YN | RESISTOR 7.5KQ, 1/10W        |
| R224 |         | QRSA08J-122YN | RESISTOR 1.2KQ, 1/10W        |
| R225 |         | QRSA08J-102YN | RESISTOR 1KQ, 1/10W          |
| R226 |         | QRSA08J-102YN | RESISTOR 1KQ, 1/10W          |
| R227 |         | QRSA08J-273YN | RESISTOR 27KQ, 1/10W         |
| R228 |         | QRSA08J-392YN | RESISTOR 3.9KQ, 1/10W        |
| R229 |         | QRSA08J-102YN | RESISTOR 1KQ, 1/10W          |
| R230 |         | QRSA08J-105YN | RESISTOR 1MΩ, 1/10W          |
| R231 |         | NVP1304-333N  | V RESISTOR, COLOR LEVEL33KQ  |
| R232 |         | QRSA08J-472YN | RESISTOR 4.7KQ, 1/10W        |
| R233 |         | QRSA08J-332YN | RESISTOR 3.3KQ, 1/10W        |
| R234 |         | QRSA08J-332YN | RESISTOR 3.3KQ, 1/10W        |
| R235 |         | QRSA08J-152YN | RESISTOR 1.5KQ, 1/10W        |
| R236 |         | QRSA08J-473YN | RESISTOR 47KQ, 1/10W         |
| R237 |         | QRSA08J-681YN | RESISTOR 680Ω, 1/10W         |
| R238 |         | NVP1304-102N  | V RESISTOR, SUB CARR ADJ 1KQ |
| R239 |         | QRSA08J-473YN | RESISTOR 47KQ, 1/10W         |
| R240 |         | QRSA08J-182YN | RESISTOR 1.8KQ, 1/10W        |
| R241 |         | QRSA08J-331YN | RESISTOR 330Ω, 1/10W         |
| R242 |         | QRSA08J-821YN | RESISTOR 820Ω, 1/10W         |
| R243 |         | QRSA08J-683YN | RESISTOR 68KQ, 1/10W         |
| R244 |         | QRSA08J-683YN | RESISTOR 68KQ, 1/10W         |
| R245 |         | QRSA08J-101YN | RESISTOR 100Ω, 1/10W         |
| R246 |         | QRSA08J-101YN | RESISTOR 100Ω, 1/10W         |
| R247 |         | QRSA08J-562YN | RESISTOR 5.6KQ, 1/10W        |
| R248 |         | QRSA08J-562YN | RESISTOR 5.6KQ, 1/10W        |
| R249 |         | QRSA08J-472YN | RESISTOR 4.7KQ, 1/10W        |
| R250 |         | QRSA08J-472YN | RESISTOR 4.7KQ, 1/10W        |
| R251 |         | QRSA08J-223YN | RESISTOR 22KQ, 1/10W         |
| R252 |         | QRSA08J-223YN | RESISTOR 22KQ, 1/10W         |
| R253 |         | QRSA08J-102YN | RESISTOR 1KQ, 1/10W          |
| R254 |         | QRSA08J-102YN | RESISTOR 1KQ, 1/10W          |
| R255 |         | QRSA08J-104YN | RESISTOR 100KQ, 1/10W        |
| R256 |         | QRSA08J-104YN | RESISTOR 100KQ, 1/10W        |
| R257 |         | QRSA08J-222YN | RESISTOR 2.2KQ, 1/10W        |
| R258 |         | QRSA08J-222YN | RESISTOR 2.2KQ, 1/10W        |
| R259 |         | QRSA08J-562YN | RESISTOR 5.6KQ, 1/10W        |
| R260 |         | QRSA08J-562YN | RESISTOR 5.6KQ, 1/10W        |
| R261 |         | QRSA08J-222YN | RESISTOR 2.2KQ, 1/10W        |
| R262 |         | QRSA08J-101YN | RESISTOR 100Ω, 1/10W         |
| R263 |         | QRSA08J-562YN | RESISTOR 5.6KQ, 1/10W        |
| R264 |         | QRSA08J-472YN | RESISTOR 4.7KQ, 1/10W        |
| R265 |         | QRSA08J-223YN | RESISTOR 22KQ, 1/10W         |
| R266 |         | QRSA08J-102YN | RESISTOR 1KQ, 1/10W          |
| R267 |         | QRSA08J-104YN | RESISTOR 100KQ, 1/10W        |
| R268 |         | QRSA08J-222YN | RESISTOR 2.2KQ, 1/10W        |
| R269 |         | QRSA08J-222YN | RESISTOR 2.2KQ, 1/10W        |
| R270 |         | QRSA08J-333YN | RESISTOR 33KQ, 1/10W         |
| R271 |         | QRSA08J-333YN | RESISTOR 33KQ, 1/10W         |
| R275 |         | QRSA08J-101YN | RESISTOR 100Ω, 1/10W         |
| R276 |         | QRSA08J-271YN | RESISTOR 270Ω, 1/10W         |
| R277 |         | QRSA08J-222YN | RESISTOR 2.2KQ, 1/10W        |

| #A   | REF No. | PART No.      | PART NAME, DESCRIPTION |
|------|---------|---------------|------------------------|
| R278 |         | NRS125J-151NZ | RESISTOR 150Ω, 1/2W    |
| R280 |         | QRSA08J-222YN | RESISTOR 2.2KQ, 1/10W  |
| R281 |         | QRSA08J-333YN | RESISTOR 33KQ, 1/10W   |
| R283 |         | QRSA08J-333YN | RESISTOR 33KQ, 1/10W   |
| R284 |         | QRSA08J-392YN | RESISTOR 3.9KQ, 1/10W  |
| R285 |         | QRSA08J-472YN | RESISTOR 4.7KQ, 1/10W  |
| R286 |         | QRSA08J-391YN | RESISTOR 390Ω, 1/10W   |
| R287 |         | QRSA08J-472YN | RESISTOR 4.7KQ, 1/10W  |
| R288 |         | QRSA08J-750YN | RESISTOR 75Ω, 1/10W    |
| R289 |         | QRSA08J-473YN | RESISTOR 47KQ, 1/10W   |
| R290 |         | QRSA08J-105YN | RESISTOR 1MΩ, 1/10W    |
| R291 |         | QRSA08J-750YN | RESISTOR 75Ω, 1/10W    |
| R292 |         | QRSA08J-391YN | RESISTOR 390Ω, 1/10W   |
| R293 |         | QRSA08J-102YN | RESISTOR 1KQ, 1/10W    |
| R294 |         | QRSA08J-391YN | RESISTOR 390Ω, 1/10W   |
| R295 |         | QRSA08J-223YN | RESISTOR 22KQ, 1/10W   |
| R296 |         | QRSA08J-223YN | RESISTOR 22KQ, 1/10W   |
| R297 |         | QRSA08J-472YN | RESISTOR 4.7KQ, 1/10W  |
| R300 |         | QRSA08J-102YN | RESISTOR 1KQ, 1/10W    |
| R301 |         | QRSA08J-822YN | RESISTOR 8.2KQ, 1/10W  |
| R302 |         | QRSA08J-472YN | RESISTOR 4.7KQ, 1/10W  |
| R303 |         | QRSA08J-162YN | RESISTOR 1.6KQ, 1/10W  |
| R305 |         | QRSA08J-272YN | RESISTOR 2.7KQ, 1/10W  |
| R307 |         | QRSA08J-392YN | RESISTOR 3.9KQ, 1/10W  |
| R308 |         | QRSA08J-272YN | RESISTOR 2.7KQ, 1/10W  |
| R309 |         | QRSA08J-272YN | RESISTOR 2.7KQ, 1/10W  |
| R311 |         | QRSA08J-392YN | RESISTOR 3.9KQ, 1/10W  |
| R312 |         | QRSA08J-272YN | RESISTOR 2.7KQ, 1/10W  |
| R313 |         | QRSA08J-751YN | RESISTOR 750Ω, 1/10W   |
| R314 |         | QRSA08J-100YN | RESISTOR 10Ω, 1/10W    |
| R315 |         | QRSA08J-102YN | RESISTOR 1KQ, 1/10W    |
| R316 |         | QRSA08J-222YN | RESISTOR 2.2KQ, 1/10W  |
| R318 |         | QRSA08J-222YN | RESISTOR 2.2KQ, 1/10W  |
| R319 |         | QRSA08J-103YN | RESISTOR 10KQ, 1/10W   |
| R320 |         | QRSA08J-182YN | RESISTOR 1.8KQ, 1/10W  |
| R321 |         | QRSA08J-391YN | RESISTOR 390Ω, 1/10W   |
| R322 |         | QRSA08J-182YN | RESISTOR 1.8KQ, 1/10W  |
| R323 |         | QRSA08J-391YN | RESISTOR 390Ω, 1/10W   |
| R324 |         | QRSA08J-182YN | RESISTOR 1.8KQ, 1/10W  |
| R325 |         | QRSA08J-391YN | RESISTOR 390Ω, 1/10W   |
| R326 |         | QRSA08J-472YN | RESISTOR 4.7KQ, 1/10W  |
| R327 |         | QRSA08J-682YN | RESISTOR 6.8KQ, 1/10W  |
| R328 |         | QRSA08J-0R0YN | RESISTOR 0Ω, 1/10W     |
| R329 |         | QRSA08J-104YN | RESISTOR 100KQ, 1/10W  |
| R330 |         | QRSA08J-224YN | RESISTOR 220KQ, 1/10W  |
| R331 |         | QRSA08J-333YN | RESISTOR 33KQ, 1/10W   |
| R332 |         | QRSA08J-102YN | RESISTOR 1KQ, 1/10W    |
| R333 |         | QRSA08J-333YN | RESISTOR 33KQ, 1/10W   |
| R334 |         | QRSA08J-333YN | RESISTOR 33KQ, 1/10W   |
| R335 |         | QRSA08J-102YN | RESISTOR 1KQ, 1/10W    |
| R336 |         | QRSA08J-225YN | RESISTOR 2.2MΩ, 1/10W  |
| R337 |         | QRSA08J-225YN | RESISTOR 2.2MΩ, 1/10W  |
| R339 |         | QRSA08J-104YN | RESISTOR 100KQ, 1/10W  |
| R340 |         | QRSA08J-103YN | RESISTOR 10KQ, 1/10W   |
| R341 |         | QRSA08J-102YN | RESISTOR 1KQ, 1/10W    |

| #△   | REF No.       | PART No. | PART NAME, DESCRIPTION |
|------|---------------|----------|------------------------|
| R342 | QRSA08J-102YN | RESISTOR | 1KΩ, 1/10W             |
| R343 | QRSA08J-333YN | RESISTOR | 33KΩ, 1/10W            |
| R344 | QRSA08J-333YN | RESISTOR | 33KΩ, 1/10W            |
| R345 | QRSA08J-104YN | RESISTOR | 100KΩ, 1/10W           |
| R346 | QRSA08J-822YN | RESISTOR | 8.2KΩ, 1/10W           |
| R348 | QRSA08J-473YN | RESISTOR | 47KΩ, 1/10W            |
| R351 | QRSA08J-183YN | RESISTOR | 18KΩ, 1/10W            |
| R352 | QRSA08J-333YN | RESISTOR | 33KΩ, 1/10W            |
| R353 | QRSA08J-563YN | RESISTOR | 56KΩ, 1/10W            |
| R354 | QRSA08J-273YN | RESISTOR | 27KΩ, 1/10W            |
| R355 | QRSA08J-153YN | RESISTOR | 15KΩ, 1/10W            |
| R356 | QRSA08J-303YN | RESISTOR | 30KΩ, 1/10W            |
| R357 | QRSA08J-472YN | RESISTOR | 4.7KΩ, 1/10W           |
| R358 | QRSA08J-333YN | RESISTOR | 33KΩ, 1/10W            |
| R359 | QRSA08J-103YN | RESISTOR | 10KΩ, 1/10W            |
| R360 | QRSA08J-472YN | RESISTOR | 4.7KΩ, 1/10W           |
| R361 | QRSA08J-103YN | RESISTOR | 10KΩ, 1/10W            |
| R362 | QRSA08J-272YN | RESISTOR | 2.7KΩ, 1/10W           |
| R363 | QRSA08J-122YN | RESISTOR | 1.2KΩ, 1/10W           |
| R364 | QRSA08J-102YN | RESISTOR | 1KΩ, 1/10W             |
| R365 | QRSA08J-102YN | RESISTOR | 1KΩ, 1/10W             |
| R366 | QRSA08J-0R0YN | RESISTOR | 0Ω, 1/10W              |
| R367 | QRSA08J-102YN | RESISTOR | 1KΩ, 1/10W             |
| R370 | QRSA08J-392YN | RESISTOR | 3.9KΩ, 1/10W           |
| R371 | QRSA08J-223YN | RESISTOR | 22KΩ, 1/10W            |
| R372 | QRSA08J-222YN | RESISTOR | 2.2KΩ, 1/10W           |
| R373 | QRSA08J-222YN | RESISTOR | 2.2KΩ, 1/10W           |
| R374 | QRSA08J-222YN | RESISTOR | 2.2KΩ, 1/10W           |
| R375 | QRSA08J-222YN | RESISTOR | 2.2KΩ, 1/10W           |
| R376 | QRSA08J-222YN | RESISTOR | 2.2KΩ, 1/10W           |
| R382 | QRSA08J-222YN | RESISTOR | 2.2KΩ, 1/10W           |
| R383 | QRSA08J-103YN | RESISTOR | 10KΩ, 1/10W            |
| R384 | QRSA08J-474YN | RESISTOR | 470KΩ, 1/10W           |
| R385 | QRD162J-474   | RESISTOR | 470KΩ, 1/6W            |
| R501 | QRSA08J-104YN | RESISTOR | 100KΩ, 1/10W           |
| R502 | QRSA08J-104YN | RESISTOR | 100KΩ, 1/10W           |
| R503 | QRSA08J-104YN | RESISTOR | 100KΩ, 1/10W           |
| R504 | QRSA08J-104YN | RESISTOR | 100KΩ, 1/10W           |
| R505 | QRSA08J-104YN | RESISTOR | 100KΩ, 1/10W           |
| R506 | QRSA08J-104YN | RESISTOR | 100KΩ, 1/10W           |
| R507 | QRSA08J-104YN | RESISTOR | 100KΩ, 1/10W           |
| R508 | QRSA08J-104YN | RESISTOR | 100KΩ, 1/10W           |
| R509 | QRSA08J-104YN | RESISTOR | 100KΩ, 1/10W           |
| R510 | QRSA08J-104YN | RESISTOR | 100KΩ, 1/10W           |
| R511 | QRSA08J-104YN | RESISTOR | 100KΩ, 1/10W           |
| R512 | QRSA08J-104YN | RESISTOR | 100KΩ, 1/10W           |
| R513 | QRSA08J-104YN | RESISTOR | 100KΩ, 1/10W           |
| R514 | QRSA08J-104YN | RESISTOR | 100KΩ, 1/10W           |
| R515 | QRSA08J-104YN | RESISTOR | 100KΩ, 1/10W           |
| R516 | QRSA08J-104YN | RESISTOR | 100KΩ, 1/10W           |
| R517 | QRSA08J-104YN | RESISTOR | 100KΩ, 1/10W           |
| R518 | QRSA08J-104YN | RESISTOR | 100KΩ, 1/10W           |
| R519 | QRSA08J-104YN | RESISTOR | 100KΩ, 1/10W           |
| R520 | QRSA08J-104YN | RESISTOR | 100KΩ, 1/10W           |
| R521 | QRSA08J-472YN | RESISTOR | 4.7KΩ, 1/10W           |

| #△   | REF No.       | PART No.     | PART NAME, DESCRIPTION |
|------|---------------|--------------|------------------------|
| R522 | QRSA08J-104YN | RESISTOR     | 100KΩ, 1/10W           |
| R523 | QRSA08J-104YN | RESISTOR     | 100KΩ, 1/10W           |
| R524 | QRSA08J-104YN | RESISTOR     | 100KΩ, 1/10W           |
| R525 | QRSA08J-271YN | RESISTOR     | 270Ω, 1/10W            |
| R526 | QRSA08J-271YN | RESISTOR     | 270Ω, 1/10W            |
| R527 | QRSA08J-271YN | RESISTOR     | 270Ω, 1/10W            |
| R528 | QRSA08J-104YN | RESISTOR     | 100KΩ, 1/10W           |
| R529 | QRSA08J-151YN | RESISTOR     | 150Ω, 1/10W            |
| R530 | QRSA08J-472YN | RESISTOR     | 4.7KΩ, 1/10W           |
| R531 | QRSA08J-271YN | RESISTOR     | 270Ω, 1/10W            |
| R532 | QRSA08J-271YN | RESISTOR     | 270Ω, 1/10W            |
| R533 | QRSA08J-472YN | RESISTOR     | 4.7KΩ, 1/10W           |
| R534 | QRSA08J-472YN | RESISTOR     | 4.7KΩ, 1/10W           |
| R535 | QRSA08J-122YN | RESISTOR     | 1.2KΩ, 1/10W           |
| R536 | QRSA08J-122YN | RESISTOR     | 1.2KΩ, 1/10W           |
| R537 | QRSA08J-122YN | RESISTOR     | 1.2KΩ, 1/10W           |
| R538 | QRSA08J-122YN | RESISTOR     | 1.2KΩ, 1/10W           |
| R539 | QRSA08J-122YN | RESISTOR     | 1.2KΩ, 1/10W           |
| R540 | QRSA08J-104YN | RESISTOR     | 100KΩ, 1/10W           |
| R541 | QRSA08J-104YN | RESISTOR     | 100KΩ, 1/10W           |
| R546 | QRSA08J-103YN | RESISTOR     | 10KΩ, 1/10W            |
| R547 | QRSA08J-102YN | RESISTOR     | 1KΩ, 1/10W             |
| R549 | QRSA08J-331YN | RESISTOR     | 330Ω, 1/10W            |
| R550 | QRSA08J-683YN | RESISTOR     | 68KΩ, 1/10W            |
| R552 | QRSA08J-472YN | RESISTOR     | 4.7KΩ, 1/10W           |
| R554 | QRSA08J-122YN | RESISTOR     | 1.2KΩ, 1/10W           |
| R567 | QRSA08J-821YN | RESISTOR     | 820Ω, 1/10W            |
| R568 | QRSA08J-472YN | RESISTOR     | 4.7KΩ, 1/10W           |
| R569 | QRSA08J-681YN | RESISTOR     | 680Ω, 1/10W            |
| R570 | QRSA08J-472YN | RESISTOR     | 4.7KΩ, 1/10W           |
| R574 | QRSA08J-271YN | RESISTOR     | 270Ω, 1/10W            |
| R577 | QRSA08J-104YN | RESISTOR     | 100KΩ, 1/10W           |
| R578 | QRSA08J-104YN | RESISTOR     | 100KΩ, 1/10W           |
| R579 | QRSA08J-104YN | RESISTOR     | 100KΩ, 1/10W           |
| R580 | QRSA08J-103YN | RESISTOR     | 10KΩ, 1/10W            |
| R581 | QRSA08J-102YN | RESISTOR     | 1KΩ, 1/10W             |
| R582 | QRSA08J-882YN | RESISTOR     | 6.8KΩ, 1/10W           |
| R583 | QRSA08J-562YN | RESISTOR     | 5.6KΩ, 1/10W           |
| R584 | QRSA08J-332YN | RESISTOR     | 3.3KΩ, 1/10W           |
| R585 | QRSA08J-102YN | RESISTOR     | 1KΩ, 1/10W             |
| R586 | QRSA08J-102YN | RESISTOR     | 1KΩ, 1/10W             |
| R587 | QRSA08J-102YN | RESISTOR     | 1KΩ, 1/10W             |
| R588 | QRSA08J-102YN | RESISTOR     | 1KΩ, 1/10W             |
| R589 | QRSA08J-102YN | RESISTOR     | 1KΩ, 1/10W             |
| R590 | QRSA08J-102YN | RESISTOR     | 1KΩ, 1/10W             |
| C1   | QCTA1CH-3R0   | FC CAPACITOR | 3PF, 16V               |
| C2   | QCTA1CH-3R0   | FC CAPACITOR | 3PF, 16V               |
| C3   | QCYA1HK-102   | CAPACITOR    | 0.001μF, 50V           |
| C4   | QETC1CM-336   | E CAPACITOR  | 33μF, 16V              |
| C5   | QCFAIHZ-103   | CAPACITOR    | 0.01μF, 50V            |
| C6   | QCTA1CH-3R0   | FC CAPACITOR | 3PF, 16V               |
| C7   | QCTA1CH-3R0   | FC CAPACITOR | 3PF, 16V               |
| C8   | QCYA1HK-102   | CAPACITOR    | 0.001μF, 50V           |
| C9   | QCFAIHZ-103   | CAPACITOR    | 0.01μF, 50V            |

| #Δ | REF No. | PART No.      | PART NAME, DESCRIPTION   |
|----|---------|---------------|--------------------------|
|    | C10     | QCYA1HK-102   | CAPACITOR 0.001μF, 50V   |
|    | C11     | QCFA1HZ-103   | CAPACITOR 0.01μF, 50V    |
|    | C12     | QCYA1HK-102   | CAPACITOR 0.001μF, 50V   |
|    | C13     | QCYA1HK-102   | CAPACITOR 0.001μF, 50V   |
|    | C14     | QETC1CM-336   | E CAPACITOR 33μF, 16V    |
|    | C15     | QCFA1HZ-103   | CAPACITOR 0.01μF, 50V    |
|    | C16     | PU57601-225MC | E CAPACITOR 2.2μF        |
|    | C18     | QETC1CM-105   | E CAPACITOR 1μF, 50V     |
|    | C19     | QCFA1HZ-103   | CAPACITOR 0.01μF, 50V    |
|    | C20     | QCFA1HZ-103   | CAPACITOR 0.01μF, 50V    |
|    | C21     | QCFA1HZ-103   | CAPACITOR 0.01μF, 50V    |
|    | C22     | QCYA1HK-102   | CAPACITOR 0.001μF, 50V   |
|    | C23     | QETC1CM-336   | E CAPACITOR 33μF, 16V    |
|    | C25     | QETC1HM-474   | E CAPACITOR 0.47μF, 50V  |
|    | C26     | QCYA1HK-102   | CAPACITOR 0.001μF, 50V   |
|    | C28     | QCTA1CH-220   | CAPACITOR 22PF, 16V      |
|    | C29     | QETC1CM-106   | NP E CAPACITOR 10μF, 16V |
|    | C30     | QCFA1HZ-103   | CAPACITOR 0.01μF, 50V    |
|    | C31     | QETC1HM-225   | E CAPACITOR 2.2μF, 50V   |
|    | C32     | QETC1CM-336   | E CAPACITOR 33μF, 16V    |
|    | C33     | QETC1HM-105   | E CAPACITOR 1μF, 50V     |
|    | C34     | QETC1CM-336   | E CAPACITOR 33μF, 16V    |
|    | C35     | QCFA1HZ-103   | CAPACITOR 0.01μF, 50V    |
|    | C36     | QCTA1CH-150   | CAPACITOR 15PF, 16V      |
|    | C37     | QCTA1CH-181   | CAPACITOR 180PF, 16V     |
|    | C38     | QCFA1HZ-103   | CAPACITOR 0.01μF, 50V    |
|    | C39     | QETC1CM-106   | E CAPACITOR 10μF, 16V    |
|    | C40     | QETC1CM-106   | E CAPACITOR 10μF, 16V    |
|    | C41     | QETC1CM-106   | E CAPACITOR 10μF, 16V    |
|    | C42     | QETC1CM-336   | E CAPACITOR 33μF, 16V    |
|    | C43     | QCFA1HZ-103   | CAPACITOR 0.01μF, 50V    |
|    | C44     | QETC1CM-106   | E CAPACITOR 10μF, 16V    |
|    | C45     | QCTA1CH-120   | CAPACITOR 12PF, 16V      |
|    | C46     | QETC0JM-476   | E CAPACITOR 47μF, 6.3V   |
|    | C47     | QCFA1HZ-103   | CAPACITOR 0.01μF, 50V    |
|    | C48     | QETC1CM-107   | E CAPACITOR 100μF, 16V   |
|    | C49     | QCFA1HZ-103   | CAPACITOR 0.01μF, 50V    |
|    | C50     | QCFA1HZ-103   | CAPACITOR 0.01μF, 50V    |
|    | C51     | QFN31HU-104   | M CAPACITOR 0.1μF, 50V   |
|    | C52     | QETC1CM-226   | E CAPACITOR 22μF, 16V    |
|    | C53     | QETC0JM-107   | E CAPACITOR 100μF, 6.3V  |
|    | C54     | QETC1CM-106   | E CAPACITOR 10μF, 16V    |
|    | C55     | QETC1CM-106   | E CAPACITOR 10μF, 16V    |
|    | C57     | QCFA1HZ-103   | CAPACITOR 0.01μF, 50V    |
|    | C59     | QETC0JM-476   | E CAPACITOR 47μF, 6.3V   |
|    | C60     | QETC0JM-476   | E CAPACITOR 47μF, 6.3V   |
|    | C61     | QETC0JM-476   | E CAPACITOR 47μF, 6.3V   |
|    | C62     | QCFA1HZ-103   | CAPACITOR 0.01μF, 50V    |
|    | C63     | QCYA1HK-222   | CAPACITOR 0.0022μF, 50V  |
|    | C64     | QETC0JM-476   | E CAPACITOR 47μF, 6.3V   |
|    | C65     | QCYA1HK-102   | CAPACITOR 0.001μF, 50V   |
|    | C66     | QCFA1HZ-103   | CAPACITOR 0.01μF, 50V    |
|    | C67     | QCFA1HZ-103   | CAPACITOR 0.01μF, 50V    |
|    | C68     | QCFA1HZ-103   | CAPACITOR 0.01μF, 50V    |
|    | C69     | QCFA1HZ-103   | CAPACITOR 0.01μF, 50V    |

| #Δ | REF No. | PART No.    | PART NAME, DESCRIPTION   |
|----|---------|-------------|--------------------------|
|    | C71     | QCFA1HZ-103 | CAPACITOR 0.01μF, 50V    |
|    | C72     | QCFA1HZ-103 | CAPACITOR 0.01μF, 50V    |
|    | C73     | QCFA1HZ-103 | CAPACITOR 0.01μF, 50V    |
|    | C74     | QETC1CM-476 | E CAPACITOR 47μF, 16V    |
|    | C75     | QCFA1HZ-103 | CAPACITOR 0.01μF, 50V    |
|    | C76     | QETC1CM-106 | E CAPACITOR 10μF, 16V    |
|    | C78     | QETC0JM-107 | E CAPACITOR 100μF, 6.3V  |
|    | C81     | QETC1CM-336 | E CAPACITOR 33μF, 16V    |
|    | C82     | QETC1CM-336 | E CAPACITOR 33μF, 16V    |
|    | C83     | QETC1CM-336 | E CAPACITOR 33μF, 16V    |
|    | C84     | QCTA1CH-5R0 | CAPACITOR 5PF, 16V       |
|    | C85     | QETC1CM-106 | E CAPACITOR 10μF, 16V    |
|    | C86     | QETC1CM-106 | E CAPACITOR 10μF, 16V    |
|    | C87     | QETC1CM-106 | E CAPACITOR 10μF, 16V    |
|    | C88     | QCFA1EZ-104 | CAPACITOR 0.1μF, 25V     |
|    | C89     | QCFA1EZ-104 | CAPACITOR 0.1μF, 25V     |
|    | C90     | QCFA1EZ-104 | CAPACITOR 0.1μF, 25V     |
|    | C91     | QCFA1EZ-104 | CAPACITOR 0.1μF, 25V     |
|    | C92     | QCFA1EZ-104 | CAPACITOR 0.1μF, 25V     |
|    | C93     | QCFA1EZ-104 | CAPACITOR 0.1μF, 25V     |
|    | C94     | QCFA1EZ-104 | CAPACITOR 0.1μF, 25V     |
|    | C95     | QETC1CM-106 | E CAPACITOR 10μF, 16V    |
|    | C96     | QCFA1HZ-103 | CAPACITOR 0.01μF, 50V    |
|    | C97     | QETC0JM-107 | E CAPACITOR 100μF, 6.3V  |
|    | C98     | QETC0JM-107 | E CAPACITOR 100μF, 6.3V  |
|    | C99     | QETC0JM-108 | E CAPACITOR 1000μF, 6.3V |
|    | C100    | QETC0JM-108 | E CAPACITOR 1000μF, 6.3V |
|    | C101    | QETC1CM-106 | E CAPACITOR 10μF, 16V    |
|    | C102    | QETC1CM-106 | E CAPACITOR 10μF, 16V    |
|    | C103    | QETC1CM-106 | E CAPACITOR 10μF, 16V    |
|    | C104    | QETC1CM-106 | E CAPACITOR 10μF, 16V    |
|    | C105    | QCFA1CZ-474 | CAPACITOR 0.47μF, 16V    |
|    | C106    | QCFA1EZ-104 | CAPACITOR 0.1μF, 25V     |
|    | C107    | QETC1CM-106 | E CAPACITOR 10μF, 16V    |
|    | C108    | QETC1CM-106 | E CAPACITOR 10μF, 16V    |
|    | C109    | QCFA1EZ-104 | CAPACITOR 0.1μF, 25V     |
|    | C110    | QCFA1EZ-104 | CAPACITOR 0.1μF, 25V     |
|    | C112    | QCFA1HZ-103 | CAPACITOR 0.01μF, 50V    |
|    | C113    | QCFA1EZ-104 | CAPACITOR 0.1μF, 25V     |
|    | C114    | QCFA1EZ-104 | CAPACITOR 0.1μF, 25V     |
|    | C117    | QCFA1HZ-103 | CAPACITOR 0.01μF, 50V    |
|    | C118    | QCFA1HZ-103 | CAPACITOR 0.01μF, 50V    |
|    | C119    | QCFA1HZ-103 | CAPACITOR 0.01μF, 50V    |
|    | C120    | QETC1CM-106 | E CAPACITOR 10μF, 16V    |
|    | C121    | QETC1CM-106 | E CAPACITOR 10μF, 16V    |
|    | C122    | QCFA1HZ-103 | CAPACITOR 0.01μF, 50V    |
|    | C123    | QCFA1HZ-103 | CAPACITOR 0.01μF, 50V    |
|    | C126    | QCFA1HZ-103 | CAPACITOR 0.01μF, 50V    |
|    | C127    | QETC1CM-106 | E CAPACITOR 10μF, 16V    |
|    | C128    | QETC1CM-106 | E CAPACITOR 10μF, 16V    |
|    | C129    | QCFA1EZ-104 | CAPACITOR 0.1μF, 25V     |
|    | C130    | QCFA1HZ-103 | CAPACITOR 0.01μF, 50V    |
|    | C131    | QETC1CM-106 | E CAPACITOR 10μF, 16V    |
|    | C132    | QCFA1EZ-104 | CAPACITOR 0.1μF, 25V     |
|    | C133    | QETC1CM-106 | E CAPACITOR 10μF, 16V    |
|    | C134    | QCTA1CH-471 | CAPACITOR 470PF, 16V     |

| # | REF No. | PART No.    | PART NAME, DESCRIPTION | # | REF No. | PART No.    | PART NAME, DESCRIPTION |
|---|---------|-------------|------------------------|---|---------|-------------|------------------------|
|   | C135    | QCTA1CH-471 | CAPACITOR              |   | C204    | QCFA1HZ-103 | CAPACITOR              |
|   | C136    | QETC1CM-106 | E CAPACITOR            |   | C205    | QCFA1HZ-103 | CAPACITOR              |
|   | C137    | QETC1CM-106 | E CAPACITOR            |   | C206    | QCFA1HZ-103 | CAPACITOR              |
|   | C138    | QETC1CM-106 | E CAPACITOR            |   | C207    | QCFA1HZ-103 | CAPACITOR              |
|   | C139    | QETC1CM-106 | E CAPACITOR            |   | C208    | QCFA1HZ-103 | CAPACITOR              |
|   | C140    | QETC1CM-106 | E CAPACITOR            |   | C209    | QCFA1HZ-103 | CAPACITOR              |
|   |         |             |                        |   | C210    | QCFA1HZ-103 | CAPACITOR              |
|   | C141    | QETC1CM-476 | E CAPACITOR            |   | C212    | QETC0JM-476 | E CAPACITOR            |
|   | C142    | QETC1CM-106 | E CAPACITOR            |   | C213    | QETC0JM-476 | E CAPACITOR            |
|   | C143    | QETC1CM-476 | E CAPACITOR            |   | C214    | QCFA1HZ-103 | CAPACITOR              |
|   | C144    | QETC1CM-227 | E CAPACITOR            |   | C215    | QCFA1HZ-103 | CAPACITOR              |
|   | C145    | QETC1CM-227 | E CAPACITOR            |   | C216    | QCFA1HZ-103 | CAPACITOR              |
|   | C146    | QCFA1EZ-104 | CAPACITOR              |   | C218    | QCFA1HZ-103 | CAPACITOR              |
|   | C148    | QCTA1CH-471 | CAPACITOR              |   | C219    | QCFA1HZ-103 | CAPACITOR              |
|   | C149    | QETC1CM-106 | E CAPACITOR            |   | C220    | QCFA1HZ-103 | CAPACITOR              |
|   | C150    | QETC1CM-106 | E CAPACITOR            |   |         |             |                        |
|   | C151    | QETC1CM-227 | E CAPACITOR            |   | C221    | QCTA1CH-330 | CAPACITOR              |
|   | C156    | QETC1CM-336 | E CAPACITOR            |   | C222    | QETC0JM-476 | E CAPACITOR            |
|   | C157    | QCFA1HZ-103 | CAPACITOR              |   | C223    | QETC0JM-476 | E CAPACITOR            |
|   | C158    | QCFA1HZ-103 | CAPACITOR              |   | C225    | QCFA1HZ-103 | CAPACITOR              |
|   | C159    | QCFA1HZ-103 | CAPACITOR              |   | C226    | QCTA1CH-470 | CAPACITOR              |
|   | C160    | QCFA1HZ-103 | CAPACITOR              |   | C227    | QCTA1CH-620 | CAPACITOR              |
|   |         |             |                        |   | C228    | QCFA1HZ-103 | CAPACITOR              |
|   | C161    | QETC1HM-104 | E CAPACITOR            |   | C229    | QCFA1HZ-103 | CAPACITOR              |
|   | C162    | QCFA1EZ-104 | CAPACITOR              |   | C230    | QCTA1CH-330 | CAPACITOR              |
|   | C163    | QCTA1CH-220 | CAPACITOR              |   |         |             |                        |
|   | C165    | QCFA1HZ-104 | CAPACITOR              |   | C231    | QETC1CM-107 | E CAPACITOR            |
|   | C166    | QCTA1CH-220 | CAPACITOR              |   | C236    | QCFA1EZ-104 | CAPACITOR              |
|   | C167    | QAT3123-300 | TRIM CAP, FSC ADJ      |   | C236    | QCFA1HZ-103 | CAPACITOR              |
|   | C168    | QCTA1CH-220 | CAPACITOR              |   | C238    | QCFA1HZ-103 | CAPACITOR              |
|   | C169    | QCFA1EZ-104 | CAPACITOR              |   | C240    | QCFA1HZ-103 | CAPACITOR              |
|   | C170    | QCTA1CH-330 | CAPACITOR              |   |         |             |                        |
|   |         |             |                        |   | C241    | QCFA1EZ-104 | CAPACITOR              |
|   | C171    | QCFA1EZ-104 | CAPACITOR              |   | C242    | QCTA1CH-3R0 | CAPACITOR              |
|   | C173    | QCFA1EZ-104 | CAPACITOR              |   | C243    | QCTA1CH-3R0 | CAPACITOR              |
|   | C174    | QCFA1CZ-474 | CAPACITOR              |   | C244    | QCTA1CH-3R0 | CAPACITOR              |
|   | C175    | QCFA1HZ-103 | CAPACITOR              |   | C245    | QCFA1HZ-103 | CAPACITOR              |
|   | C176    | QCFA1HZ-104 | CAPACITOR              |   | C246    | QETC1AM-107 | E CAPACITOR            |
|   | C177    | QETC0JM-107 | E CAPACITOR            |   |         |             |                        |
|   | C178    | QCYA1HK-103 | CAPACITOR              |   | C328    | QETC1CM-106 | E CAPACITOR            |
|   | C179    | QETC0JM-107 | E CAPACITOR            |   | C329    | QCFA1HZ-103 | CAPACITOR              |
|   | C180    | QCFA1CZ-474 | CAPACITOR              |   | C330    | QETC0JM-107 | E CAPACITOR            |
|   |         |             |                        |   |         |             |                        |
|   | C181    | QCFA1HZ-104 | CAPACITOR              |   | C331    | QCFA1HZ-103 | CAPACITOR              |
|   | C182    | QCFA1CZ-474 | CAPACITOR              |   | C332    | QCFA1HZ-103 | CAPACITOR              |
|   | C183    | QCTA1CH-330 | CAPACITOR              |   | C333    | QCFA1HZ-103 | CAPACITOR              |
|   | C184    | QETC1CM-106 | E CAPACITOR            |   | C334    | QCFA1HZ-103 | CAPACITOR              |
|   | C185    | QCFA1EZ-104 | CAPACITOR              |   | C335    | QCFA1HZ-103 | CAPACITOR              |
|   | C186    | QETC1CM-106 | E CAPACITOR            |   | C336    | QCFA1HZ-104 | CAPACITOR              |
|   | C188    | QETC1HM-104 | E CAPACITOR            |   | C337    | QETC1CM-106 | E CAPACITOR            |
|   | C190    | QCFA1HZ-103 | CAPACITOR              |   | C338    | QETC1CM-107 | E CAPACITOR            |
|   |         |             |                        |   | C339    | QETC1CM-106 | E CAPACITOR            |
|   | C193    | QETC1CM-106 | E CAPACITOR            |   | C340    | QETC1CM-106 | E CAPACITOR            |
|   | C194    | QETC1CM-106 | E CAPACITOR            |   |         |             |                        |
|   | C195    | QETC1CM-106 | E CAPACITOR            |   | C343    | QETC1CM-106 | E CAPACITOR            |
|   | C196    | QCFA1HZ-103 | CAPACITOR              |   |         |             |                        |
|   | C197    | QCTA1CH-101 | CAPACITOR              |   |         |             |                        |
|   |         |             |                        |   | C501    | QEA40HZ-104 | E CAPACITOR (DOUBLE)   |
|   | C201    | QCFA1HZ-103 | CAPACITOR              |   | C502    | QETC1CM-106 | E CAPACITOR            |
|   | C202    | QCFA1HZ-103 | CAPACITOR              |   | C503    | QCFA1EZ-104 | CAPACITOR              |
|   | C203    | QCFA1HZ-103 | CAPACITOR              |   | C504    | QCFA1HZ-103 | CAPACITOR              |
|   |         |             |                        |   | C506    | QCFA1HZ-104 | CAPACITOR              |

| #△ | REF No. | PART No.     | PART NAME, DESCRIPTION  |
|----|---------|--------------|-------------------------|
|    | C507    | QCFA1HZ-104  | CAPACITOR 0.1μF, 50V    |
|    | C509    | QETC1CM-106  | E CAPACITOR 10μF, 16V   |
|    | C510    | QCFA1EZ-104  | CAPACITOR 0.1μF, 25V    |
|    | C511    | QCFA1EZ-104  | CAPACITOR 0.1μF, 25V    |
|    | C513    | QCFA1EZ-104  | CAPACITOR 0.1μF, 25V    |
|    | C515    | QETC1HM-225  | E CAPACITOR 2.2μF, 50V  |
|    | C516    | QCFA1EZ-683  | CAPACITOR 0.068μF, 25V  |
|    | C517    | QCSA1HJ-221  | CAPACITOR 220PF, 50V    |
|    | C518    | QCFA1EZ-473  | CAPACITOR 0.047μF, 25V  |
|    | C520    | QCTA1CH-180  | CAPACITOR 18PF, 16V     |
|    | C521    | QCFA1EZ-473  | CAPACITOR 0.047μF, 25V  |
|    | C524    | QAT3120-200  | TRIMMER CAPACITOR, VCO. |
|    | C525    | QCFA1HZ-103  | CAPACITOR 0.01μF, 50V   |
|    | C526    | QCFA1EZ-104  | CAPACITOR 0.1μF, 25V    |
|    | C527    | QCFA1EZ-104  | CAPACITOR 0.1μF, 25V    |
|    | C528    | QETC1CM-335  | E CAPACITOR 33μF, 16V   |
|    | C529    | QCTA1CH-150  | CAPACITOR 15PF, 16V     |
|    | C530    | QCSA1HJ-102  | CAPACITOR 0.001μF, 50V  |
|    | C531    | QCSA1HJ-471  | CAPACITOR 470PF, 50V    |
|    | C532    | QCFA1HZ-223  | CAPACITOR 0.022μF, 50V  |
|    | C533    | QCTA1CH-271  | CAPACITOR 270PF, 16V    |
|    | C534    | QCTA1CH-101  | CAPACITOR 100PF, 16V    |
|    | C535    | QCTA1CH-120  | CAPACITOR 12PF, 16V     |
|    | C536    | QCTA1CH-270  | CAPACITOR 27PF, 16V     |
|    | C546    | QETC1CM-335  | E CAPACITOR 33μF, 16V   |
|    | C547    | QETC1CM-225  | E CAPACITOR 22μF, 16V   |
|    | C548    | QETC1CM-225  | E CAPACITOR 22μF, 16V   |
|    | L1      | PELN0287     | IF TRANSFORMER          |
|    | L2      | PELN0286     | IF TRANSFORMER          |
|    | L3      | PU60025-1R3  | COIL 1.3μH              |
|    | L4      | PU54223-1R0J | COIL 1.0μH              |
|    | L5      | PU54223-1R0J | COIL 1.0μH              |
|    | L7      | PU60497-3    | IF TRANSFORMER          |
|    | L8      | PU54223-1R0J | COIL 1.0μH              |
|    | L9      | PU54223-100J | COIL 10μH               |
|    | L10     | PU54223-100J | COIL 10μH               |
|    | L11     | PU54223-100J | COIL 10μH               |
|    | L12     | PU54223-100J | COIL 10μH               |
|    | L14     | PU54223-100J | COIL 10μH               |
|    | L18     | PU54223-100J | COIL 10μH               |
|    | L19     | PU54223-100J | COIL 10μH               |
|    | L21     | PU54223-100J | COIL 10μH               |
|    | L22     | PU54223-100J | COIL 10μH               |
|    | L23     | PU54223-100J | COIL 10μH               |
|    | L24     | PU60281-2    | FERRITE BEADS           |
|    | L25     | PU54223-100J | COIL 10μH               |
|    | L27     | PU54223-100J | COIL 10μH               |
|    | L30     | PU54223-100J | COIL 10μH               |
|    | L31     | PU54223-100J | COIL 10μH               |
|    | L32     | PU54223-100J | COIL 10μH               |
|    | L33     | PU54223-100J | COIL 10μH               |
|    | L34     | PU54223-100J | COIL 10μH               |
|    | L501    | PU54223-150J | COIL 15μH               |

| #△ | REF No. | PART No.      | PART NAME, DESCRIPTION |
|----|---------|---------------|------------------------|
|    | L502    | PU54223-100J  | COIL 10μH              |
|    | L503    | PU54223-150J  | COIL 15μH              |
|    | EQ1     | PELN0287      | EQUALIZER              |
|    | LPF1    | PELN0282      | LOW PASS FILTER        |
|    | LPF2    | PELN0283      | LOW PASS FILTER        |
|    | LPF3    | PELN0284      | LOW PASS FILTER        |
|    | LPF4    | PELN0284      | LOW PASS FILTER        |
|    | LPF5    | PELN0285      | LOW PASS FILTER        |
|    | BPF1    | PELN0286      | BAND PASS FILTER       |
| △  | CP1     | PU59545       | RESONATOR              |
|    | DL1     | PELN0288      | DELAY LINE             |
|    | DL2     | PU60800       | DELAY LINE             |
|    | LC4     | PU61063-223   | NOISE FILTER           |
|    | LC5     | PU61063-223   | NOISE FILTER           |
|    | LC6     | PU61063-223   | NOISE FILTER           |
|    | LC7     | PU61063-223   | NOISE FILTER           |
|    | LC8     | PU61063-223   | NOISE FILTER           |
|    | SAW1    | PEV30333      | SAW FILTER             |
| △  | CF501   | PU60414       | CERAMIC FILTER         |
| △  | X1      | PEV30331      | CRYSTAL RESONATOR      |
| △  | X2      | PEV30332      | CRYSTAL RESONATOR      |
| △  | X3      | PU31449-4K    | CRYSTAL RESONATOR      |
| △  | X501    | PU60827       | CRYSTAL RESONATOR      |
| △  | X502    | PU60828       | CRYSTAL RESONATOR      |
|    | SW1     | PU59873       | SLIDE SWITCH           |
|    | CL1     | PU59311-4     | WIRE CLAMP             |
|    | JA1     | PQ20949-1-1   | JACK BOARD             |
|    | J2      | QMC0131-002   | PIN JACK               |
|    | SCW1    | SDSF2606Z     | SCREW, X2              |
|    | WR1     | PW30402-AB17M | COAXIAL CABLE          |
|    | CN1     | PU58844-4     | CAP HOUSING            |
|    | CN2     | PU58844-4     | CAP HOUSING            |
|    | CN3     | PU58844-6     | CAP HOUSING            |
|    | CN4     | PU58844-7     | CAP HOUSING            |
|    | CN5     | PU58844-6     | CAP HOUSING            |
|    | CN6     | PU59555-9     | CAP HOUSING            |
|    | CN7     | PU58844-3     | CAP HOUSING            |
|    | CN8     | PU58844-2     | CAP HOUSING            |
|    | CN9     | PU58844-6     | CAP HOUSING            |
|    | CN10    | PU58844-7     | CAP HOUSING            |
|    | CN11    | PU58844-5     | CAP HOUSING            |
|    | CN12    | PU58844-3     | CAP HOUSING            |
| △  | CP501   | ICP-F10       | CIRCUIT PROTECTOR      |

## SECTION 6

### TECHNICAL INFORMATIONS

#### 6.1 MECHANISM CONTROL CPU PIN FUNCTIONS

##### 6.1.1 IC1 pin function

| Pin No. | Symbol | I/O format | Label                                                                                   | IN/OUT | Contents                                                                                                                                                                                            |  |
|---------|--------|------------|-----------------------------------------------------------------------------------------|--------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--|
| 1       | Vcc    | —          | Vcc                                                                                     | IN     | for the System Control                                                                                                                                                                              |  |
| 2       | VREF   | —          | VREF                                                                                    | IN     | for D-A/A-D converter                                                                                                                                                                               |  |
| 3       | DA     | Analog     | DA                                                                                      | OUT    | REEL MOTOR DRIVE                                                                                                                                                                                    |  |
| 4       | PWM    | PWM        | PWM                                                                                     | OUT    | REEL MOTOR DRIVE (SUB)                                                                                                                                                                              |  |
| 5       | Port 6 | 4          | FF                                                                                      | OUT    | NORMAL : (High), REC mode : (Low)<br>POWER ON : (Low), POWER OFF : (High)<br>EE/REC : (Low), PB : (High)<br>SP mode : (Low), LP mode : (High)                                                       |  |
| 6       |        | 3          | REC START                                                                               |        |                                                                                                                                                                                                     |  |
| 7       |        | 2          | POWER ON/OFF                                                                            |        |                                                                                                                                                                                                     |  |
| 8       |        | 1          | EE                                                                                      |        |                                                                                                                                                                                                     |  |
| 9       | 0      | SP         |                                                                                         |        |                                                                                                                                                                                                     |  |
| 10      | AN     | 7          | OPERATION SW-1                                                                          | IN     |                                                                                                                                                                                                     |  |
| 11      |        | 6          | OPERATION SW-2                                                                          |        |                                                                                                                                                                                                     |  |
| 12      |        | 5          | OPERATION SW-3                                                                          |        |                                                                                                                                                                                                     |  |
| 13      | Port 4 | 4          | EXP DATA                                                                                | OUT    | 16 bit Serial data to EXPAND IC Refer to 3.1.4 - 5.                                                                                                                                                 |  |
| 14      |        | 3          | AVG FM                                                                                  | IN     | AVERAGE FM (W)                                                                                                                                                                                      |  |
| 15      |        | 2          | DET V                                                                                   |        | S-VHS/VHS PB detection, VHS : (Low), S-VHS (High)                                                                                                                                                   |  |
| 16      |        | 1          | SECAM                                                                                   | OUT    | SECAM detection; SECAM : (Low)                                                                                                                                                                      |  |
| 17      |        | 0          | S MODE                                                                                  |        | VHS : (Low), S-VHS (High)                                                                                                                                                                           |  |
| 18      | Port 3 | 7          | VP ON                                                                                   | OUT    | V. PULSE ON (H)                                                                                                                                                                                     |  |
| 19      |        | 6          | LP SPECIAL                                                                              |        | LP mode only, PB : (High), X2/SEARCH FF/SEARCH REW : (Low)                                                                                                                                          |  |
| 20      |        | 5          | AT LED                                                                                  |        | NORMAL : (High), AUTO TRACKING : (Low)                                                                                                                                                              |  |
| 21      |        | 4          | SLOW/STILL                                                                              |        | NORMAL : (High), SLOW/STILL : (Low)                                                                                                                                                                 |  |
| 22      |        | 3          | SLOW PULSE                                                                              | IN     | NORMAL : (High); SLOW :  F ADV :  |  |
| 23      |        | 2          | CAPSTAN FG                                                                              |        | SP/LP/EP detection, BACK-SPACE COUNT.                                                                                                                                                               |  |
| 24      |        | 1          | SRL DATA                                                                                |        | } 16 bit Serial data to SERVO circuit.                                                                                                                                                              |  |
| 25      |        | 0          | SRL CLOCK                                                                               |        |                                                                                                                                                                                                     |  |
| 26      | INT-1  | —          | REMOTE                                                                                  | IN     | 16-bit Serial Data (A/B code)                                                                                                                                                                       |  |
| 27      | CN Vss |            | GND                                                                                     | IN     | GND                                                                                                                                                                                                 |  |
| 28      | RESET  |            | RESET                                                                                   | IN     | AC IN RESET                                                                                                                                                                                         |  |
| 29      | X IN   |            |  CLOCK | IN     | Main System clock (6 MHz)                                                                                                                                                                           |  |
| 30      | X OUT  |            |                                                                                         | OUT    |                                                                                                                                                                                                     |  |
| 31      | φ      |            | NC                                                                                      | —      | NC                                                                                                                                                                                                  |  |
| 32      | Vss    |            | GND                                                                                     | IN     | GND                                                                                                                                                                                                 |  |
| 33      | Port 5 | 7          | CTL PULSE                                                                               | IN     | SP/LP detection                                                                                                                                                                                     |  |
| 34      |        | 6          | DRUM FF                                                                                 |        | DRUM rotation timing                                                                                                                                                                                |  |
| 35      |        | 5          | SUPPLY REEL FG                                                                          |        | } REEL rotation detect                                                                                                                                                                              |  |
| 36      |        | 4          | TAKE-UP REEL FG                                                                         |        |                                                                                                                                                                                                     |  |
| 37      |        | 3          | CASSETTE SENSOR                                                                         | IN     | CASSETTE HOUSING detection.                                                                                                                                                                         |  |
| 38      |        | 2          | REMOTE PAUSE                                                                            |        | REMOTE PAUSE Input: PAUSE ON : (Low), PAUSE OFF : (High)                                                                                                                                            |  |
| 39      |        | 1          | MODE SENS-1                                                                             |        | } MECHANISM mode detection.                                                                                                                                                                         |  |
| 40      |        | 0          | MODE SENS-2                                                                             |        |                                                                                                                                                                                                     |  |
| 41      | Port 1 | 7          | REC SAFETY SW                                                                           | IN     | REC SAFETY SW                                                                                                                                                                                       |  |
| 42      |        | 6          | START SENS.                                                                             |        | START SENSOR                                                                                                                                                                                        |  |
| 43      |        | 5          | END SENS.                                                                               |        | END SENSOR                                                                                                                                                                                          |  |
| 44      |        | 4          | S CASSETTE SW                                                                           | IN     | S CASSETTE detection, S-TAPE : (Low), NORMAL TAPE : (High)                                                                                                                                          |  |
| 45      |        | 3          | REEL (-)                                                                                | OUT    | REEL MOTOR REVERSE (High) : IN2 ⑤                                                                                                                                                                   |  |
| 46      |        | 2          | REEL (+)                                                                                | OUT    | REEL MOTOR FOWARD (High) : IN1 ⑤                                                                                                                                                                    |  |
| 47      |        | 1          | CAP (-)                                                                                 | OUT    | CAPSTAN MOTOR REVERSE (High) : IN ⑤                                                                                                                                                                 |  |
| 48      |        | 0          | CAP (+)                                                                                 | OUT    | CAPSTAN MOTOR FOWARD (High) : IN2 ⑤                                                                                                                                                                 |  |
| 49      | Port 0 | 7          | INDEX                                                                                   | IN/OUT | NORMAL : (Low), INDEX : (High)                                                                                                                                                                      |  |
| 50      |        | 6          | CTL ERASE                                                                               | OUT    | NORMAL : (Low), ERASE : (High)                                                                                                                                                                      |  |
| 51      |        | 5          | SERVO                                                                                   | OUT    | NORMAL : (Low), CAPSTAN DRIVE : (High)                                                                                                                                                              |  |
| 52      |        | 4          | D.O. CTL                                                                                | IN     | D.O. CTL ON : (Low), FMA DET (H)                                                                                                                                                                    |  |
| 53      |        | 3          | N MODE                                                                                  | OUT    | REC, EE : (Low), PB (High)                                                                                                                                                                          |  |
| 54      |        | 2          | MUTE                                                                                    | OUT    | MUTE : (Low)                                                                                                                                                                                        |  |
| 55      |        | 1          | HIFI REC START                                                                          | OUT    | REC START : (Low), NORMAL : (High)                                                                                                                                                                  |  |
| 56      |        | 0          | FE CTL                                                                                  | OUT    | FLYING ERASE HEAD CTL, ERASE ON : (Low)                                                                                                                                                             |  |
| 57      | Port 2 | 7          | L.C. MOTOR CTL-3                                                                        | OUT    | IN3 ③                                                                                                                                                                                               |  |
| 58      |        | 6          | L.C. MOTOR CTL-2                                                                        |        | IN2 ②                                                                                                                                                                                               |  |
| 59      |        | 5          | L.C. MOTOR CTL-1                                                                        |        | IN1 ①                                                                                                                                                                                               |  |
| 60      |        | 4          | STROBE                                                                                  | IN     | 4 bit TM bus                                                                                                                                                                                        |  |
| 61      |        | 3          | DATA 3                                                                                  | IN/OUT |                                                                                                                                                                                                     |  |
| 62      |        | 2          | DATA 2                                                                                  |        |                                                                                                                                                                                                     |  |
| 63      |        | 1          | DATA 1                                                                                  |        |                                                                                                                                                                                                     |  |
| 64      |        | 0          | DATA 0                                                                                  |        |                                                                                                                                                                                                     |  |



## 6.2 TIMER/DISPLAY CONTROL CIRCUIT

### 6.2.1 Timer CPU pin functions (IC1)

| Pin No. | Symbol  | Label            | IN/OUT | Contents                                                |
|---------|---------|------------------|--------|---------------------------------------------------------|
| 1       | S3      | KS D             | OUT    | KEY SCAN PULSE OUTPUT                                   |
| 2       | S2      | " C              |        |                                                         |
| 3       | S1      | " B              |        |                                                         |
| 4       | S0      | " A              |        |                                                         |
| 5       | P00     | POWER DOWN (H)   | IN     | POWER DOWN DET                                          |
| 6       | P01     | DSP SERIAL CLOCK | OUT    |                                                         |
| 7       | P02     | DSP SERIAL DATA  |        |                                                         |
| 8       | P03     | TEST (L)         | IN     | CLOCK ADJUSTMENT                                        |
| 9       | P10     | REMOTE           | IN     | 16-bit serial                                           |
| 10      | P11     | VPS DAVN         | IN     | VPS DATA DET (E, EG only)                               |
| 11      | P12     | BUSY             | IN     |                                                         |
| 12      | P13     | CNT PULSE        | IN     | CTL PULSE (REAL TIME COUNTER)                           |
| 13      | P20     | MECHAON DATA 0   | IN/OUT | T-M BUS                                                 |
| 14      | P21     | " 1              |        |                                                         |
| 15      | P22     | " 2              |        |                                                         |
| 16      | P23     | " 3              |        |                                                         |
| 17      | P30     | DSP CE (L)       | OUT    | DISPLAY SERIAL DATA CHIP ENABLE                         |
| 18      | P31     | SERIAL DATA      | IN/OUT | 8-bit VPS SERIAL DATA between Timer CPU and VPS decoder |
| 19      | P32     | SERIAL CLOCK     | OUT    |                                                         |
| 20      | P33     | DSP OFF          | OUT    | NC                                                      |
| 21      | P60     | TUNER DATA 0     | IN/OUT | T-T BUS                                                 |
| 22      | P61     | " 1              |        |                                                         |
| 23      | P62     | " 2              |        |                                                         |
| 24      | P63     | " 3              |        |                                                         |
| 25      | P40     | KS 0             | IN     | KEY SCAN DATA INPUT                                     |
| 26      | P41     | " 1              |        |                                                         |
| 27      | P42     | " 2              |        |                                                         |
| 28      | P43     | " 3              |        |                                                         |
| 29      | PP0     | FMA CTL          | OUT    | AUX : (Low), TUNER : (High)                             |
| 30      | X1      | SYSTEM CLOCK     | IN     | 4.19 MHz                                                |
| 31      | X2      |                  |        |                                                         |
| 32      | Vss     | GND              |        |                                                         |
| 33      | XT1     | GND              |        |                                                         |
| 34      | XT2     |                  |        |                                                         |
| 35      | P50     | AUX (L)          | OUT    | AUX : (Low), TUNER : (High)                             |
| 36      | P51     | TUNER STROBE     | OUT    |                                                         |
| 37      | P52     | MECHAON STROBE   | OUT    |                                                         |
| 38      | P53     | TEXT             | OUT    | TUNER : (Low), TEX : (High) (E, EG only)                |
| 39      | RESEY   | RESET (L)        | IN     |                                                         |
| 40      | T0      |                  |        |                                                         |
| 41      | T1      |                  |        |                                                         |
| 42      | T2      |                  |        |                                                         |
| 43      | T3      |                  |        |                                                         |
| 44      | T4      |                  |        |                                                         |
| 45      | T5      |                  |        |                                                         |
| 46      | T6      |                  |        |                                                         |
| 47      | T7      |                  |        |                                                         |
| 48      | T8      |                  |        |                                                         |
| 49      | T9      |                  |        |                                                         |
| 50      | T10/PH3 | RESET OUT        | OUT    | TUNER RESET : (High)                                    |
| 51      | T11/PH2 |                  |        |                                                         |
| 52      | T12/PH1 | NICAM CTL        | OUT    | (EK only)                                               |
| 53      | T13/PH0 | SIMUL (L)        | OUT    | INPUT SELECT CTL SIMUL CASTIN : (Low)                   |
| 54      | T14/S11 | KSL              | OUT    | KEY SCAN PULSE OUTPUT                                   |
| 55      | T15/S10 | KSK              |        |                                                         |
| 56      | VLOAD   | GND              | IN     | S0-S9 GND                                               |
| 57      | VPRE    | GND              |        |                                                         |
| 58      | S9      | KS J             | OUT    | KEY SCAN PULSE OUTPUT                                   |
| 59      | S8      | " I              |        |                                                         |
| 60      | S7      | " H              |        |                                                         |
| 61      | S6      | " G              |        |                                                         |
| 62      | S5      | " F              |        |                                                         |
| 63      | S4      | " E              |        |                                                         |
| 64      | VDD     | 5V               | IN     |                                                         |

## 6.3 TUNER CONTROL CIRCUIT

### 6.3.1 Tuner CPU pin functions

| Pin No. | Symbol | Label            | IN/OUT | Contents                      |
|---------|--------|------------------|--------|-------------------------------|
| 1       | XT1    | GND              | IN     |                               |
| 2       | XT2    | NC               | —      |                               |
| 3       | RESET  | RESET (L)        | IN     | SYSTEM POWER ON RESET         |
| 4       | X1     | 4.19 MHz         | IN     | SYSTEM CLOCK                  |
| 5       | X2     | 4.19 MHz         | —      |                               |
| 6       | P33    | ENABLE           | OUT    |                               |
| 7       | P32    | CLOCK            | OUT    |                               |
| 8       | P31    | DATA             | OUT    |                               |
| 9       | P30    | A. MUTE (H)      | OUT    | CH CHANGE or NO SYNC (H)      |
| 10      | P61    | NC               | —      |                               |
| 11      | P80    | NC               | —      |                               |
| 12      | P03    | GND              | —      |                               |
| 13      | P02    | GND              | —      |                               |
| 14      | P01    | GND              | —      |                               |
| 15      | P00    | STROBE           | IN     |                               |
| 16      | P11    | NC               | —      |                               |
| 17      | P12    | SYNC DET (L)     | IN     |                               |
| 18      | P11    | MAC DET (H)      | IN     |                               |
| 19      | P10    | GND              | —      |                               |
| 20      | NC     | UNSW 5 V         | —      |                               |
| 21      | VDD    | UNSW 5 V         | IN     |                               |
| 22      | P23    | MAC ON (H)       | OUT    | Cd CHANNEL (H)                |
| 23      | P22    | MAC A. MUTE (L)  | OUT    | CH CHANGE with Cd CHANNEL (L) |
| 24      | P21    | AGC DEFEAT (H)   | OUT    | CH CHANGE (H)                 |
| 25      | P20    | TUNER ON (H)     | OUT    |                               |
| 26      | P73    | NC               | —      |                               |
| 27      | P72    | MEMORY S. DATA   | OUT    |                               |
| 28      | P71    | MEMORY S. CLOCK  | OUT    |                               |
| 29      | P70    | MEMORY CS        | OUT    |                               |
| 30      | P63    | MEMORY S. DATA   | IN     |                               |
| 31      | P62    | NC               | —      |                               |
| 32      | P61    | P. MUTE (H)      | OUT    |                               |
| 33      | P60    | A. MUTE LONG (H) | OUT    |                               |
| 34      | P63    | NC               | —      |                               |
| 35      | P62    | NC               | —      |                               |
| 36      | P61    | NC               | —      |                               |
| 37      | P60    | BUSY (L)         | OUT    |                               |
| 38      | P43    | T/T BUS DATA 3   | IN/OUT |                               |
| 39      | P42    | T/T BUS DATA 2   | IN/OUT |                               |
| 40      | P41    | T/T BUS DATA 1   | IN/OUT |                               |
| 41      | P40    | T/T BUS DATA 0   | IN/OUT |                               |
| 42      | Vss    | GND              | IN     |                               |